

[Manuals.plus](#) /

> [VGR](#) /

> VGR Professional Hair Clippers and Trimmers Set VGR-600&900 User Manual

VGR VGR-600&900

VGR Professional Hair Clippers and Trimmers Set VGR-600&900 User Manual

Model: VGR-600&900

INTRODUCTION

This manual provides essential instructions for the safe and effective operation, maintenance, and troubleshooting of your VGR Professional Hair Clippers and Trimmers Set (Models VGR-600 & VGR-900). Please read this manual thoroughly before first use and retain it for future reference.

IMPORTANT SAFETY INSTRUCTIONS

- Keep away from water. Do not use while sleeping or unconscious.
- Keep out of reach of children.
- Exercise caution when handling sharp blades.
- Ensure the device is fully charged before first use to optimize battery life.
- Only use the provided charging cable and accessories.
- Do not disassemble or attempt to repair the device yourself. Contact customer support for assistance.

PACKAGE CONTENTS

Your VGR Professional Hair Clippers and Trimmers Set includes the following items:

- 1 x Hair Clipper (VGR-600)
- 1 x Precision Trimmer (VGR-900)
- 6 x Clipper Guide Combs (various sizes)
- 4 x Trimmer Guide Combs (various sizes)
- 1 x Styling Comb
- 1 x Cleaning Brush

- 1 x Type-C Charging Cable
- 1 x Lubricating Oil
- 1 x Barber Cape
- 1 x User Manual



Image: Complete VGR Hair Clippers and Trimmers Set with all included accessories.

PRODUCT FEATURES

The VGR Professional Hair Clippers and Trimmers Set is designed for precision and ease of use. Key features include:

- **Powerful Motor:** High-speed motor for efficient cutting.
- **Ultra-Sharp Blades:** Professional-grade stainless steel and ceramic blades for smooth, precise cuts.
- **LED Display:** Shows real-time battery status and oil reminder.
- **Long Battery Life:** Clipper (2000mAh) offers 200 minutes runtime; Trimmer (700mAh) offers 120 minutes runtime.
- **USB-C Charging:** Convenient and fast charging.

- **Transparent Design:** Modern aesthetic with visible internal mechanics.

Product features display



✓ ON/OFF BUTTON

Easy to operate, convenient and practical

✓ USB CHARGING

USB cable provide you to charging wherever you need.

✓ LED DISPLAY

The LED display show the power left status and add oil timely.

✓ GUIDE COMB

10 attachment guards for superior comfort and cut quality

Image: Overview of product features including power button, USB charging port, LED display, and guide comb attachment points.



7000 RPM
POWERFUL MOTOR



SHARP
BLADE

**Cutting Hair Smooth and
Won't pulled Hair**

Suitable for Thick or Curly Hair

Image: Detail of the clipper's powerful 7000 RPM motor and sharp blade, designed for smooth cutting without pulling hair.




Image: Illustration of the different guide comb sizes (1.5mm, 3mm, 4.5mm, 6mm, 10mm, 13mm) and the adjustable cutting length mechanism (0.8-2.0mm).



Ceramic and stainless steel blade

3 Hours
Charging Time
200 Mins
Operating Time
7000 RPM
DC Motor
2000 mAh
Battery



2 Hours
Charging Time
120 Mins
Operating Time
7000 RPM
DC Motor
700 mAh
Battery

Image: Specifications for the clipper and trimmer, including charging time (3 hours for clipper, 2 hours for trimmer), operating time (200 mins for clipper, 120 mins for trimmer), 7000 RPM DC motor, and battery capacity (2000mAh for clipper, 700mAh for trimmer).

SETUP AND INITIAL USE

Charging the Device

1. Before first use, fully charge both the hair clipper and the precision trimmer.
2. Connect the Type-C charging cable to the charging port on the device and to a suitable USB power adapter (not included).
3. The LED display will indicate the charging status. The clipper takes approximately 3 hours for a full charge, and the trimmer takes about 2 hours.
4. Once fully charged, disconnect the device from the power source.

Attaching Guide Combs

1. Select the desired guide comb size for your haircut or trim.

2. Align the comb with the blade and push it firmly until it clicks into place.
3. To remove, gently pull the comb away from the blade.

OPERATING INSTRUCTIONS

General Operation

- Press the ON/OFF button to power on the device. The LED display will illuminate.
- For the clipper, adjust the taper lever on the side to fine-tune the cutting length between 0.8mm and 2.0mm.
- Always start with a longer guide comb if you are unsure of the desired length.
- Move the clipper/trimmer against the direction of hair growth for an even cut.
- Regularly check the LED display for battery status and oil reminders.

Hair Cutting Tips

- Ensure hair is clean and dry before cutting.
- Use the barber cape to keep hair off clothing.
- Section hair with the styling comb for easier management.
- For detailed work and edging, use the precision trimmer without a guide comb.

MAINTENANCE AND CLEANING

Cleaning the Blades

1. After each use, turn off the device and remove any attached guide combs.
2. Use the provided cleaning brush to remove loose hairs from the blades and the device body.
3. For a more thorough cleaning, the blades can be carefully detached (refer to the blade removal section in the full manual if available).
4. Do not rinse the entire device under water. The blades can be rinsed if detached and dried completely before reattaching.

Lubricating the Blades

1. Regular lubrication is crucial for optimal performance and blade longevity.
2. After cleaning, apply 1-2 drops of the provided lubricating oil to the blades.
3. Turn on the device for a few seconds to allow the oil to distribute evenly.
4. Wipe off any excess oil with a soft cloth.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Low battery.	Charge the device fully.
Poor cutting performance / pulling hair.	Blades are dull, dirty, or not lubricated.	Clean and lubricate the blades. If problem persists, consider blade replacement.
Device overheats.	Extended continuous use or clogged blades.	Turn off the device and allow it to cool down. Clean blades thoroughly.

Problem	Possible Cause	Solution
LED display not working.	Device malfunction.	Contact customer support.

SPECIFICATIONS

- **Model Numbers:** VGR-600 (Clipper), VGR-900 (Trimmer)
- **Power Source:** USB-Charging
- **Battery Type:** Lithium-Ion
- **Clipper Battery Capacity:** 2000mAh
- **Clipper Charging Time:** Approximately 3 hours
- **Clipper Runtime:** Up to 200 minutes
- **Trimmer Battery Capacity:** 700mAh
- **Trimmer Charging Time:** Approximately 2 hours
- **Trimmer Runtime:** Up to 120 minutes
- **Motor Speed:** 7000 RPM
- **Blade Material:** Stainless Steel, High Carbon Steel
- **Item Weight:** 287 Grams
- **Package Dimensions:** 9.37 x 6.3 x 3.11 inches

WARRANTY AND SUPPORT

VGR offers a **1-year warranty** on this product from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. It does not cover damage caused by misuse, accidents, unauthorized repairs, or normal wear and tear.

For warranty claims, technical support, or any questions regarding your VGR Professional Hair Clippers and Trimmers Set, please contact VGR customer service. Please have your purchase receipt and product model number ready when contacting support.




Image: VGR customer support details, including 30-day money-back guarantee, 1-year warranty, and 24-hour support availability.



© 2026 VGR. All rights reserved.