

[Manuals.plus](#) /

> [Outfunny](#) /

> Outfunny 24V 4WD Electric Ride-On Car Toy (Model JC308) Instruction Manual

## Outfunny JC308

# Outfunny 24V 4WD Electric Ride-On Car Toy (Model JC308) Instruction Manual

For Kids 4-8 Years Old with Remote Control

## 1. PRODUCT OVERVIEW

---

The Outfunny 24V 4WD Electric Ride-On Car Toy is designed to provide an engaging and safe driving experience for children aged 4 to 8. Featuring powerful 4x200W motors, a genuine 2-seater design, and parental remote control, this vehicle is built for imaginative outdoor adventures.



Image: Two children enjoying the spacious 2-seater Outfunny electric ride-on car.

### Key Features:

- **Powerful Performance:** Equipped with 4x200W motors and switchable 2WD/4WD for stable performance on various terrains.
- **2-Seater Design:** Spacious 20-inch seats for two children, promoting shared play.
- **Parental Remote Control:** Allows parents to intervene and ensure safety.
- **High Security:** Features 3-point seat belts, lockable doors, 16mm solid steel axle, and a soft-start system.
- **Realistic Driving Experience:** Includes working headlights, rear searchlights, built-in music player, and battery level display.

## 2. SETUP AND ASSEMBLY

---

Follow these steps for proper assembly of your Outfunny ride-on car. For a visual guide, please refer to the installation video below.

Video: Official installation guide for the Outfunny 24V Ride on Car Toy. This video demonstrates the step-by-step assembly process from unboxing to final setup.

### Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging. Ensure all components listed in the manual are present.
2. **Install Front Bumper:** Attach the front bumper to the main body of the car using the provided screws.
3. **Attach Side Panels:** Secure the left and right side panels to the car's chassis. Ensure they click into place and are fastened with screws.
4. **Mount Rear Axle and Motors:** Insert the rear axle through the designated slots. Attach the motors to the axle and connect the wiring.
5. **Install Wheels:** Place the wheels onto the axles, securing them with washers and nuts. Cover the nuts with the decorative caps.
6. **Attach Windshield:** Secure the windshield to the front of the car.
7. **Install Side Mirrors:** Attach the side mirrors to the designated slots on the car's body.
8. **Connect Battery:** Open the hood and connect the battery terminals. Ensure a secure connection.
9. **Install Steering Wheel:** Connect the steering wheel's wiring and then attach it to the steering column.
10. **Secure Seats:** Place the seats into position and fasten them with screws. Connect the seat belts.
11. **Attach Roll Bar with Lights:** Install the roll bar, ensuring the lights are properly connected and secured.

## 3. OPERATING INSTRUCTIONS

---

### Starting the Vehicle:

- **Power On:** Press and hold the power button on the dashboard until the vehicle powers on.
- **Battery Check:** The dashboard display will show the current battery level.



Image: The authentic control panel of the ride-on car, showing the power button, music controls, and input port.

### Driving Modes:

- **Manual Driving:** The child can operate the vehicle using the steering wheel and foot pedal.
- **Remote Control:** Parents can use the included remote control to steer, accelerate, brake, and select speeds.
- **2WD/4WD Switch:** Use the switch on the dashboard to toggle between 2-wheel drive and 4-wheel drive for optimal performance on different terrains.

# Parents Remote Control

Full control, safe fun for little riders



Image: A parent using the remote control to operate the ride-on car, ensuring safe supervision.

## Multimedia Features:

- **Built-in Music:** Press the music buttons on the dashboard to play pre-loaded tunes.
- **Bluetooth Connectivity:** Connect your smartphone via Bluetooth to play custom music through the car's speakers.
- **Headlights & Searchlights:** Activate the working headlights and rear searchlights using the dedicated buttons.



Image: Bluetooth connectivity allows for playing custom music through the car's sound system.

## 4. SAFETY GUIDELINES

---

Always prioritize safety when operating the ride-on car. Adult supervision is required at all times.

### Important Safety Features:

- **Seat Belts:** Ensure children are securely fastened with the 3-point seat belts before driving.
- **Lockable Doors:** The car features lockable doors to prevent accidental opening during operation.
- **Soft-Start System:** Provides gradual acceleration to prevent sudden jolts and ensure a safer ride.

- **Weight Capacity:** Do not exceed the maximum weight capacity of 150 lbs.



## 3-Point Harness

Secure adventures for little explorers

Image: A child secured by the 3-point harness, highlighting the safety features of the vehicle.

## 5. MAINTENANCE

### Battery Charging:

- **Initial Charge:** Charge the battery for 8-12 hours before first use.
- **Regular Charging:** Recharge the battery after each use for 8-12 hours. Do not overcharge.
- **Charging Port:** The charging port is located on the dashboard. Use only the provided charger.

## Cleaning and Storage:

- **Cleaning:** Wipe the vehicle with a damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the vehicle in a dry, cool place away from direct sunlight. If storing for extended periods, charge the battery monthly.

## 6. TROUBLESHOOTING

---

### Common Issues:

- **Vehicle Not Moving:** Check battery connection, ensure the battery is charged, and verify the power switch is on.
- **Remote Control Not Working:** Ensure batteries in the remote are fresh and correctly inserted. Re-pair the remote with the vehicle if necessary (refer to the full user manual for pairing instructions).
- **Reduced Power/Speed:** This may indicate a low battery charge or an overloaded vehicle. Charge the battery or reduce the load.

## 7. SPECIFICATIONS

---



Image: Visual representation of the ride-on car's dimensions and recommended age/load capacity.

| Feature          | Detail              |
|------------------|---------------------|
| Brand            | Outfunny            |
| Model Number     | JC308               |
| Motor            | 4x200W              |
| Battery          | 24V                 |
| Seating Capacity | 2-Seater (20" wide) |

| Feature                     | Detail                |
|-----------------------------|-----------------------|
| Max Weight Capacity         | 150 Pounds            |
| Recommended Age             | 4-8 Years             |
| Item Weight                 | 60.4 Pounds           |
| Item Dimensions (L x W x H) | 47.2" x 31.5" x 32.3" |

## 8. WARRANTY AND SUPPORT

---

For warranty information, technical support, or replacement parts, please contact Outfunny customer service directly. Refer to your purchase documentation for specific contact details.

You can also visit the [Outfunny Store on Amazon](#) for more product information and support.