

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [GardePro](#) /

› GardePro MB300 Lockable Security Box Instruction Manual

GardePro MB300

GardePro MB300 Lockable Security Box Instruction Manual

Model: MB300

1. INTRODUCTION

The GardePro MB300 Lockable Security Box is designed to provide enhanced protection for your compatible GardePro trail camera. This robust metal case helps to deter theft, vandalism, and unauthorized access, ensuring your camera remains secure in outdoor environments. It is engineered for durability and ease of installation, offering peace of mind when deploying your trail camera.



Image 1: The GardePro MB300 Lockable Security Box alongside its brown cardboard packaging.

2. COMPATIBILITY

This security box is specifically designed for use with the following GardePro trail camera models. Please verify your camera model before installation to ensure proper fit and function.

- E5 2.0
- A60
- T5NG Pro
- T5CF Pro
- T5WF Pro
- T6LRW
- E6+
- E6 2.0
- E8 2.0

- E9 2.0
- A80
- X70
- X80
- X80 Pro

Note: This security box is not compatible with any other GardePro models not listed above.

3. PACKAGE CONTENTS

The GardePro MB300 package includes:

- 1 x GardePro MB300 Lockable Security Box

Note: Padlocks, security cables, and mounting screws are not included and must be purchased separately. The camera strap is typically included with your GardePro trail camera.

4. SETUP AND INSTALLATION

4.1 Inserting the Trail Camera

1. Open the front panel of the security box.
2. Carefully slide your compatible GardePro trail camera into the security box, ensuring it fits snugly and the lens, sensors, and controls are aligned with the box's openings.
3. Close the front panel of the security box.



Image 2: A GardePro trail camera securely placed inside the MB300 security box.

4.2 Mounting the Security Box

The security box offers flexible mounting options:

- **Strap Mounting:** Use the strap provided with your trail camera to secure the security box to a tree or post. Thread the strap through the designated slots on the back of the security box and tighten it firmly.
- **Screw Installation:** For a more permanent setup, the security box can be screwed directly into a wall or post. Use appropriate screws (not included) through the pre-drilled holes on the back of the box. Ensure the mounting surface is sturdy enough to support the camera and box.
- **Cable Lock:** The box features openings for a cable lock (not included) to further secure it to an immovable object, providing an additional layer of theft deterrence.



Image 3: The GardePro security box, with a trail camera inside, mounted on a tree in a natural environment.

5. OPERATING THE LOCKABLE DESIGN

Once your trail camera is inside the MB300 security box and the front panel is closed, you can secure it using a padlock (not included). The box has a reinforced loop designed to accommodate standard padlocks. Insert the padlock through this loop and lock it to prevent unauthorized opening of the box. This feature enhances the security of your trail camera against tampering and theft.

6. MAINTENANCE

The GardePro MB300 security box requires minimal maintenance:

- **Cleaning:** Periodically wipe the exterior of the box with a damp cloth to remove dirt, dust, or debris. Avoid using harsh chemicals or abrasive cleaners.
- **Inspection:** Regularly inspect the box for any signs of damage, such as dents or cracks, which could compromise its protective capabilities. Ensure all mounting points remain secure.
- **Lock Mechanism:** If using a padlock, ensure it is functioning correctly and lubricate it if necessary to prevent seizing.

7. TROUBLESHOOTING

7.1 Camera Does Not Fit

Issue: The trail camera does not fit into the security box.

Solution: Verify that your trail camera model is listed under the "Compatibility" section (Section 2). This security box is designed for specific GardePro models only. If your model is not listed, it is not compatible.

7.2 Box Feels Loose After Mounting

Issue: The security box feels loose or unstable after mounting.

Solution:

- If using a strap, ensure it is threaded correctly through all slots and pulled as tight as possible.
- If using screws, check that the screws are fully tightened and that the mounting surface is solid and not deteriorating.
- Ensure the camera itself is properly seated within the box.

7.3 Difficulty Locking the Box

Issue: The padlock does not fit or is difficult to secure.

Solution: Ensure you are using a padlock of appropriate size for the security loop. The loop is designed for standard-sized padlocks. Avoid forcing the lock.

8. SPECIFICATIONS

Feature	Detail
Model Number	MB300
Brand	GardePro
Color	Black
Item Dimensions (L x W x H)	7.4 x 4.81 x 2.68 inches
Item Weight	12.64 ounces
Material	Metal (Protective Case)
Mounting Options	Strap, Screws, Cable Lock

9. WARRANTY INFORMATION

The GardePro MB300 Lockable Security Box is covered by a **1-Year Manufacturer Warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For specific terms and conditions, refer to the warranty documentation provided with your product or contact GardePro customer support.

10. CUSTOMER SUPPORT

If you have any questions, require technical assistance, or need to report an issue with your GardePro MB300 Lockable Security Box, please contact GardePro customer support. Refer to the official GardePro website or product packaging for the most current contact information.

Online Resources: Visit the official GardePro website for FAQs, product registration, and additional support materials.

