

Lamshaw Hard Shell Travel and Storage Carrying Case

Lamshaw Hard Shell Carrying Case for AGXOV M302 MP3 Player

User Manual

1. INTRODUCTION

Thank you for choosing the Lamshaw Hard Shell Carrying Case. This case is designed to provide robust protection and organized storage for your AGXOV M302 4.02-inch MP4/MP3 player and its accessories. Its durable construction and thoughtful design ensure your devices are safe during travel and daily use.

2. PRODUCT FEATURES

- **Premium Protection:** This hard-shell storage case provides superior protection for your valuable electronic accessories, keeping them safe from accidental drops, bumps, and scratches.
- **Organized Storage:** The interior of the case features elastic mesh fences on both side lids, allowing you to conveniently store and organize cables, earbuds, and other electronic accessories without tangling.
- **Secure Zipper Closure:** The case is equipped with a reliable zipper closure that ensures secure storage while you're on the move, providing peace of mind that your accessories are protected.
- **Versatile Use:** This storage case is perfect for earbuds, earphones, tools, USB cables, chargers, and various other electronic accessories. It can also be used for organizing and storing small items like jewelry, coins, or keys.
- **Portable Design:** This case is easily portable in purses, bags, or backpacks, allowing you to carry your essentials with ease wherever you go.

3. SETUP

1. **Unpack the Case:** Carefully remove the carrying case from its packaging.
2. **Inspect for Damage:** Before first use, inspect the case for any signs of damage that may have occurred during shipping. If any damage is found, please contact customer support.
3. **Prepare for Use:** Open the zipper and ensure the interior is clean and free of debris. The case is now ready to store your devices.



Figure 3.1: Interior view of the open carrying case, highlighting the mesh pocket and elastic strap for organization.


4. OPERATING INSTRUCTIONS

1. **Placing Your Device:** Gently place your AGXOV M302 MP3/MP4 player into one side of the case. The soft interior lining helps prevent scratches.
2. **Organizing Accessories:** Utilize the elastic mesh pocket on the opposite side to store smaller accessories such as earbuds, charging cables, or memory cards. The elastic strap can secure larger items.
3. **Securing the Case:** Once all items are placed, carefully close the zipper completely to ensure a secure seal. This protects your contents from dust and accidental spills.
4. **Portability:** The compact design allows for easy placement in backpacks, purses, or travel bags, ensuring your device and accessories are protected on the go.



1 High-quality
EVA shell

2 Durable and
smooth zipper



3 Internal fixed
mesh bag

Figure 4.1: Key features of the case, including the high-quality EVA shell, durable zipper, and internal mesh bag for accessory organization.



Figure 4.2: The compact case fits easily into a backpack, demonstrating its portability for daily use or travel.

5. MAINTENANCE

- **Cleaning:** To clean the exterior, wipe with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used, followed by wiping with a clean, damp cloth. Allow to air dry completely.
- **Interior Care:** The interior can be gently wiped with a dry or slightly damp cloth. Avoid excessive moisture.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or harsh chemicals as these may damage the case material.
- **Storage:** When not in use, store the case in a cool, dry place away from direct sunlight to maintain its integrity.

6. TROUBLESHOOTING

- **Zipper Stiffness:** If the zipper feels stiff, apply a small amount of zipper lubricant or a graphite pencil lead along the teeth. Operate the zipper back and forth several times to distribute the lubricant.

- **Minor Scratches/Scuffs:** For minor surface marks on the hard shell, a gentle rub with a soft cloth may help reduce their visibility.
- **Case Not Closing Properly:** Ensure no items are obstructing the zipper path or overfilling the case. Rearrange contents to allow for smooth closure.



Figure 6.1: The hard-shell design provides impact protection, safeguarding your device from accidental drops.

7. SPECIFICATIONS

Brand	Lamshaw
Compatible Devices	AGXOV M302 MP3 Players, Oilsky M30 PRO MP3 Players, SWOFY M503 Pro MP3 Players, ZAQE M505 MP3 Players
Shell Type	Hard
Form Factor	Case
Color	Black
Special Features	Dust Resistant
Item Weight	0.88 ounces
Package Dimensions	4.84 x 1.18 x 0.67 inches

8. WHAT'S IN THE BOX

- 1 x Lamshaw Hard Shell Carrying Case (Black)

9. WARRANTY INFORMATION

Warranty information for this product is not available in the provided data. Please refer to the product packaging or contact the retailer/manufacturer directly for details regarding warranty coverage.

10. CUSTOMER SUPPORT

Specific customer support contact information is not available in the provided data. For assistance, please refer to the contact details provided with your purchase or visit the official Lamshaw website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question