

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [TIMEX](#) /
- › [TIMEX Main Street Analog Watch TW5M61200JQ User Manual](#)

TIMEX TW5M61200JQ

TIMEX Main Street Analog Watch TW5M61200JQ User Manual

INTRODUCTION

This manual provides essential instructions for the setup, operation, maintenance, and troubleshooting of your TIMEX Main Street Analog Watch, model TW5M61200JQ. Please read this guide thoroughly to ensure proper use and care of your timepiece.



Image: Front view of the TIMEX Main Street Analog Watch with a black dial and black silicone strap.

SETUP

1. Setting the Time

1. **Pull out the crown:** Locate the crown on the right side of the watch case. Gently pull it out to the first position.
2. **Adjust the time:** Rotate the crown clockwise or counter-clockwise until the hour and minute hands display the correct time.
3. **Push in the crown:** Once the time is set, push the crown back into its original position to start the watch movement.



Image: Side view of the watch, highlighting the crown used for time adjustment.

2. Adjusting the Strap

The silicone strap features a traditional buckle clasp for secure and comfortable wear. Adjust the strap by inserting the pin into the desired hole to fit your wrist size. Ensure the watch is snug but not overly tight to allow for proper circulation.

OPERATING THE WATCH

Your TIMEX Main Street Analog Watch is powered by a reliable Quartz movement, providing accurate timekeeping. Once the time is set, the watch will continuously display the current time.

Water Resistance

This watch is water resistant up to 50 meters (5 ATM). This means it is suitable for short periods of recreational swimming, showering, or washing hands. It is **not** suitable for diving, snorkeling, or high-impact water sports. Always ensure the crown is fully pushed in before any contact with water.



Image: Close-up of the watch's stainless steel back, displaying the 'WR 50 METERS' water resistance marking.

MAINTENANCE

Cleaning Your Watch

- Wipe the watch case and strap regularly with a soft, dry cloth to remove dirt and perspiration.
- For silicone straps, a mild soap and water solution can be used, followed by thorough rinsing and drying.
- Avoid using harsh chemicals or abrasive materials, as these can damage the watch's finish.

Battery Replacement

The watch is powered by a product-specific battery. When the watch stops running, it indicates that the

battery needs replacement. Battery replacement should be performed by a qualified watch technician to ensure the watch's water resistance is maintained.

Water Resistance Care

- Do not operate the crown or pushers (if present) while the watch is wet or submerged in water.
- Avoid exposing the watch to extreme temperature changes, as this can affect the seals.
- Have the water resistance seals checked periodically by a professional, especially after battery replacement.

TROUBLESHOOTING

- **Watch not running:** Check if the crown is fully pushed in. If it is, the battery may need replacement.
- **Incorrect time:** Reset the time as described in the 'Setting the Time' section. If the time continues to be inaccurate, the watch may require servicing.
- **Condensation under crystal:** This may indicate a loss of water resistance. Avoid further contact with water and have the watch inspected by a professional immediately.

SPECIFICATIONS

Model Number	TW5M61200JQ
Display Type	Analog
Movement Type	Quartz
Case Diameter	42 Millimetres
Case Thickness	12.5 Millimetres
Case Shape	Round
Dial Colour	Black
Crystal Material	Mineral
Band Material Type	Silicone
Band Colour	Black
Band Width	22 Millimetres
Clasp Type	Buckle
Water Resistance Depth	50 Metres (5 ATM)
Battery	1 Product Specific battery (included)

WARRANTY INFORMATION

Your TIMEX Main Street Analog Watch TW5M61200JQ comes with a **1-year warranty** against manufacturing defects from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from improper handling, accidents, unauthorized repairs, or normal wear and tear.

Please retain your proof of purchase for warranty claims.

CUSTOMER SUPPORT

For any questions, service, or warranty claims regarding your TIMEX watch, please contact the manufacturer or authorized service center.

Manufacturer/Importer Contact:

Timex Group India Limited

Plot No. 10, Industrial Area- Katha

Bhatoli Kalan, Baddi, Himachal Pradesh – 173205

For additional support and information, you may visit the official TIMEX website.