Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- HYUNDAI /
- > Hyundai 65-Inch Frameless WebOS 4K UHD Smart LED TV User Manual Model L65HYNDA650

HYUNDAI L65HYNDA650

HYUNDAI

65-Inch Frameless WebOS 4K UHD Smart LED TV

Model: L65HYNDA650 User Manual

1. Introduction

Thank you for choosing the Hyundai 65-Inch Frameless WebOS 4K UHD Smart LED TV, Model L65HYNDA650. This manual provides essential information for the safe and efficient operation of your new television. Please read it thoroughly before use and retain it for future reference.

2. Safety Information

Always observe the following safety precautions to prevent electric shock, fire, or injury:

- Do not expose the TV to rain or moisture.
- Do not open the TV casing; refer all servicing to qualified personnel.
- Ensure proper ventilation around the TV.
- Unplug the TV during lightning storms or when unused for long periods.
- Keep the TV away from direct sunlight, heat sources, and strong magnetic fields.

3. Package Contents

Verify that all items are present in the package:

- Hyundai 65-Inch Smart LED TV
- Magic Remote Control
- TV Stand components
- User Manual (this document)
- Power Cable

4. Product Overview

The Hyundai L65HYNDA650 is a 65-inch Frameless WebOS 4K UHD Smart LED TV designed for an

immersive viewing experience. It features a high-resolution display, smart functionality powered by webOS 2.0, and versatile connectivity options.



Image 1: Front view of the Hyundai 65-Inch Smart LED TV with the included Magic Remote.



Image 2: The Hyundai Magic Remote Control, featuring dedicated buttons for smart functions and navigation.

5. Setup

5.1 Unpacking

Carefully remove the TV from its packaging. It is recommended to have two people for this process due to the size and weight of the television.

5.2 Stand Installation

To install the TV stand:

- 1. Place the TV screen-down on a soft, flat surface to prevent scratches.
- 2. Align the stand components with the designated slots on the bottom of the TV.
- 3. Secure the stand using the provided screws. Ensure the stand is firmly attached before placing the TV upright.

5.3 Connecting Peripherals

Your TV offers various connectivity options:

• HDMI Ports (x3): Connect external devices such as Blu-ray players, gaming consoles, or set-top boxes.

- USB Ports (x2): Connect USB storage devices for media playback or software updates.
- Antenna/Cable Input: Connect your antenna or cable for the built-in T2/S2 receiver.
- Network (LAN/Wi-Fi): Connect to your home network for internet access and smart features.
- Bluetooth: Pair with compatible audio devices or accessories.

5.4 Initial Power On

After connecting the power cable, press the power button on the TV or the Magic Remote. Follow the on-screen instructions for initial setup, including language selection (English, Arabic, French, German, Italian, Spanish, Dutch), network configuration, and channel scanning.

6. Operating

6.1 Magic Remote Control

The Magic Remote allows intuitive control of your TV. Point and click, use the scroll wheel, or utilize voice commands for navigation. Specific buttons are available for quick access to popular streaming services and settings.

6.2 Basic TV Functions

- Power On/Off: Press the power button on the remote.
- Volume Control: Use the Volume Up/Down buttons.
- Channel Selection: Use the Channel Up/Down buttons or the number pad.
- Input Source: Press the 'Input' button to select between HDMI, USB, or TV tuner.

6.3 Smart Features (webOS 2.0)

Your TV runs on webOS 2.0, providing a user-friendly smart TV experience:

- Home Dashboard: Access apps, connected devices, and settings from the customizable home screen.
- App Store: Download and install additional applications.
- E-share / Screen Mirroring: Wirelessly share content from compatible mobile devices to your TV.
- Bluetooth Connectivity: Connect Bluetooth headphones, soundbars, or other accessories.

7. Maintenance

7.1 Cleaning the TV

- Screen: Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a specialized screen cleaner. Do not spray liquid directly onto the screen.
- Casing: Wipe the TV casing with a soft, dry cloth. Avoid using abrasive cleaners or solvents.

7.2 Software Updates

Periodically check for software updates through the TV's settings menu to ensure optimal performance and access to the latest features.

8. Troubleshooting

If you encounter issues, refer to the following common solutions:

Problem	Possible Solution
No power	Check if the power cable is securely connected and the power outlet is working.
No picture, but sound is present	Verify the correct input source is selected. Check external device connections.
No sound, but picture is present	Check volume level and mute settings. Ensure external audio devices are properly connected.
Remote control not working	Replace batteries. Ensure no obstructions between the remote and the TV. Re-pair the Magic Remote if necessary.
Cannot connect to Wi-Fi	Check your router and internet connection. Re-enter Wi-Fi password. Try restarting the TV and router.
Smart apps not loading	Ensure a stable internet connection. Try restarting the app or the TV. Check for software updates.

9. Specifications

Feature	Detail
Model Number	L65HYNDA650
Screen Size	65 Inches
Display Technology	LED
Resolution	4K UHD (3840x2160)
Refresh Rate	60Hz
Smart Platform	webOS 2.0
RAM	1.5GB
Storage	8GB
Connectivity	3 HDMI, 2 USB, Bluetooth, Wi-Fi, E-share
Built-in Receiver	T2/S2
Audio Output	Dual 8W Speakers
Product Dimensions (D x W x H)	8.4 x 147 x 84 cm
Item Weight	21 kg
Special Features	Frameless Design, Magic Remote, UHD 4K
Language Support	English, Arabic, French, German, Italian, Spanish, Dutch

10. Warranty and Support

Your Hyundai TV is covered by a manufacturer's warranty. Please refer to the warranty card included with your product for specific terms and conditions. For technical support or service inquiries, please contact your retailer

or the authorized Hyundai service center in your region.

Related Documents - L65HYNDA650

HYUNDAI LITERATION TO THE PROPERTY OF THE PRO	Hyundai HLP32T356 Instruction Manual Comprehensive user guide for the Hyundai HLP32T356 television, covering setup, operation, safety, features, specifications, and troubleshooting.
OWNERS MANAGE WARRING WARRIN	Hyundai Azera Owner's Manual: Operation, Maintenance, and Specifications Comprehensive owner's manual for the Hyundai Azera, covering operation, maintenance, safety features, and specifications. Includes guidance on fuel requirements, break-in procedures, and instrument cluster symbols.
HYUNDAI FLA40450 Instruction Manual	Hyundai FLA40450 LED TV: User Manual, Setup Guide & Features Comprehensive user manual for the Hyundai FLA40450 LED TV. Learn about setup, remote control, connectivity (HDMI, USB), smart features, picture/sound settings, safety, and troubleshooting. Get the most from your Hyundai television.
NEXO fuel cell	HYUNDAI NEXO Fuel Cell: Gen5 Premium Class Navigation Owner's Manual This owner's manual provides comprehensive guidance for the HYUNDAI NEXO fuel cell's Gen5 Premium Class Navigation system, covering operation, features, safety, and troubleshooting.
HYUNDAI HLA24354 Navod k použiti Nivod na použiti Instrukcju obsługi	Hyundai HLA24354 Instruction Manual This document provides comprehensive instructions for the Hyundai HLA24354 television, covering setup, operation, features, and troubleshooting. Learn how to connect devices, navigate menus, and optimize your viewing experience.
	HYUNDAI LP40 True Wireless Earphones User Manual and Specifications Official user manual and technical specifications for the HYUNDAI LP40 True Wireless Earphones, covering setup, operation, safety, warranty, and FCC compliance.