

Yilezena B0F2GHYRV5

Yilezena 3-in-1 Convertible Sofa Bed with USB Ports - User Manual

Model: B0F2GHYRV5

[Introduction](#) [Safety](#) [Components](#) [Assembly](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Support](#)

1. INTRODUCTION

Thank you for choosing the Yilezena 3-in-1 Convertible Sofa Bed. This versatile furniture piece is designed to function as a comfortable sofa, a relaxing lounger, and a convenient sleeper bed, making it ideal for various living spaces. This manual provides essential information for safe assembly, operation, maintenance, and troubleshooting to ensure optimal use and longevity of your product.

2. SAFETY INFORMATION

- Read all instructions carefully before assembly and use.
- Keep children and pets away from the assembly area. Small parts can be a choking hazard.
- Ensure all connections are securely tightened before use. Periodically check and re-tighten fasteners.
- Do not exceed the maximum weight capacity of 800 pounds.
- Avoid standing or jumping on the sofa bed.
- Place the sofa bed on a level surface to prevent tipping.
- Keep away from open flames and direct heat sources.
- When converting the sofa, ensure no objects or body parts are in the path of moving components.

3. INCLUDED COMPONENTS

Please verify that all components listed below are present before beginning assembly:

- Arm (Left & Right) x 2
- Pillow x 2
- Screwdriver x 1
- Seat frame
- User Manual (this document)

4. ASSEMBLY INSTRUCTIONS

Assembly is required for this product. Please follow the detailed instructions provided in the separate assembly guide included in your package. Ensure all parts are correctly oriented and securely fastened.



Figure 4.1: The Yilezena sofa in its compact, assembled form. This image shows the sofa ready for use after assembly.

Key Assembly Steps:

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Attach the arms to the main seat frame using the provided hardware and screwdriver.
3. Ensure all bolts are tightened securely. Do not overtighten.
4. Place the pillows on the sofa.

If you encounter any difficulties during assembly, refer to the troubleshooting section or contact customer support.

5. OPERATING INSTRUCTIONS

5.1. Converting from Sofa to Bed

The Yilezena sofa bed features an effortless 3-in-1 conversion mechanism. To transform the sofa into a lounger or a full-size bed:

1. Ensure there is sufficient clear space in front of the sofa for extension.
2. Locate the dual pull straps positioned at the front base of the sofa.
3. Gently pull the straps outwards and upwards. The pull-out section will glide forward on its smooth-rolling wheels.
4. Continue pulling until the section is fully extended, forming a flat sleeping surface.
5. To convert back to a sofa, push the extended section back into the base until it locks into place.



Figure 5.1: The sofa bed in its lounge configuration, with the pull-out section partially extended.

DETAILS



Figure 5.2: The sofa bed fully extended, providing a flat sleeping surface.

5.2. Adjusting the Backrest

The backrest offers three adjustable positions for customized comfort:

- **105° Upright:** Ideal for sitting and working.
- **138° Recline:** Suitable for relaxing or reading.
- **180° Flat Bed:** For sleeping or lounging fully extended.

To adjust, gently push the backrest forward until you hear a click, then recline it to your desired position. To return to an upright position, push it fully forward until it resets, then recline to the first click.



Sofa



Recliner



Bed

3 - Level Adjustable Backrest

This sleeper sofa bed comes with a 3-level adjustable backrest, This convertible sofa can meet your various needs, perfect for sitting, lying or sleeping



Figure 5.3: Visual representation of the 3-level adjustable backrest feature.

5.3. Using USB Charging Ports

Dual USB charging ports are integrated into the armrests for convenient device charging.

1. Locate the USB ports on the side of the armrest.
2. Plug your device's USB charging cable into the port.
3. Ensure the sofa bed is connected to a power source for the USB ports to function.



Figure 5.4: Close-up of the armrest showing the integrated USB charging ports and side storage pockets.

5.4. Utilizing Storage Pockets

The side storage pockets are designed to keep small items organized and within reach.

- Use the pockets to store remote controls, magazines, books, or other small personal items.

5.5. Locking Caster Wheels

The pull-out section is equipped with locking caster wheels for easy repositioning and stability.

- To move the sofa bed, ensure the wheels are unlocked.
- Once in the desired position, press down on the locking mechanism on each wheel to secure the sofa bed in place.



Figure 5.5: Detail of the pull-out mechanism, highlighting the locking caster wheels.

6. MAINTENANCE AND CARE

Proper care will extend the life and appearance of your Yilezena sofa bed.

6.1. Fabric Care (Velvet)

- **Regular Cleaning:** Vacuum regularly using an upholstery attachment to remove dust and debris.
- **Spot Cleaning:** For spills, blot immediately with a clean, dry cloth. Do not rub, as this can spread the stain and damage the velvet pile. For stubborn stains, use a mild, water-free solvent or dry-cleaning product. Always test on an inconspicuous area first.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading.

6.2. Frame and Mechanism Care

- Wipe the metal frame and other non-fabric surfaces with a soft, damp cloth. Avoid harsh chemicals.
- Periodically check all bolts and fasteners and re-tighten if necessary to maintain stability.
- Keep the pull-out mechanism free of obstructions.

7. TROUBLESHOOTING

If you encounter issues with your sofa bed, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Sofa bed difficult to convert	Obstruction in mechanism; wheels locked; mechanism needs lubrication.	Check for obstructions. Ensure wheels are unlocked. Apply a silicone-based lubricant to moving parts if necessary.
USB ports not charging	Sofa not connected to power; faulty cable/device; port malfunction.	Ensure the sofa bed is plugged into a working power outlet. Test with a different cable and device. If issue persists, contact support.

Problem	Possible Cause	Solution
Backrest not adjusting	Mechanism jammed; not pushed fully forward to reset.	Ensure no obstructions. Push the backrest fully forward until it clicks to reset the mechanism, then try adjusting again.
Sofa feels unstable	Loose fasteners; uneven surface; wheels unlocked.	Check and re-tighten all assembly fasteners. Place the sofa on a level surface. Ensure caster wheels are locked when stationary.

If these solutions do not resolve the issue, please contact Yilezena customer support for further assistance.

8. SPECIFICATIONS

Key specifications for the Yilezena 3-in-1 Convertible Sofa Bed:

- **Brand:** Yilezena
- **Model:** B0F2GHYRV5
- **Product Dimensions (Sofa):** 55"D x 38.5"W x 32.3"H
- **Seat Depth:** 20.86 inches
- **Seat Height:** 17.71 Inches
- **Item Weight:** 98 Pounds
- **Weight Capacity:** 800 Pounds
- **Seating Capacity:** 2
- **Material:** Velvet, Metal, Wood
- **Fill Material:** Spring + Foam
- **Upholstery Fabric Type:** Velvet
- **Color:** Black
- **Special Features:** 3-position adjustable backrest, Dual USB charging ports, Instant sofa-to-bed conversion, Locking caster wheels, Side storage pockets.
- **Assembly Required:** Yes

9. WARRANTY AND CUSTOMER SUPPORT

For warranty information, please refer to the documentation included with your purchase or visit the official Yilezena website. If you have any questions, require assistance with assembly, or need troubleshooting support, please contact Yilezena customer service. Contact details can typically be found on the product packaging or the brand's official online store.

We are committed to providing you with a high-quality product and excellent service.