

[Manuals.plus](#) /

› [Jocoevol](#) /

› Jocoevol Fluted 7 Drawers Dresser (Model C-0642) User Manual

Jocoevol C-0642

Jocoevol Fluted 7 Drawers Dresser User Manual


MODEL: C-0642

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your Jocoevol Fluted 7 Drawers Dresser, Model C-0642. Please read all instructions carefully before beginning assembly and retain this manual for future reference. Proper assembly and care will ensure the longevity and optimal performance of your dresser.

Product Overview

The Jocoevol Fluted 7 Drawers Dresser is designed with a modern minimalist aesthetic, featuring wavy fluted panels and classic black metal handles. It offers ample storage and can be utilized in various rooms, including bedrooms, living rooms, hallways, and entryways. The dresser is constructed from premium MDF wood with robust metal glides for smooth drawer operation.



The dresser features seven spacious drawers for organized storage.



Key features include smooth glides, a waterproof tabletop, and a delicate vertical stripe design.



Smooth Glide



Waterproof Tabletop



Delicate Vertical Stripes Design



Large Capacity Storage

Constructed with environmental friendly materials, offering a waterproof and easy-to-clean surface.



The dresser's versatile design allows it to fit seamlessly into various home environments.

Specifications

Feature	Detail
Brand	Jocoevol
Model Name	7 Drawer Dresser
Model Number	C-0642
Product Dimensions	15.4"D x 51.2"W x 32.5"H
Number of Drawers	7
Color	White & Wood
Material	Engineered Wood

Finish Type	Polished
Item Weight	103.6 Pounds
Assembly Required	Yes
Room Type	Bedroom, Closet, Entryway, Hallway, Living Room



Refer to this diagram for detailed product dimensions.

Assembly Instructions

Your Jocoevol Fluted 7 Drawers Dresser is designed for straightforward assembly. Please ensure all parts are present before beginning. A detailed visual guide is provided in the video below. Follow the steps carefully to ensure correct and secure construction.

1. Unpack all components and hardware. Verify against the parts list in your package.

2. Assemble the main frame of the dresser, attaching the side panels, back panel, and support beams.
3. Install the drawer slides onto the interior of the dresser frame.
4. Assemble each of the seven drawers individually, ensuring the bottom panel and front fluted panel are securely attached.
5. Attach the drawer slides to the assembled drawers.
6. Carefully insert the assembled drawers into the dresser frame.
7. Secure the anti-tip kit to the back of the dresser and to a wall stud to prevent accidental tipping.

Your browser does not support the video tag. Please refer to the written instructions or contact support.

Watch this video for a complete visual guide on assembling your Jocoevol Fluted 7 Drawers Dresser.

Operating Instructions

The Jocoevol Fluted 7 Drawers Dresser is designed for simple operation.

- **Opening/Closing Drawers:** Use the metal handles to gently pull drawers open and push them closed. Avoid excessive force to ensure smooth operation of the metal glides.
- **Weight Distribution:** Distribute items evenly within drawers to prevent strain on the glides and maintain stability. Avoid placing excessively heavy items in a single drawer.
- **Top Surface Use:** The wide top surface can hold decorative items, photos, or a television. Ensure the weight placed on the top does not exceed the dresser's stability limits.

Maintenance

To keep your dresser in optimal condition, follow these maintenance guidelines:

- **Cleaning:** The thickened top is waterproof and easy to clean. Use a soft, damp cloth to wipe down surfaces. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Spills:** Wipe up spills immediately to prevent moisture damage, especially on non-waterproof surfaces.
- **Hardware:** Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary to maintain structural integrity.
- **Drawer Glides:** If drawer operation becomes less smooth, a small amount of silicone-based lubricant can be applied to the metal glides.

Safety Information

To ensure the safety of your household, especially children and pets, it is crucial to install the included anti-tip kit.

Quality Drawers Dresser



Environmental
Friendly



Waterproof



Easy to
clean



Stable



Always secure the dresser to a wall using the anti-tip kit to prevent accidental tipping.

Warning: Furniture can tip over, causing serious or fatal injuries. Always use tip-over restraints. Never allow children to climb or hang on drawers, doors, or shelves.

Troubleshooting

- **Wobbly Dresser:** Ensure all cam locks and screws are fully tightened. Verify that the dresser is placed on a level surface. Adjust floor glides if present.
- **Drawers Not Closing Smoothly:** Check that drawer slides are correctly installed and aligned on both the drawer and the dresser frame. Ensure no objects are obstructing the drawer's path.
- **Missing Parts:** If any parts are missing or damaged upon arrival, do not proceed with assembly. Contact customer support for assistance.

Warranty and Support

Jocoevol is committed to providing excellent service. If you have any questions or require assistance before or after your purchase, please do not hesitate to contact us. We aim to reply to all inquiries within 24 hours.

This product is eligible for a 30-day easy return policy. Please refer to your purchase documentation for specific warranty details and contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question