

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Shark](#) /

> [Shark PowerPro Flex Reveal Plus Cordless Vacuum IZ382H Instruction Manual](#)

Shark IZ382H

Shark PowerPro Flex Reveal Plus Cordless Vacuum

Model: IZ382H

1. PRODUCT OVERVIEW AND COMPONENTS

The Shark PowerPro Flex Reveal Plus Cordless Vacuum is designed for efficient cleaning across various surfaces. This section details the main components of your vacuum.



Image: The Shark PowerPro Flex Reveal Plus Cordless Vacuum shown with its main body, flexible

wand, floor nozzle, and included accessories like the crevice tool and upholstery tool.

Included Accessories:

- 8-inch Crevice Tool
 - Upholstery Tool
-

2. SETUP AND INITIAL USE

Assembly

1. Insert the wand into the floor nozzle until it clicks securely into place.
2. Insert the handheld vacuum into the top of the wand until it clicks securely into place.
3. Ensure all connections are firm before operation.

Charging the Battery

The vacuum is powered by a removable battery. For optimal performance, fully charge the battery before first use.

- Remove the battery by pressing the release button and sliding it out.
- Connect the charger to the battery and plug it into a power outlet.
- The battery indicator lights will show charging status. A full charge provides up to 50 minutes of runtime (measured at the handvac in standard mode).
- Once charged, reinsert the battery into the handheld vacuum until it clicks.



**Up to 50 minutes of
removable battery runtime***

Simply pop it out for easy charging and pop in for whole-home cleaning.

*Measured at the handvac in standard mode.

Image: The Shark PowerPro Flex Reveal Plus vacuum in use, illustrating its cordless operation and highlighting the removable battery for charging.

3. OPERATING INSTRUCTIONS

Powering On/Off

Press the power button located on the handheld unit to turn the vacuum on or off.

FloorDetect Technology

The vacuum automatically detects the floor type and adjusts the brushroll speed for optimized cleaning performance on both carpets and hard floors. No manual adjustments are required when transitioning between surfaces.



Floor Detect™ technology

Detects floor types and auto-adjusts brushroll speed for optimized cleaning.

Image: An overhead view of the vacuum head on a floor, with an overlay illustrating the FloorDetect technology sensing the surface and adjusting brushroll speed.

Dirt-Reveal Technology and LED Headlights

Integrated LED headlights illuminate hidden dust and debris on your floors, ensuring no spot is missed during cleaning. This feature works in conjunction with Dirt-Reveal Technology to make invisible dirt visible.



Dirt-Reveal Technology

Illuminates invisible dirt and dust to ensure no spot is missed.

Image: The vacuum head with its LED light shining on a dark floor, revealing illuminated dust particles.



LED headlights

Illuminate dark areas so you never miss a spot.

Image: A close-up of the vacuum head's LED headlights illuminating debris on a dark surface.

MultiFLEX Technology

The flexible wand allows you to bend the vacuum to easily clean under furniture without needing to move it. It also folds over for compact storage.



Easily reach under furniture

MultiFLEX® technology allows you to bend the wand to clean under furniture or fold it over for compact storage.

Image: A person using the vacuum with the wand bent to clean underneath a table, demonstrating the MultiFLEX feature.

Handheld Vacuum Conversion

The main unit easily detaches from the wand to convert into a handheld vacuum, ideal for cleaning countertops, furniture, and hard-to-reach areas.



Removable handheld with attachable accessories

Clean counters, stairs, and hard-to-reach spots with hand vac accessories.

Image: A split image showing the vacuum in full stick mode reaching high, and then converted to a handheld unit cleaning a sofa with pet hair.

Multi-Surface Cleaning

The PowerFins multi-surface nozzle is designed to engage floors with continuous contact, providing deep cleaning on both carpets and hard floors without the need to switch nozzles.



Multi-surface cleaning

Go from hard floor to carpet and back—without swapping nozzles.

Image: The vacuum head cleaning a rug that transitions onto a hard floor, demonstrating its multi-surface capability.

Pet Hair Pickup

The vacuum is engineered for powerful pet hair pickup, effectively removing pet hair from various surfaces.




Image: A person vacuuming a carpet with the Shark PowerPro Flex Reveal Plus, showing a pile of pet hair being collected.

4. MAINTENANCE

Emptying the Dust Cup

The CleanTouch Dirt Ejector allows for effortless emptying of debris without direct contact with dirt.

1. Ensure the vacuum is turned off.
2. Position the dust cup over a trash receptacle.
3. Press the dust cup release button to open the bottom flap and empty contents.
4. Close the flap securely after emptying.




CleanTouch™ Dirt Ejector

Effortlessly empty debris without getting your hands dirty.

Image: A hand holding the handheld vacuum over a trash can, demonstrating the CleanTouch Dirt Ejector releasing debris.

Cleaning the Brushroll

The self-cleaning PowerFins brushroll is designed to prevent hair wrap. Periodically inspect the brushroll for any trapped debris and remove as necessary.



PowerFins[®] brushroll

Engages floors with continuous contact to deep clean multiple surfaces.

Image: A comparison showing a traditional bristled brushroll with tangled hair versus the PowerFins brushroll, highlighting its self-cleaning design.

HEPA Filtration System

The Anti-Allergen Complete Seal with True HEPA Filtration captures and traps over 99.97% of dust and allergens (based on ASTM F1977 of particles 0.3 microns and larger). Regularly clean or replace the HEPA filter according to the instructions provided in the full user manual to maintain optimal performance.



Image: A diagram illustrating the vacuum's HEPA filtration system, showing how it traps dust, allergens, and other particles.

5. TROUBLESHOOTING

If you encounter issues with your Shark PowerPro Flex Reveal Plus, refer to the following common solutions:

- **Reduced Suction:** Check if the dust cup is full and needs emptying. Inspect the nozzle, wand, and hose for any blockages. Ensure all connections are secure.
- **Vacuum Not Turning On:** Ensure the battery is fully charged and correctly inserted. Check if the power button is pressed firmly.
- **Brushroll Not Spinning:** Verify that the vacuum is in the correct mode for the floor type. Check the brushroll for any obstructions or hair wrap.
- **Battery Not Charging:** Ensure the charger is properly connected to both the battery and a working power outlet.

For more detailed troubleshooting, consult the comprehensive user manual or contact customer support.

6. SPECIFICATIONS

Feature	Detail
Brand	Shark
Model Name	PowerPro Flex Reveal Cordless Vacuum
Item Model Number	IZ382H
Special Features	Cordless, HEPA, Lightweight, Portable, Rechargeable
Filter Type	HEPA Filter
Included Components	8-inch Duster Crevice Tool, Upholstery Tool
Capacity	0.79 Quarts
Wattage	181 watts
Form Factor	Stick
Product Dimensions	13.5"L x 10.4"W x 44.68"H
Item Weight	7.4 pounds
Battery Life	Up to 50 minutes (handvac in standard mode)
UPC	622356665193

7. WARRANTY INFORMATION

Warranty details for the Shark PowerPro Flex Reveal Plus Cordless Vacuum are typically included with your purchase documentation. Please refer to the warranty card or the official Shark website for specific terms, conditions, and registration information.

8. CUSTOMER SUPPORT

For further assistance, product registration, or to purchase replacement parts and accessories, please visit the official Shark website or contact their customer service department. Contact information can usually be found on the product packaging or the manufacturer's website.