

- Manuals.plus /
- > Nike /
 - > Nike Big Kids' Air Force 1 High Top (GS) 'Electric' (FD1019-100) - User Manual

Nike FD1019-100

Nike Big Kids' Air Force 1 High Top (GS) 'Electric' (FD1019-100) - User Manual

Comprehensive guide for the care and use of your Nike Air Force 1 High Top sneakers.

PRODUCT OVERVIEW

The Nike Big Kids' Air Force 1 High Top (GS) 'Electric' (FD1019-100) is a youth-sized basketball-inspired sneaker designed for everyday wear. It features a durable construction with iconic design elements, providing comfort and style for active children. This manual provides essential information for setup, usage, maintenance, and troubleshooting to ensure the longevity and optimal performance of your sneakers.



Figure 1: Side view of the Nike Air Force 1 High Top 'Electric' sneaker, showcasing its classic silhouette and color scheme.

SETUP AND INITIAL USE

Upon receiving your Nike Air Force 1 High Top sneakers, follow these steps for initial setup and optimal fit:

1. **Unboxing:** Carefully remove the sneakers from their packaging. Inspect them for any visible defects or damage.
2. **Size Verification:** Confirm that the size indicated on the shoe tongue or box matches your child's foot size. Refer to the Nike size guide if unsure.
3. **Lacing:** Ensure the laces are properly threaded through all eyelets. Adjust the lacing tension to provide a snug yet comfortable fit across the foot.
4. **Ankle Strap Adjustment:** The high-top design includes an adjustable ankle strap. Secure this strap to provide additional ankle support. It should be firm but not overly tight to allow for natural movement.
5. **First Wear:** Encourage your child to wear the sneakers for short periods initially to allow them to break in and conform to their feet.



Figure 2: Detail of the adjustable ankle strap and tongue, highlighting the secure fit mechanism.

OPERATING (USAGE) GUIDELINES

These Nike Air Force 1 High Top sneakers are designed for versatile use, offering comfort and durability for various

activities:

- **Everyday Wear:** Ideal for daily activities, school, and casual outings due to their comfortable fit and durable construction.
- **Light Athletic Use:** Suitable for light athletic activities such as walking, playground use, and non-intensive sports. While inspired by basketball, they are primarily designed for general wear.
- **Cushioning:** The integrated Air-Sole unit provides lightweight cushioning, enhancing comfort during prolonged wear and impact.
- **Traction:** The rubber outsole with a pivot point offers reliable traction on various surfaces. Exercise caution on wet or slippery surfaces.



Figure 3: The durable rubber outsole with its pivot point design, engineered for reliable traction.

MAINTENANCE AND CARE

Proper care will extend the life and maintain the appearance of your Nike Air Force 1 High Top sneakers:

- **Cleaning the Upper:** For the leather upper, wipe with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners. For stubborn marks, a soft brush can be used gently.

- **Cleaning the Sole:** Use a brush or old toothbrush with soap and water to clean the rubber outsole and midsole. Rinse thoroughly.
- **Drying:** Air dry the sneakers at room temperature. Do not use direct heat sources like radiators or hair dryers, as this can damage the materials. Stuffing with paper towels can help absorb moisture and maintain shape.
- **Storage:** Store sneakers in a cool, dry place away from direct sunlight. Keeping them in their original box or a shoe bag can help protect them from dust and damage.
- **Avoid Machine Washing:** Do not machine wash or tumble dry these sneakers, as it can damage the materials and construction.



Figure 4: Detail of the perforated toe box, which requires gentle cleaning to maintain its integrity.

TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- **Issue:** The shoes feel too tight or loose.
Solution: Adjust the lacing tension. Ensure the ankle strap is not too tight or too loose. If the issue persists, verify

the shoe size against your child's foot measurements.

- Issue:** Squeaking sound from the sole.
Solution: New rubber soles can sometimes squeak on smooth surfaces. This often resolves with wear as the sole breaks in. Ensure the shoes are dry, as moisture can also cause squeaking.
- Issue:** Minor scuffs or marks on the leather.
Solution: For light scuffs, a soft eraser or a specialized leather cleaner can often remove them. Follow product-specific instructions for leather care.
- Issue:** Odor inside the shoe.
Solution: Allow the shoes to air out after each use. Consider using shoe deodorizers or baking soda sprinkled inside (remove before wearing) to absorb odors. Ensure socks are worn to absorb sweat.

SPECIFICATIONS

Attribute	Detail
Product Name	Nike Big Kids' Air Force 1 High Top (GS) 'Electric'
Model Number	FD1019-100
Brand	Nike
Product Dimensions	12 x 8 x 5 inches; 2 Pounds (approximate, varies by size)
Sole Material	Rubber
Outer Material	Rubber (likely referring to the outsole, while the upper is leather)
Closure Type	Lace-Up with adjustable ankle strap
Water Resistance Level	Not Water Resistant
Department	unisex-child
First Available	March 25, 2025

WARRANTY AND SUPPORT

For information regarding product warranty, returns, or specific support inquiries, please refer to the official Nike website or contact Nike customer service directly. Keep your proof of purchase for any warranty claims.

Online Support: Visit the official Nike support page for FAQs and contact options.www.nike.com/help

Customer Service: Contact details for customer service can typically be found on the Nike website or product packaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F2GWR5CN>

More documents and user manuals: <https://manuals.plus/>