

[Manuals.plus](#) /

> [bakb](#) /

> Wireless Earbuds User Manual

bakb T09

Wireless Earbuds User Manual

Model: T09 | Brand: bakb

INTRODUCTION

Thank you for choosing the bakb Wireless Earbuds. This manual provides essential information for setting up, operating, and maintaining your new earbuds. Please read it thoroughly before use to ensure optimal performance and longevity.



Image: The bakb Wireless Earbuds in their open charging case, displaying the LED battery indicator.

PACKAGE CONTENTS

- Wireless Earbuds (Left & Right)
- Charging Case

- USB-C Charge Cable
- User Manual

SETUP

1. Initial Charging

Before first use, fully charge the earbuds and the charging case. Connect the provided USB-C cable to the charging port on the case and a power source. The LED display on the case will show the battery percentage. A full charge takes approximately 1.5 hours.

Stay charged. Stay connected. 48-Hour Playtime*



10min Charge
=1H MUSIC



8H Single Use



1.5H to Full Charge



Duration data is taken from Our lab, the actual experience may beslightly different by the test environment, device volume, audiofiles, etc., please refer to the actual product experience shall prevail.

Image: Visual representation of the earbuds and charging case, highlighting the 48-hour total playtime and charging indicators.

Dual LED Digital Display



Image: Close-up of the charging case displaying dual LED indicators for case power and individual earbud power levels.

2. Bluetooth Pairing

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode, indicated by a flashing light on the earbuds.
3. On your device (smartphone, tablet, etc.), enable Bluetooth.
4. Search for "T09" in the list of available Bluetooth devices and select it to connect.
5. Once connected, the earbud indicator lights will turn off or show a steady light, and you will hear a confirmation

tone.

The earbuds will automatically reconnect to the last paired device when taken out of the case, provided Bluetooth is enabled on the device.

Bluetooth 5.4: Sound and Screen in Sync.

Latency reduced to 0.06s



Image: A woman wearing the earbuds, with text indicating Bluetooth 5.4 for sound and screen synchronization.

OPERATING INSTRUCTIONS

Touch Controls

The bakb Wireless Earbuds feature intuitive touch controls on each earbud. The following table outlines the functions:

Smart Touch, Do Anything

Tri-Tap L or R

Hi Siri, Call Emma

				<h2>Music Mode</h2> <p>Light Click of Your Fingertips to Play Music or Answer Calls</p>
Volume + <small>(Long Press R)</small>	Volume - <small>(Long Press L)</small>	Play & Pause <small>(One Tap)</small>	Previous <small>(Double-Tap L)</small>	
Next <small>(Double-Tap R)</small>	voice assistant <small>(Tri-Tap L or R)</small>	Answer & Hung up <small>(Double-Tap L or R)</small>	Decline <small>(Long Press 2S L or R)</small>	

Image: A diagram illustrating various touch control gestures for music playback, volume, and call management.

Action	Function
Single Tap (L or R)	Play/Pause Music, Answer/End Call
Double Tap (Right Earbud)	Next Track

Action	Function
Double Tap (Left Earbud)	Previous Track
Long Press (Right Earbud)	Volume Up
Long Press (Left Earbud)	Volume Down
Triple Tap (L or R)	Activate Voice Assistant (Siri, Google Assistant, etc.)
Long Press 2S (L or R) during call	Decline Call

Wearing the Earbuds

Gently insert each earbud into your ear canal. Rotate slightly to find a comfortable and secure fit. A proper fit ensures optimal sound quality and noise isolation.

Studio-Quality Sound

Music Sounds This Alive



Image: An exploded view of an earbud illustrating its internal components and sound projection for studio-quality audio.

MAINTENANCE

Cleaning

Regularly clean your earbuds and charging case to maintain hygiene and performance. Use a soft, dry, lint-free cloth. Do not use abrasive cleaners or submerge the devices in liquid.

Storage

When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.

Water Resistance (IPX7)

The earbuds are IPX7 water-resistant, meaning they can withstand splashes, sweat, and rain. They are not designed for swimming or prolonged submersion. Ensure the earbuds are dry before placing them back into the charging case to prevent damage.



Image: The earbuds shown with water droplets, emphasizing their IPX7 water-resistant rating.

TROUBLESHOOTING

- **Earbuds not pairing:** Ensure both earbuds are in the charging case, then open the lid to activate pairing mode. Check that Bluetooth is enabled on your device and try searching again. If issues persist, try forgetting the device on your phone and re-pairing.
- **Only one earbud working:** Place both earbuds back into the charging case, close the lid, wait a few seconds, then open it again. This often resets the connection between the two earbuds.
- **No sound:** Check the volume level on both your device and the earbuds. Ensure the earbuds are properly connected to your device.
- **Charging issues:** Ensure the charging cable is securely connected to both the case and the power source. Check for any debris in the charging port.
- **Poor sound quality:** Ensure the earbuds are clean and properly seated in your ears. Move closer to your connected device to avoid interference.

SPECIFICATIONS

Feature	Detail
Model Name	T09
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.4
Bluetooth Range	Up to 33 Feet
Battery Life (Earbuds)	9 Hours (single charge)
Total Playtime (with case)	Up to 48 Hours
Charging Time	Approx. 1.5 hours (full charge)
Water Resistance Level	IPX7 (Waterproof)
Control Method	Touch
Frequency Range	20Hz - 20,000Hz
Earpiece Shape	In Ear
Material	Plastic
Item Weight	3.2 ounces

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the contact details provided on the product packaging or the official bakb website. Keep your purchase receipt as proof of purchase.

