



Manuals.plus /

- › UNITSTAGE /
- › UNITSTAGE 5-Tier Shoe Rack with Drawers Instruction Manual

## UNITSTAGE B0F2H85QTK

# UNITSTAGE 5-Tier Shoe Rack with Drawers

## INSTRUCTION MANUAL

### Introduction

---

Thank you for choosing the UNITSTAGE 5-Tier Shoe Rack with Drawers. This manual provides essential information for the safe assembly, proper use, and maintenance of your new shoe storage solution. Please read these instructions carefully before beginning assembly and retain them for future reference.



This image displays the UNITSTAGE 5-Tier Shoe Rack, featuring a black metal frame, five wire mesh shelves for shoes, and two black non-woven fabric drawers with round knobs on top. The top surface is a dark wood-grain finish.

### Important Safety Information

- Always follow the assembly instructions carefully.
- Do not exceed the weight capacity of the shelves or drawers. Each metal mesh shelf supports up to 22 lb (10 kg), and the wooden top supports up to 33 lb (15 kg).
- Ensure all connections are securely tightened before use.
- Use the provided anti-tip device to secure the shoe rack to a wall, especially in households with children

or pets, to prevent accidental tipping.

- Keep small parts away from children during assembly.
- Avoid placing hot items directly on the wooden top surface.

## Parts List

---

Please verify that all components are present before beginning assembly. Refer to the included detailed illustrated manual for specific part identification and numbering.

- Metal Frame Components (vertical supports, cross bars)
- 5 x Metal Mesh Shelves
- 1 x Wooden Top Panel
- 2 x Non-Woven Fabric Drawers
- 2 x Drawer Knobs
- Adjustable Feet
- Anti-Tip Device (strap, screws)
- Assembly Hardware (screws, Allen wrench)

## Setup and Assembly

---

Assembly is designed to be straightforward. All necessary tools and numbered accessories are included. It is recommended to assemble the unit on a soft, clean surface to prevent scratches.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out. Compare them with the parts list in your detailed manual to ensure everything is present.
2. **Assemble Frame:** Connect the vertical metal frame components using the provided screws and Allen wrench. Ensure the cross bars are correctly oriented for stability.
3. **Install Shelves:** Slide the metal mesh shelves into the designated slots on the frame. Ensure they are level and securely seated.
4. **Attach Top Panel:** Place the wooden top panel onto the uppermost frame section and secure it with the appropriate screws.
5. **Insert Drawers:** Assemble the non-woven fabric drawers by inserting the bottom panel and attaching the knobs. Slide the completed drawers into their designated compartments under the top panel.
6. **Adjust Feet:** Screw in the adjustable feet at the bottom of the frame. Adjust them as needed to ensure the shoe rack is stable and level on uneven surfaces.
7. **Install Anti-Tip Device:** For enhanced safety, attach the anti-tip device to the top rear of the shoe rack and secure it to a wall stud using appropriate hardware.



## Easy to Assemble



Anti-tilting Device



Adjustable Feet



2 Fabric Drawers

This image collage illustrates key features: an anti-tilting device for stability, adjustable feet for leveling on uneven surfaces, and the two fabric drawers, shown filled with folded clothing items, demonstrating their storage capacity.

### Operating Instructions

The UNITSTAGE 5-Tier Shoe Rack is designed for versatile shoe storage and organization.

- **Shoe Storage:** Each metal mesh shelf can comfortably hold 3-4 pairs of standard adult shoes, accommodating a total of 16-20 pairs across the five tiers.
- **Adjustable Shelf Height:** If you need to store taller items like boots, one or more shelves can be removed to create additional vertical space.
- **Drawer Usage:** The two non-woven fabric drawers on top are ideal for storing smaller items such as socks, gloves, keys, sunglasses, or other entryway essentials.
- **Top Surface:** The wooden top panel provides a stable surface for decorative items, small plants, or frequently used personal belongings.



The shoe rack is shown in an entryway setting, organized with multiple pairs of shoes on its five tiers. The top surface holds decorative items like a vase with flowers, a candle, and a small box, demonstrating its dual functionality as a storage unit and a display surface.

# Removable Shelves

Creating space for high boots.



This image demonstrates the versatility of the shoe rack, showing two configurations. On the left, a shelf has been removed to create taller space for boots, while the right shows the standard five-tier setup. Icons above indicate compatibility with various shoe types including sneakers, high-tops, heels, and boots.

# Large Capacity

Store 16-20 pairs of shoes to maximize vertical space.

 BEFORE



 AFTER



This image illustrates the 'Large Capacity' feature, showing a disorganized pile of shoes labeled 'BEFORE' next to the UNITSTAGE shoe rack neatly storing 16-20 pairs of shoes, labeled 'AFTER', demonstrating effective space utilization.

## Maintenance

- **Cleaning:** Wipe the metal frame and shelves with a soft, damp cloth. For the wooden top, use a dry or slightly damp cloth and avoid harsh chemicals. The non-woven drawers can be spot cleaned with a mild detergent and air-dried.
- **Dusting:** Regularly dust all surfaces to maintain appearance and prevent buildup.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Avoid Moisture:** Do not expose the shoe rack to excessive moisture or direct sunlight for prolonged periods, as this may damage the materials.

# Metal Shelves

Serviceable and easy to clean.

Ours



Metal Shelves

Others



Oxford Fabric Shelves

VS

A side-by-side comparison highlighting the durable metal wire shelves of the UNITSTAGE product on the left, contrasted with fabric shelves on the right, emphasizing the serviceability and ease of cleaning of the metal design.

## Troubleshooting

- **Unit is Wobbly:** Ensure all screws are tightened. Adjust the leveling feet at the bottom of the frame to stabilize the unit on uneven floors.
- **Parts Missing/Damaged:** If any parts are missing or damaged upon arrival, please contact customer support for assistance.
- **Drawers Not Sliding Smoothly:** Check that the drawer fabric is not caught on any part of the frame. Ensure the drawer bottom is fully inserted and the knob is securely attached.

## Specifications

Feature	Detail
Brand	UNITSTAGE
Model Number	B0F2H85QTK
Dimensions (L x W x H)	36.2 inches x 11.0 inches x 36.2 inches (92 cm x 28 cm x 92 cm)
Number of Tiers	5
Drawers	2 Non-Woven Fabric Drawers
Material	Steel Frame, Particleboard Top, Non-Woven Fabric Drawers
Weight Capacity (per shelf)	22 lb (10 kg)
Weight Capacity (top panel)	33 lb (15 kg)
Assembly Required	Yes



This diagram provides detailed measurements of the shoe rack, including its overall height (96cm/37.8 inches), width (70cm/27.6 inches), and depth (27.5cm/10.8 inches). It also shows the height of each shelf (18cm/7.1 inches) and the dimensions of the individual drawers (33cm/13 inches L x 27cm/10.6 inches W x 12cm/4.7 inches H).

## Warranty and Support

---

For any questions, concerns, or warranty claims regarding your UNITSTAGE 5-Tier Shoe Rack, please refer to the contact information provided with your purchase documentation or visit the official UNITSTAGE website for customer support details.