

VGRPRO V-007 V-109 V-337

VGRPRO Professional Waterproof Hair Clipper and Trimmer Set User Manual

Models: V-007, V-109, V-337

1. INTRODUCTION

Thank you for choosing the VGRPRO Professional Waterproof Hair Clipper and Trimmer Set. This comprehensive grooming kit is designed for precision hair cutting, beard trimming, and shaving, offering versatility and convenience. Please read this manual carefully before using the product to ensure safe and optimal performance. Keep this manual for future reference.

2. SAFETY INFORMATION

To reduce the risk of electric shock, injury, or fire, always follow these basic safety precautions:

- This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Do not immerse the appliance in water while charging.
- Always check the appliance for damage before use. Do not use if the blades are damaged or broken.
- Use only the charger supplied with the appliance.
- Keep the appliance away from heated surfaces.
- Do not open the appliance casing. Repairs should only be performed by authorized service personnel.

3. PRODUCT OVERVIEW

The VGRPRO grooming kit includes a hair clipper, a precision trimmer, and a foil shaver, along with various accessories for a complete grooming experience.



Figure 1: Overview of the VGRPRO Professional Hair Clipper, Precision Trimmer, Foil Shaver, and included accessories.

Components Included:

- Hair Clipper (V-007)
- Precision Trimmer (V-109)
- Foil Shaver (V-337)
- 15 Guide Combs (various sizes)
- Blade Oil
- Cleaning Brush
- Barber Cape
- USB Charging Cable
- Storage Case

4. SETUP

4.1 Initial Charging

Before first use, fully charge each device. The LED display will indicate battery status.

1. Connect the USB charging cable to the charging port on the device.
2. Plug the other end of the USB cable into a compatible USB power adapter (not included) or a computer USB port.
3. Allow approximately 4 hours for a full charge. The battery display will show charging progress and full charge status.



Figure 2: Illustration of the VGRPRO devices being charged via USB, highlighting the LED battery indicator.

4.2 Attaching Guide Combs

To attach a guide comb, align the comb with the blade and push it firmly until it clicks into place. To remove, gently pull the comb away from the blade.

5. OPERATING INSTRUCTIONS

5.1 Hair Clipper (V-007)

The hair clipper is ideal for general hair cutting and fading.

- **Power On/Off:** Press the power button to turn the clipper on or off.
- **Speed Settings:** The clipper features 4-speed settings. Press the speed adjustment button to cycle through the available speeds.
- **Adjustable Fade Lever:** Use the side lever to adjust the cutting length from 0.5mm to 1.5mm without a guide comb. This is useful for blending and fading.
- **Guide Combs:** Select the appropriate guide comb for your desired hair length. Attach it securely before use.

Cutting Hair Smooth and Evenly

Won't Pulled Hair




Figure 3: The hair clipper's adjustable fade lever and various guide comb lengths for precise cutting.

5.2 Precision Trimmer (V-109)

The precision trimmer is suitable for detailing, beard shaping, sideburns, necklines, and nose/ear hair removal.

- **Power On/Off:** Press the power button.
- **Beard Trimming:** Use without a comb for close trimming or with a small guide comb for desired beard length.
- **Outline Trimming:** The narrow blade is ideal for creating sharp lines and edges for sideburns and necklines.
- **Nose/Ear Hair:** Attach the specialized nose/ear hair trimmer head for safe and comfortable removal of

unwanted hair.



Figure 4: The precision trimmer's various applications, including beard, sideburns, head, and nose/ear grooming.

5.3 Foil Shaver (V-337)


The foil shaver provides a close, smooth shave for facial hair.

- **Power On/Off:** Press the power button.
- **Shaving Technique:** Hold the shaver at a right angle to your skin and move it against the direction of hair growth.
- **Features:** Equipped with a powerful 7500 RPM motor, VGRpro sharp blades, and a precision-engineered hexagonal mesh for a clean shave without irritation.


Clean and No Skin Irritation



7500 RPM
Powerful Motor



VGRpro
Sharp Blades



Precision-engineered
Hexagonal Mesh



Figure 5: Close-up of the foil shaver, detailing its internal components for efficient and comfortable shaving.

6. MAINTENANCE

Regular cleaning and maintenance will prolong the life and performance of your VGRPRO grooming kit.

6.1 Cleaning

1. Turn off and unplug the device before cleaning.
2. Remove any attached guide combs.
3. Use the provided cleaning brush to remove hair clippings from the blades and inside the device head.

4. Since the devices are waterproof, the blades can be rinsed under running water. Ensure the device is completely dry before storage or next use.
5. For the foil shaver, carefully remove the foil head and brush out any trapped hair. Rinse the foil head under water if necessary.

6.2 Oiling Blades

After every few uses, or if the blades feel sluggish, apply a small drop of the included blade oil to the teeth of the blades. Turn on the device for a few seconds to distribute the oil evenly. Wipe off any excess oil.

6.3 Storage

Store the devices and all accessories in the provided storage case in a cool, dry place, away from direct sunlight and moisture.

Storage Case

Family Trim Series



Figure 6: The VGRPRO storage case, designed to keep all components organized and protected.

7. TROUBLESHOOTING

If you encounter any issues with your VGRPRO grooming kit, refer to the following common problems and solutions:

- **Device not turning on:** Ensure the device is fully charged. If the battery is low, connect it to the charger.
- **Blades pulling hair:** The blades may be dull or clogged with hair. Clean the blades thoroughly and apply blade oil. If the issue persists, consider replacing the blade head (if available).
- **Reduced cutting performance:** This could be due to low battery, dirty blades, or insufficient oiling.

Charge the device, clean the blades, and apply oil.

- **Device overheating:** Discontinue use immediately. Allow the device to cool down. Ensure proper ventilation during use and charging.

If the problem persists after attempting these solutions, please contact VGRPRO customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	VGRPRO
Model Numbers	V-007, V-109, V-337
Power Source	Battery Powered
Blade Material	Metal
Battery Type	Lithium Ion (1 AAA battery included)
Charging Time	4 Hours
Running Time	Up to 4 Hours
Product Dimensions	17.3 x 5.7 x 4.5 cm
Product Weight	1.4 kg
Manufacturer	NINGBO VGR ELECTRIC APPLIANCE CO.,LTD.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or visit the official VGRPRO store on Amazon:

[Visit the VGRPRO Store](#)

Please note that product packaging may contain information that differs from what is shown on our website. Always read the label, warnings, and instructions provided on the product before using or consuming it.