

[Manuals.plus](#) /

› [Timberland](#) /

› Timberland TDWGF2182901 Quartz Analog Watch User Manual

Timberland TDWGF2182901

Timberland TDWGF2182901 Quartz Analog Watch User Manual

Model: TDWGF2182901

INTRODUCTION

Thank you for choosing the Timberland TDWGF2182901 Quartz Analog Watch. This manual provides essential information for the proper setup, operation, and maintenance of your watch. Please read it carefully to ensure optimal performance and longevity of your timepiece.

SAFETY INFORMATION

For detailed safety guidelines, please refer to the official safety information PDF document available for this product. Always handle the watch with care to prevent damage.

Link to Safety Information: [Safety Information \(PDF\)](#)

PACKAGE CONTENTS

Ensure all items are present in the package:

- Timberland TDWGF2182901 Quartz Analog Watch
- Branded Watch Box
- Warranty Information

PRODUCT OVERVIEW

The Timberland TDWGF2182901 features a 43mm stainless steel case, a charcoal Sunray dial with 3 hands, and a brown leather strap. It is powered by a quartz movement and includes a chronograph function.



Image: Front view of the Timberland TDWGF2182901 Quartz Analog Watch. The watch features a round charcoal dial with three hands, a stainless steel case, and a brown leather strap with a buckle closure.

SETUP

Setting the Time

1. Pull the crown (the small knob on the side of the watch case) out to the first or second position (depending on the model, usually the second position for time setting).
2. Turn the crown clockwise or counter-clockwise to adjust the hour and minute hands to the correct time.
3. Once the time is set, push the crown back into its normal position against the watch case.

Wearing the Watch

Adjust the leather strap to fit comfortably around your wrist. The buckle closure ensures a secure fit for daily use.

OPERATING

Basic Timekeeping

Your watch is an analog quartz timepiece, designed for accurate timekeeping. The three hands display hours, minutes, and seconds.

Chronograph Function

The chronograph function allows for measuring elapsed time. Specific instructions for operating the chronograph (start, stop, reset) will depend on the exact movement. Typically, there are two pushers on either side of the crown:

- **Start/Stop:** Press the top pusher to start and stop the chronograph.
- **Reset:** Press the bottom pusher to reset the chronograph hands to zero when the chronograph is stopped.

Refer to the specific movement's detailed instructions if available, or consult a qualified watch technician for advanced operation.

MAINTENANCE

Cleaning

Wipe the watch case and crystal with a soft, dry cloth. For the leather strap, avoid excessive moisture and harsh chemicals. Clean gently with a damp cloth if necessary and allow to air dry.

Battery Replacement

The watch is powered by a standard non-standard battery. When the watch stops or the second hand starts skipping, it indicates a low battery. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and function.

Water Resistance

This watch has a water resistance rating of 30 meters (3 ATM). This means it is resistant to splashes and brief immersion in water, but it is **not** suitable for swimming, showering, or diving. Avoid operating the crown or pushers when the watch is wet.

TROUBLESHOOTING

- **Watch not running:** Check if the crown is pushed in completely. If it is, the battery may need replacement.
- **Incorrect time:** Reset the time as described in the "Setting the Time" section.
- **Condensation under crystal:** This may indicate a breach in water resistance. Avoid further contact with water and have the watch inspected by a technician.

For issues not listed here, please contact customer support or a certified watch repair center.

SPECIFICATIONS

Feature	Detail
Model Number	TDWGF2182901
Brand	Timberland

Feature	Detail
Display Type	Analog
Movement Type	Quartz
Special Features	Chronograph
Power Source	Battery (1 non-standard battery included)
Case Material	Metal
Case Diameter	43 Millimeters
Case Thickness	9 Millimeters
Dial Color	Charcoal (grigio)
Dial Style	Sunray
Crystal Material	Glass (Vetro)
Strap Material	Leather
Strap Color	Brown (Marrone)
Strap Width	20 Millimeters
Strap Length	250 Millimeters
Clasp Type	Buckle (Fibbia)
Water Resistance Rating	30 Meters (Resistant to water)
Item Weight	70 Grams
Package Dimensions	9.5 x 8 x 7 cm

WARRANTY AND SUPPORT

Your Timberland TDWGF2182901 watch comes with a **2-year limited warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage resulting from accidents, improper use, unauthorized repairs, or normal wear and tear.

For warranty claims or technical support, please contact your retailer or the official Timberland customer service. Keep your proof of purchase for warranty validation.

For more information, visit the [Timberland Store](#).