

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [JBL](#) /

› [JBL PartyBox Ultimate 1100W Portable Speaker User Manual](#)

## JBL JBLPARTYBOXULTAM

# JBL PartyBox Ultimate 1100W Portable Speaker User Manual

Model: JBLPARTYBOXULTAM

## INTRODUCTION

The JBL PartyBox Ultimate is a powerful portable speaker designed to deliver an immersive audio experience with its 1100W output. It features dual 9-inch woofers, 4.5-inch midrange drivers, and 2.75-inch tweeters for balanced sound. Connectivity options include dual-band Wi-Fi and Bluetooth for seamless streaming. The speaker also incorporates a multi-colored light show that syncs with music, dual microphone inputs, and a guitar jack for live performances and karaoke. This bundle includes the JBL PartyLight Beam, a Bluetooth projection party light, and a microfiber cleaning cloth.

## WHAT'S IN THE BOX



This image displays the JBL PartyBox Ultimate portable speaker, featuring its distinctive light rings. Alongside it is the JBL PartyLight Beam, a compact projection light. A power cord and a microfiber cleaning cloth are also included, representing the complete bundle.

- 1 x JBL PartyBox Ultimate 1100W Portable Speaker
- 1 x JBL PartyLight Beam
- 1 x MicroFiber Cleaning Cloth
- 1 x Ring-Angle Power Cord (6.6 feet)

## SETUP

### 1. Power Connection

Connect the provided power cord to the speaker's power input and then to a suitable AC power outlet. The speaker will automatically enter standby mode or power on.

### 2. Initial Placement

Place the speaker on a stable, flat surface. For optimal sound and light show projection, consider placing it in a central location within the desired listening area. The speaker is designed for floor standing use.

### 3. JBL One App Setup

For advanced control and customization, download the JBL One app from your device's app store. Follow the in-app instructions to connect your PartyBox Ultimate to your Wi-Fi network and access features like light show customization, EQ settings, and firmware updates.

### 4. Connecting the PartyLight Beam

The JBL PartyLight Beam connects via Bluetooth. Power on the PartyLight Beam and ensure it is in pairing mode. On your PartyBox Ultimate or via the JBL One app, initiate Bluetooth pairing to connect the light beam. It will sync with the speaker's audio and light show.

## OPERATING INSTRUCTIONS

### 1. Power On/Off

Press the **Power** button located on the top panel to turn the speaker on or off.

### 2. Bluetooth Connectivity

To pair a new Bluetooth device, press the **Bluetooth** button on the speaker. The speaker will enter pairing mode. Select 'JBL PartyBox Ultimate' from your device's Bluetooth list.

### 3. Wi-Fi Streaming

Once connected to Wi-Fi via the JBL One app, you can stream audio using services like Apple AirPlay, Alexa Multi-Room Music, or Google Home. Ensure your streaming device is on the same Wi-Fi network as the speaker.

### 4. Light Show Control

Use the dedicated **Light Show** button on the speaker or the JBL One app to cycle through different light patterns and colors. The lights will synchronize with the music beat.

### 5. Microphone and Guitar Inputs

Connect microphones or a guitar to the respective input jacks on the rear panel. Adjust input levels using the dedicated knobs. The speaker supports karaoke EQ for enhanced vocal performance.

## 6. PartyPad Functionality

The PartyPad on the top panel allows for interactive sound effects and light show control. Tap or slide your fingers across the pad to activate various effects.

## 7. True Wireless Stereo (TWS) Pairing

For an amplified sound experience, two JBL PartyBox Ultimate speakers can be paired wirelessly using the TWS function. Refer to the JBL One app for detailed instructions on TWS pairing.

## MAINTENANCE

### 1. Cleaning

Regularly clean the speaker's exterior using the provided microfiber cleaning cloth. For stubborn marks, lightly dampen the cloth with water. Do not use abrasive cleaners or solvents.

### 2. Storage

When not in use for extended periods, store the speaker in a cool, dry place, away from direct sunlight and extreme temperatures. Ensure the speaker is powered off and unplugged.

### 3. Splashproof Rating (IPX4)

The JBL PartyBox Ultimate has an IPX4 splash-proof rating, meaning it is resistant to splashing water from any direction. It is not designed to be submerged in water or exposed to high-pressure water jets. Ensure all port covers are securely closed before exposure to moisture.

## TROUBLESHOOTING

- **No Power:** Ensure the power cord is securely connected to both the speaker and a working power outlet. Try a different outlet.
- **No Sound:** Check the volume level on both the speaker and your connected device. Ensure the correct input source is selected. For Bluetooth, re-pair the device. For Wi-Fi, check network connectivity.
- **Bluetooth Disconnection:** Ensure your device is within the speaker's Bluetooth range (typically 10 meters/33 feet). Avoid obstacles that may interfere with the signal. Try forgetting the device on your phone and re-pairing.
- **Light Show Not Working:** Verify that the light show feature is enabled via the speaker controls or the JBL One app. Check for any error messages in the app.
- **Wi-Fi Connectivity Issues:** Ensure your Wi-Fi network is active and the speaker is within range of your router. Restart your router and the speaker. Use the JBL One app to reconfigure Wi-Fi settings.

## SPECIFICATIONS

Model Name	JBLPARTYBOXULTAM
UPC	094148709338

<b>Manufacturer</b>	JBL
<b>Product Dimensions</b>	17.3 x 17.9 x 41.3 inches
<b>Item Weight</b>	87.1 pounds
<b>Power Output</b>	1100W
<b>Drivers</b>	Dual 9" woofers, 4.5" midrange drivers, 2.75" tweeters
<b>Connectivity</b>	Wi-Fi, Bluetooth
<b>Water Resistance</b>	IPX4 Splash-proof
<b>Mounting Type</b>	Floor Standing

## WARRANTY AND SUPPORT

JBL products are designed for reliability and performance. For information regarding warranty coverage, please refer to the warranty card included with your product or visit the official JBL support website. For technical assistance, troubleshooting, or service inquiries, please contact JBL customer support. Keep your purchase receipt as proof of purchase for warranty claims.

Online Support: [www.jbl.com/support](http://www.jbl.com/support)