

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Turtlebox](#) /

› [Turtlebox Ranger Portable Bluetooth Speaker User Manual](#)

## Turtlebox Turtlebox Ranger

# Turtlebox Ranger Portable Bluetooth Speaker User Manual

Model: Turtlebox Ranger | Brand: Turtlebox

## 1. INTRODUCTION

The Turtlebox Ranger is a rugged, waterproof, and ultra-portable Bluetooth 5.4 speaker designed for outdoor use. It delivers powerful, distortion-free sound with deep bass, capable of reaching 105dB. Built to withstand various outdoor conditions, it features shockproof construction and IP67 waterproofing. This manual provides essential information for setting up, operating, and maintaining your Turtlebox Ranger speaker.




Image: Turtlebox Ranger speaker in an outdoor environment, showcasing its robust build.

## 2. WHAT'S IN THE BOX

Ensure all items are present upon unboxing:

- Turtlebox Ranger Speaker
- Power Cable

## 3. KEY FEATURES

- **Unmatched Volume & Bass:** Delivers 105dB of powerful, distortion-free sound, optimized for outdoor environments.
- **IP67 Waterproof & Built Tough:** Fully waterproof, dustproof, and shockproof design ensures durability in challenging conditions.
- **All-Day Battery Life:** Provides up to 25 hours of playtime on a single charge.
- **Unlimited Pairing (Party Mode):** Sync multiple Ranger speakers for a premium, portable surround sound experience.
- **Designed for the Outdoors:** Features a rugged handle, built-in tie-down anchors, and a compact, easy-to-carry design.



Image: Visual representation of the Turtlebox Ranger's main features.

## 4. SETUP

---

### 4.1 Charging the Speaker

Before first use, fully charge your Turtlebox Ranger. Connect the provided Power Cable to the USB-C charging port located on the back of the speaker. The battery indicator lights will show charging progress. A full charge typically takes approximately 3 hours and provides up to 25 hours of playtime.



## TIE-DOWNS

Image: The fully waterproof charging ports of the Turtlebox Ranger.

### 4.2 Powering On/Off

Press and hold the **Power button** (usually indicated by a circle with a vertical line) on the control panel until the indicator lights illuminate. To power off, press and hold the Power button again.

### 4.3 Bluetooth Pairing

1. Ensure the speaker is powered on and the Bluetooth indicator light is blinking, indicating it's in pairing mode.
2. On your mobile device (smartphone, tablet, etc.), go to the Bluetooth settings.
3. Select "Turtlebox Ranger" from the list of available devices.
4. Once connected, the Bluetooth indicator light on the speaker will become solid.

## 5. OPERATING INSTRUCTIONS

---

### 5.1 Controls Overview

The control panel on the speaker allows for easy management of audio playback and settings.

---



Image: The control panel of the Turtlebox Ranger, showing various buttons.

- **Power Button:** Press and hold to turn the speaker on/off.
- **Volume Up (+):** Increases the volume.
- **Volume Down (-):** Decreases the volume.
- **Play/Pause:** Controls audio playback.
- **Track Skip (Forward/Backward):** Skips to the next or previous track.
- **Bluetooth Button:** Initiates Bluetooth pairing mode.

## 5.2 Audio Playback

Once paired, you can control music directly from your connected device or using the speaker's control buttons.

## 6. PARTY MODE PAIRING

For an enhanced audio experience, you can wirelessly connect multiple Turtlebox Ranger speakers using Party Mode.

1. Ensure all speakers are powered on and not connected to any Bluetooth device.

2. On the primary speaker (the one you want to control from), press the Party Mode button (often indicated by a chain link or multiple speaker icon).
3. On the secondary speakers, press their respective Party Mode buttons.
4. The speakers will automatically connect, creating a synchronized audio system.




Image: Multiple Turtlebox Ranger speakers connected wirelessly in Party Mode.

## 7. MAINTENANCE

---

### 7.1 Cleaning

Due to its IP67 rating, the Turtlebox Ranger can be easily cleaned with water. Rinse off dirt, sand, or mud. Avoid using harsh chemicals or abrasive cleaners.



Image: The Turtlebox Ranger being rinsed with water, showcasing its waterproof design.

## 7.2 Storage

Store the speaker in a cool, dry place when not in use. Avoid prolonged exposure to extreme temperatures.

## 8. TROUBLESHOOTING

---

- **No Power:** Ensure the speaker is fully charged. Connect to a power source and check the battery indicator lights.
- **No Sound:** Check the volume levels on both the speaker and your connected device. Ensure the device is properly paired via Bluetooth.
- **Bluetooth Pairing Issues:** Turn off and restart the speaker and your device's Bluetooth. Try re-pairing the devices. Ensure no other devices are actively connected to the speaker.
- **Poor Audio Quality:** Ensure the speaker is within Bluetooth range of your device. Move closer to the device or away from potential interference sources.

## 9. SPECIFICATIONS

---

<b>Model Name</b>	Turtlebox Ranger
<b>Speaker Type</b>	Outdoor
<b>Connectivity Technology</b>	Bluetooth 5.4
<b>Power Output</b>	105 decibels
<b>Battery Life</b>	Up to 25 hours
<b>Battery Capacity</b>	25.2 Wh Lithium-ion (25200 Milliamp Hours)
<b>Water Resistance Level</b>	IP67 (Waterproof & Dustproof)
<b>Product Dimensions</b>	3.15"D x 3.15"W x 8.05"H
<b>Item Weight</b>	2.4 Pounds
<b>Included Components</b>	Power Cable
<b>Mounting Type</b>	Magnetic Mount

Engineered  
for the  
outdoors

WEIGHT: 2.4 lbs.



HEIGHT: 8.05"

WIDTH: 3.15"

Image: Dimensions and weight of the Turtlebox Ranger speaker.

## 10. WARRANTY AND SUPPORT

### 10.1 Limited Warranty

The Turtlebox Ranger comes with a limited warranty. For specific terms and conditions, please refer to the warranty card included with your product or visit the official Turtlebox website.

### 10.2 Customer Support

For further assistance, technical support, or warranty claims, please contact Turtlebox customer support through their official website or the contact information provided in your product packaging.