

- Manuals.plus /
- > LALISU /
  - > LALISU Dimmable Floor Lamp with Flexible Gooseneck and Rotatable Shade - User Manual

LALISU LALISULALITTB04

LALISU Dimmable Floor Lamp User Manual

Model: LALISULALITTB04

INTRODUCTION

Thank you for choosing the LALISU Dimmable Floor Lamp. This modern standing lamp features a flexible gooseneck and a rotatable shade, designed to provide adjustable illumination for various tasks and environments. It includes an E26 socket and comes with an energy-efficient LED bulb. This manual provides essential information for safe assembly, operation, maintenance, and troubleshooting.



Image: The LALISU Dimmable Floor Lamp in gold, showcasing its sleek design and flexible gooseneck.

## SAFETY INSTRUCTIONS

---

- Ensure the lamp is unplugged before assembly, cleaning, or changing the bulb.
- Use only E26 base bulbs with a maximum wattage appropriate for the fixture. The included bulb is 9W LED.
- Do not operate the lamp with a damaged cord or plug.
- Keep the lamp away from water or damp environments.
- This lamp is designed for indoor use only.
- Ensure the base is stable and placed on a flat surface to prevent tipping.

## PACKAGE CONTENTS

---

- Floor Lamp Base

- Lamp Pole Sections (pre-wired)
- Flexible Gooseneck with Lamp Head
- 9W E26 LED Bulb (3000K Warm White)
- User Manual

## SETUP AND ASSEMBLY

---

The LALISU Dimmable Floor Lamp is designed for quick and easy assembly. All parts are pre-wired, simplifying the process.

1. Carefully unpack all components and place them on a clean, flat surface.
2. Screw the lamp pole sections together clockwise. Ensure each section is securely tightened. The electrical cord runs through the pole sections, so be careful not to twist or damage it.
3. Attach the assembled lamp pole to the heavy lamp base by screwing it clockwise until firm.
4. Screw the flexible gooseneck with the lamp head onto the top of the assembled pole.
5. Insert the provided 9W E26 LED bulb into the lamp head socket by turning it clockwise until secure.
6. Place the lamp in your desired location, ensuring the base is stable.
7. Plug the power cord into a standard 110V electrical outlet.



Image: An illustration showing the assembled LALISU Floor Lamp with key dimensions and components labeled, including the E26 bulb socket and flexible gooseneck.

## OPERATING INSTRUCTIONS

---

### Power On/Off and Dimming

The lamp features a vintage-style rotary knob switch located just below the lamp head for convenient access.

- To turn the lamp **ON**, rotate the knob clockwise from the 'Off' position.
- Continue rotating the knob clockwise to cycle through three brightness levels: **Low (20%)**, **Medium (50%)**, and **High (100%)**.
- To turn the lamp **OFF**, rotate the knob counter-clockwise until it clicks into the 'Off' position.

# Upgraded Switch

## 3 Ways Dimmable Brightness




Image: Close-up of the rotary knob switch on the LALISU Floor Lamp, illustrating the three dimmable brightness settings (20%, 50%, 100%).

### Adjusting the Gooseneck and Shade

The lamp is equipped with a 360° flexible gooseneck and a rotatable shade, allowing you to direct light precisely where needed.

- Gently bend the flexible gooseneck to adjust the height and angle of the lamp head.
- Rotate the lamp shade to further refine the direction of the light beam.



## 360° Rotation Design Flexible Gooseneck Floor Lamp

Image: A woman using the LALISU Floor Lamp, demonstrating the flexibility of the gooseneck to position the light for reading or other tasks.

### MAINTENANCE

---

#### Cleaning

- Always unplug the lamp before cleaning.
- Wipe the lamp's exterior surfaces with a soft, dry cloth.
- Do not use abrasive cleaners, solvents, or polishes as they may damage the finish.

#### Bulb Replacement

- Ensure the lamp is unplugged and the bulb has cooled completely before attempting to replace it.
- Unscrew the old E26 bulb counter-clockwise.
- Screw in a new E26 base bulb clockwise. Ensure the replacement bulb's wattage does not exceed the lamp's maximum

rating.

TROUBLESHOOTING

| Problem                         | Possible Cause                                                                      | Solution                                                                                                                                                                                                         |
|---------------------------------|-------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Lamp does not turn on.          | No power to the outlet.<br>Bulb is loose or faulty.<br>Lamp not properly assembled. | Check if the outlet is working by plugging in another device.<br>Ensure the plug is fully inserted.<br>Tighten the bulb or replace it with a new one.<br>Verify all lamp sections are securely screwed together. |
| Lamp flickers.                  | Loose bulb.<br>Incompatible bulb.<br>Faulty bulb.                                   | Tighten the bulb.<br>Ensure the bulb is an E26 LED type. Replace with a new bulb.                                                                                                                                |
| Dimming function does not work. | Bulb is not dimmable.<br>Faulty rotary switch.                                      | Ensure you are using a dimmable E26 LED bulb. The included bulb is dimmable.<br>If using the included bulb and dimming still fails, contact customer support.                                                    |

SPECIFICATIONS

| Feature              | Detail                       |
|----------------------|------------------------------|
| Model Number         | LALISULALITTB04              |
| Dimensions (Overall) | 64.5" H (approx.)            |
| Base Dimensions      | 8.5" Diameter x 1" H         |
| Product Weight       | 2.25 Pounds                  |
| Material             | Metal                        |
| Finish Type          | Polished                     |
| Color                | Gold                         |
| Bulb Base            | E26                          |
| Included Bulb        | 9W LED (3000K Warm White)    |
| Wattage              | 9 Watts (LED)                |
| Voltage              | 110 Volts                    |
| Switch Type          | Rotary Knob                  |
| Special Feature      | Dimmable, Flexible Gooseneck |
| Certifications       | ETL Listed                   |

## WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product or contact LALISU directly through their official website or the retailer where the product was purchased. Please have your model number (LALISULALITTB04) and purchase date available when contacting support.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

#### Name

#### Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

#### Question

#### Details

Submit question

Open the live page

<https://manuals.plus/asin/B0F2JJ3PC8>

More documents and user manuals: <https://manuals.plus/>