

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Lindby](#) /

› [Lindby Vatana Wall Lamp with USB Charging Station \(4-Bulb, E27\) Instruction Manual](#)

Lindby 10030171

Lindby Vatana Wall Lamp with USB Charging Station

Model: 10030171

INTRODUCTION

This manual provides essential instructions for the safe installation, operation, and maintenance of your Lindby Vatana Wall Lamp. Please read this manual thoroughly before installation and retain it for future reference. This wall lamp features a rustic wooden design, four E27 bulb sockets, and an integrated USB charging port for added convenience.

SAFETY INSTRUCTIONS

- **Electrical Safety:** Installation must be performed by a qualified electrician or in accordance with local electrical codes. Ensure the main power supply is disconnected before installation, maintenance, or bulb replacement.
- **Voltage:** This lamp operates on 230 Volts. Verify your electrical supply matches this requirement.
- **Bulb Type:** Use only E27 bulbs. Do not exceed a maximum wattage of 15W per bulb. LED bulbs are recommended for energy efficiency.
- **Indoor Use Only:** This product is designed for indoor use (IP20 protection class). Do not expose to moisture or direct water.
- **Mounting:** Ensure the wall surface is strong enough to support the lamp's weight (approximately 3.4 kg) and any additional items placed on the shelf.
- **USB Port:** The integrated USB port is for charging small electronic devices. Do not overload the port.
- **Cleaning:** Disconnect power before cleaning. Use a dry, soft cloth. Do not use abrasive cleaners or solvents.

PACKAGE CONTENTS

Please check that all components are present and undamaged. If any parts are missing or damaged, contact your retailer.

- Lindby Vatana Wall Lamp fixture (Model 10030171)
- Mounting hardware (screws, wall plugs)
- Instruction Manual

Note: Light bulbs are not included and must be purchased separately.

SETUP AND INSTALLATION

Follow these steps carefully for proper installation. It is recommended to have two people for installation.

1. Prepare for Installation

1. **Turn off Power:** Locate the circuit breaker for the installation area and turn off the power supply. Verify power is off using a voltage tester.
2. **Unpack:** Carefully remove all components from the packaging.
3. **Identify Mounting Location:** Choose a suitable wall location, ensuring it can support the lamp's weight and has access to a power outlet.

2. Mark and Drill Holes

1. **Position the Lamp:** Hold the lamp against the wall at the desired height and mark the positions for the mounting brackets. Ensure it is level.
2. **Drill Holes:** Using an appropriate drill bit for your wall type, drill pilot holes at the marked locations. Insert wall plugs if necessary.
- 3.




Image: Dimensions of the Lindby Vatana wall lamp. The lamp measures 80 cm in width, 23.5 cm in height, and 16 cm in depth. The power cord extends 102.5 cm from the lamp.

3. Mount the Lamp

1. **Secure Brackets:** Attach the lamp's mounting brackets to the wall using the provided screws. Ensure they are

firmly secured.

2. **Connect Power:** Plug the lamp's power cord into a suitable wall outlet.

3.



Image: Detail of the E27 bulb sockets and metal bracket. This image shows where the bulbs are screwed in and how the lamp is supported.

4. Install Bulbs

1. **Insert Bulbs:** Carefully screw four E27 bulbs (max 15W each) into the lamp sockets. Do not overtighten.

2.



Image: The Lindby Vatana wall lamp with bulbs installed, mounted on a wall. The image displays the lamp's overall appearance and how it functions as both a light source and a small shelf.

OPERATING INSTRUCTIONS

1. Turning the Lamp On/Off

- **Rocker Switch:** The lamp is equipped with a rocker switch located on the side of the wooden body. Press the "I" side to turn the lamp ON and the "O" side to turn it OFF.
-



Image: Detail of the rocker switch. This image highlights the physical switch used to control the lamp's power.

2. Using the USB Charging Port

- **Connect Device:** Plug your USB charging cable into the USB port located on the lamp.
- **Charge:** Connect the other end of the cable to your smartphone or other compatible electronic device to begin charging. The USB port is active when the lamp is plugged into a power outlet, regardless of whether the light is on or off.

MAINTENANCE

- **Cleaning:** Before cleaning, ensure the lamp is unplugged from the power outlet. Wipe the wooden and metal surfaces with a soft, dry, or slightly damp cloth. Do not use harsh chemicals, abrasive cleaners, or polishes that could damage the finish.
- **Bulb Replacement:** Always disconnect power before replacing bulbs. Allow old bulbs to cool completely before removal. Screw in new E27 bulbs (max 15W) carefully.
- **Inspection:** Periodically inspect the power cord and lamp for any signs of damage. If damage is found, discontinue

use and contact a qualified technician.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	No power supply. Bulb(s) faulty or not screwed in correctly. Rocker switch is OFF.	Check if the power cord is securely plugged into a working outlet. Ensure the circuit breaker is ON. Replace faulty bulbs. Ensure bulbs are screwed in tightly. Press the "I" side of the rocker switch.
USB port is not charging.	Lamp not plugged in. Device cable faulty. Device not compatible.	Ensure the lamp is plugged into a live power outlet. Try a different USB cable. Verify your device is compatible with standard USB charging.
Flickering light.	Loose bulb connection. Incompatible bulb.	Tighten bulbs. Ensure bulbs are E27 type and within the 15W limit.

SPECIFICATIONS

Brand	Lindby
Model Number	10030171
Material	Wood
Color	Dark Wood
Style	Rustic / Farmhouse
Product Dimensions (L x W x H)	80 cm x 16 cm x 23.5 cm
Weight	3.4 kg
Bulb Sockets	4 x E27
Max. Wattage per Bulb	15W (LED recommended)
Operating Voltage	230 Volts
Power Source	Corded Electric
Switch Type	Rocker Switch
USB Charging Port	Yes
Protection Rating	IP20 (Indoor Use Only)
Protection Class	II
Bulbs Included	No

WARRANTY AND SUPPORT

This product is manufactured by Lindby and distributed by Lampenwelt. For warranty information or technical support, please refer to the purchase documentation or contact your retailer directly. You may also contact Lampenwelt customer service through their seller profile on Amazon for assistance with product-related questions.

Note: The quality of this product has been certified by experts.

© 2026 Lindby. All rights reserved.