

[Manuals.plus](#) /

› [WLIVE](#) /

› WLIVE 70-Inch Farmhouse TV Stand Instruction Manual

WLIVE B0F2MJLSNM

WLIVE 70-Inch Farmhouse TV Stand Instruction Manual

Model: B0F2MJLSNM

[Contents](#) [Assembly](#) [Introduction](#) [Safety Information](#) [Package](#)
[Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Support](#)

1. INTRODUCTION

Thank you for purchasing the WLIVE 70-Inch Farmhouse TV Stand. This entertainment center is designed to accommodate TVs up to 80 inches and features ample storage with adjustable shelves, cable management, and corrugated acrylic doors. This manual provides essential information for safe assembly, operation, and maintenance of your new TV stand.



Image 1.1: The WLIVE 70-Inch Farmhouse TV Stand, designed to support TVs up to 80 inches and a maximum weight of 150 lbs.

2. SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or product damage.

- **Weight Limit:** Do not load more than 150 lbs (68 kg) on the tabletop. Exceeding this weight limit may cause the stand to sag or become unstable, leading to potential injury or damage.
- **Stability:** Ensure the TV stand is placed on a flat, level, and stable surface.
- **Assembly:** Assembly requires two people for efficient and safe setup. Do not attempt to assemble alone.
- **Children:** Keep children away from the assembly area. Small parts can be a choking hazard.
- **Care:** Wipe with a dry cloth only. Avoid harsh chemicals.



Image 2.1: Illustration highlighting the 3-inch thickened base for enhanced stability and support for TVs up to 80 inches.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all parts and hardware are present and undamaged. Refer to the detailed parts list provided in your assembly guide. The package typically includes:

- Particle board panels for the frame, shelves, and doors.
- Corrugated acrylic door panels.
- Metal handles and hinges.
- Assembly hardware (screws, dowels, cam locks, etc.).
- Adjustable shelf pins.
- Cable management grommets.
- Instruction manual.



Image 3.1: A view of the TV stand's interior, illustrating the two storage cabinets with adjustable shelves.

4. ASSEMBLY INSTRUCTIONS

Assembly is required for this product. Please follow the detailed instructions provided in the included assembly guide. Two people are recommended for efficient and safe setup. Necessary tools are included.

General Steps:

1. Unpack all components and verify against the parts list.
2. Identify and separate hardware.
3. Assemble the main frame of the TV stand.
4. Install the adjustable shelves into the side cabinets.
5. Attach the corrugated acrylic doors using the provided hinges and handles.
6. Insert cable management grommets into the designated holes.
7. Place the assembled TV stand in its desired location, ensuring it is level.

Assembly Tutorial Video:

Your browser does not support the video tag.

Video 4.1: A short official WLIVE video demonstrating the assembly or features of the TV stand. (Duration: 0:09)

5. OPERATING INSTRUCTIONS

Adjustable Shelves:

The side storage cabinets feature 3-level adjustable shelves. To adjust a shelf, remove any items, lift the shelf, and reposition the shelf pins to the desired height. Ensure all four pins are securely inserted before placing items back on the shelf.



Image 5.1: Detailed diagram illustrating the three adjustable positions for each shelf, with 1.5 inches between each level.

Cable Management:

Utilize the triangular cable holes located at the back of the TV stand to organize and route your electronic device cables. This helps maintain a tidy appearance and prevents tangled wires.

Corrugated Acrylic Doors:

The corrugated acrylic doors provide a modern aesthetic while allowing remote control signals to pass through without obstruction. This means you can operate your devices stored inside the cabinets even when the doors are closed.

CORRUGATED ACRYLIC DOORS

Not Affect Signal
Reception



Image 5.2: An illustration demonstrating how remote control signals can effectively pass through the corrugated acrylic doors.

6. MAINTENANCE

To keep your WLIVE TV stand in optimal condition, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the surfaces with a dry, soft cloth. Avoid using abrasive cleaners, harsh chemicals, or wet cloths, as these may damage the finish.
- **Spills:** In case of spills, wipe immediately with a dry cloth to prevent moisture absorption.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration of the material.

7. TROUBLESHOOTING

If you encounter any issues with your WLIVE TV stand, please refer to the following common solutions:

- **Stand is wobbly:** Ensure all screws are tightened. Verify the stand is on a level surface. Adjust the feet if applicable.
- **Doors do not close properly:** Check hinges for proper alignment and tightness. Ensure no items inside the cabinet are obstructing the door.
- **Missing parts:** Double-check the packaging. If parts are genuinely missing, contact customer support immediately.
- **Difficulty with assembly:** Review the instruction manual carefully. Watch the assembly tutorial video if available. Ensure you have all necessary tools and assistance.

8. SPECIFICATIONS



Image 8.1: Detailed product dimensions, including overall size and internal compartment measurements.

Feature	Detail
---------	--------

Brand	WLIVE
Model	70" Farmhouse TV Stand (B0F2MJLSNM)
Color	Black
Material Type	Engineered Wood, Acrylic
Overall Dimensions (W x D x H)	69.69 x 14.96 x 26.77 inches
Max. TV Size Supported	Up to 80 inches
Max. Tabletop Load Capacity	150 lbs (68 kg)
Number of Shelves	6 (3-level adjustable in side cabinets)
Additional Features	Adjustable Shelves, Cable Management, Corrugated Acrylic Doors
Assembly Required	Yes
Product Care Instructions	Wipe with Dry Cloth

9. WARRANTY & CUSTOMER SUPPORT

WLIVE is committed to providing high-quality products and excellent customer service. While specific warranty details are not provided in this document, WLIVE offers 24/7 customer support for any questions or concerns you may have regarding your product.

For assistance, please refer to the contact information provided with your purchase or visit the official WLIVE website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question