

Manuals.plus /

> WOLFANG /

> WOLFANG WMP01 64GB MP3 Player with Bluetooth 5.3 User Manual

## WOLFANG WMP01

# WOLFANG WMP01 64GB MP3 Player with Bluetooth 5.3 User Manual

Model: WMP01 | Brand: WOLFANG

## 1. PRODUCT OVERVIEW

The WOLFANG WMP01 is a compact and lightweight 64GB MP3 player designed for active lifestyles. It features Bluetooth 5.3 for stable wireless connections, Hi-Fi lossless sound quality, an FM radio, voice recorder, and a pedometer. Its mini size and sport clip make it ideal for on-the-go music enjoyment.



Image 1.1: WOLFANG WMP01 MP3 Player highlighting its key features.

### Key Features:

- **64GB Internal Storage:** Store thousands of songs. Expandable up to 128GB with a Micro SD card.
- **Bluetooth 5.3:** Faster transmission, longer connection distance, and improved anti-interference.
- **Hi-Fi Lossless Sound:** Integrated audio decoding chip for exceptional sound quality.
- **Multi-functional:** Includes FM radio, photo viewer, voice recorder, pedometer, and stopwatch.
- **Sport Clip Design:** Easily attachable to clothing or bags for portability.
- **Lightweight:** Weighs only 28 grams.

## 2. PACKAGE CONTENTS

Upon opening your WOLFANG WMP01 MP3 Player package, you should find the following items:

- 1 x WOLFANG WMP01 MP3 Player
- 1 x Wired Earphones
- 1 x USB Charging Cable (Type-C)
- 1 x User Manual (Quick Guide)
- 1 x 64GB TF Card (pre-installed or included separately)



### Lista de Paquetes

- 1.Caja de regalo
- 2.Auriculares con cable
- 3.Cable de datos USB
- 4.Guía rápida
- 5.Tarjeta TF de 64 G
- 6.Reproductor de música MP3

Image 2.1: All items included in the WOLFANG WMP01 MP3 Player package.

## 3. DEVICE LAYOUT AND CONTROLS

Familiarize yourself with the physical components and controls of your WMP01 MP3 player:

- **Volume Up/Down Buttons:** Located on the side.

- **Power Button:** Located on the side.
- **Micro SD Card Slot:** For memory expansion (up to 128GB).
- **Sport Clip:** On the back for secure attachment.
- **Reset Pinhole:** For device reset in case of malfunction.
- **Type-C Port:** For charging and data transfer.
- **Headphone Jack (3.5mm):** For wired earphones.

Your browser does not support the video tag.

Video 3.1: A detailed overview of the WOLFANG WMP01 MP3 Player's physical features and controls, including volume buttons, power button, Micro SD card slot, sport clip, reset pinhole, Type-C port, and headphone jack.

## 4. SETUP AND INITIAL USE

### 4.1 Charging the Device

Before first use, fully charge your MP3 player. Connect the provided USB Type-C cable to the player and a power source (e.g., computer USB port, USB wall adapter). The device will indicate charging status.

- **Charging Time:** Approximately 1.5 hours for a full charge.
- **Playback Time:** Up to 24 hours on a full charge.
- **Standby Time:** Up to 480 hours.

### 4.2 Transferring Music

To transfer music files to your WMP01 MP3 player:

1. Connect the MP3 player to your computer using the USB Type-C cable.
2. On the MP3 player screen, select "Charge & transfer" when prompted.
3. Your computer will recognize the MP3 player as a removable disk.
4. Drag and drop your music files (MP3, APE, FLAC, WAV, DRM, ACELP formats supported) from your computer to the "Music" folder on the MP3 player.
5. Once transfer is complete, safely eject the device from your computer before disconnecting the cable.

Your browser does not support the video tag.

Video 4.1: Demonstrates how to quickly import music onto your WOLFANG WMP01 MP3 Player by connecting it to a computer and transferring files.

## 5. OPERATING INSTRUCTIONS

### 5.1 Basic Navigation

Use the physical buttons on the front of the device to navigate through menus, select options, and control playback. The central play/pause button, along with the directional and menu buttons, allows for intuitive operation.

## 5.2 Bluetooth Pairing

The WMP01 MP3 player supports Bluetooth 5.3 for connecting to wireless headphones or speakers. It does not connect to mobile phones or computers via Bluetooth.

1. Ensure your Bluetooth headphones or speaker are in pairing mode.
2. On the MP3 player, navigate to the Bluetooth menu.
3. Turn Bluetooth on and select "Search for device."
4. Select your device from the list to pair.

Your browser does not support the video tag.

Video 5.1: Guide on how to pair your WOLFANG WMP01 MP3 Player with Bluetooth headphones or speakers.

## 5.3 Using the Sport Clip

The integrated sport clip allows you to securely attach the MP3 player to your clothing, belt, or bag, providing hands-free music during activities.

Your browser does not support the video tag.

Video 5.2: Demonstrates the versatility of the sport clip for attaching the MP3 player to various items of clothing.

## 5.4 Supported Music Formats

The WMP01 supports a wide range of audio formats, including MP3, APE, FLAC, WAV, DRM, and ACELP, ensuring compatibility with most of your music library.



Image 5.3: Supported audio formats for the WOLFANG WMP01 MP3 Player.

## 6. MAINTENANCE

To ensure the longevity and optimal performance of your WOLFANG WMP01 MP3 Player:

- Keep the device dry and away from extreme temperatures.
- Clean the screen and body with a soft, dry cloth. Avoid abrasive cleaners.
- Avoid dropping the device or subjecting it to strong impacts.
- Use only the provided charging cable or a certified equivalent.

## 7. TROUBLESHOOTING

### 7.1 Device Freezes or Becomes Unresponsive

If your MP3 player freezes or stops responding:

1. Carefully remove the Micro SD card from its slot.
2. Locate the reset pinhole on the device.
3. Insert a small, pointed object (like an ejection pin or straightened paperclip) into the reset pinhole and gently press until the device restarts.
4. If the issue persists, ensure the device firmware is up to date. Contact customer support for the latest firmware.

Your browser does not support the video tag.

Video 7.1: Instructions on how to troubleshoot a frozen WOLFANG WMP01 MP3 Player by removing the memory card and performing a reset.

## 8. SPECIFICATIONS

Feature	Specification
Model Number	WMP01
Brand	WOLFANG
Storage Capacity	64 GB (expandable up to 128 GB via Micro SD)
Connectivity Technology	Bluetooth 5.3, Wired
Supported Audio Formats	MP3, APE, FLAC, WAV, DRM, ACELP
Special Features	Voice Recorder, Digital Radio (FM), Pedometer
Screen Size	5.9 Centimeters
Product Dimensions	5.9 x 3.8 x 1.8 cm
Product Weight	28 grams
Country of Origin	China

## 9. WARRANTY AND SUPPORT

WOLFANG offers a comprehensive after-sales service for your WMP01 MP3 Player:

- **Free Maintenance:** 10 years of free maintenance.
- **Technical Support:** Professional technical assistance for life.

For any inquiries, technical support, or warranty claims, please contact WOLFANG customer service via their official online channels or email: [support.vc@wolfang.co](mailto:support.vc@wolfang.co). You may also refer to the QR code in the physical manual for direct access to support.