

[Manuals.plus](#) /

› [Ezebaby](#) /

› Ezebaby Convertible Baby High Chair (Green) - Instruction Manual

Ezebaby B0F2MQ8MM8

Ezebaby Convertible Baby High Chair (Green)

MODEL: B0F2MQ8MM8 - INSTRUCTION MANUAL

1. Product Overview: 8-in-1 Convertible Design

The Ezebaby Convertible Baby High Chair is designed to adapt to your child's growth, offering 8 different configurations from infancy to early childhood. This versatile design ensures long-term utility and convenience for various activities.

- **High Chair for Infants:** Provides a secure and comfortable feeding position for babies.
- **Toddler High Chair:** Adjusts for older toddlers to self-feed.
- **Booster Seat:** Can be attached to a standard dining chair for mealtime with the family.
- **Kids Chair:** A standalone chair for children.
- **Child Stool:** A low stool for various activities.
- **Junior Stool:** A slightly taller stool for growing children.
- **Learning Table & Chair Set:** Transforms into a small table and chair for playtime or learning.
- **Small Dining Chair:** A compact chair suitable for young children at a table.



Baby High Chair

8-in-1 Convertible Design



Learning Table & Chair



Baby Booster Seat



Kids Chair



Small Dining Chair



Baby Chair



Junior Stool



Child Stool

Image 1.1: The Ezebaby high chair demonstrating its 8-in-1 convertible design, including high chair, booster seat, kids chair, and learning table configurations.

Your browser does not support the video tag.

Video 1.1: An overview of the Ezebaby Convertible Baby High Chair, showcasing its various configurations and ease of transformation.

2. Safety and Stability Features

The high chair is engineered with your child's safety as a priority, featuring robust construction and secure restraint systems.

- **Sturdy Construction:** Crafted with solid beech wood legs and a pyramid-shaped base for enhanced stability.
- **Non-Slip Feet:** Enlarged non-slip feet prevent tipping on various floor surfaces, including hardwood and tile.
- **5-Point Harness:** A secure 5-point harness system keeps your child safely seated, preventing accidental falls.

- **Anti-Falling Barrier:** Integrated design elements further enhance safety by minimizing the risk of falling.



Image 2.1: Detailed view of the high chair's safety features, including the 5-point harness, anti-falling barrier, durable beech wood legs, and enlarged non-slip feet.

3. Adjustable and Detachable Tray

The high chair features a highly functional tray designed for convenience and adaptability.

- **Three-Position Adjustment:** The tray slides into three distinct positions to accommodate your child's growth and activity, from snug infant seating to toddler self-feeding or a play zone.
- **Fully Detachable:** The tray can be easily detached for versatile use, allowing the high chair to be pulled up to a dining table or for easy cleaning.



Image 3.1: The high chair's tray illustrating its three adjustable positions for different stages of child development.

4. Easy-to-Clean Design

Maintaining hygiene is simple with the Ezebaby high chair's thoughtful design.

- **Dishwasher-Safe Tray:** The main tray is dishwasher-safe, allowing for thorough and effortless cleaning after meals.
- **Removable PU Cushion:** The soft PU cushion can be easily removed and wiped clean in seconds with a damp cloth, making it ideal for busy parents.



Image 4.1: Demonstrates the ease of cleaning the high chair's tray and removable cushion.

5. Setup Instructions

The Ezebaby high chair is designed for quick and stress-free assembly without the need for additional tools.

1. **Unbox and Verify Parts:** Carefully unbox all components and ensure all parts are present according to the packing list.
2. **Assemble Table Base (for high chair/learning table modes):** Connect the longer wooden legs (G) to the table base (D) by inserting them firmly until they click into place.
3. **Assemble Seat Base (for booster/child chair modes):** Connect the shorter wooden legs (E or F) to the seat base (B) by inserting them firmly until they click into place. Ensure 'R' marked legs are on the right side and 'L' on the left.
4. **Attach Seat to Table Base (for high chair mode):** Place the assembled seat (A) onto the assembled table base

(D), aligning the connection points and pressing down until it securely locks.

5. **Attach Tray:** Slide the tray (C) onto the armrests of the seat until it clicks firmly into place.



Image 5.1: Visual guide illustrating the tool-free assembly process of the high chair components.

Your browser does not support the video tag.

Video 5.1: A demonstration of the assembly process for the Ezebaby Convertible Baby High Chair, showing how to connect the legs, seat, and tray.

6. Operating Modes and Usage

The high chair's modular design allows for easy conversion between its 8 modes to suit different ages and needs.

- **High Chair:** Use the full assembly for infants and toddlers during meal times.
- **Booster Seat:** Detach the seat from the table base and use the integrated straps to secure it to a standard dining chair.
- **Kids Chair/Child Stool/Junior Stool:** Remove the seat from the table base and attach the appropriate shorter legs for a standalone chair or stool.
- **Learning Table & Chair:** Use the table base with its short legs as a separate activity table, and the seat with its short legs as a matching chair.



Image 6.1: The high chair shown in different settings, demonstrating its adaptability for feeding, play, and learning activities.

Your browser does not support the video tag.

Video 6.1: A concise video demonstrating the 8-in-1 conversion capabilities of the Ezebaby high chair, highlighting each mode.

7. Maintenance

Regular cleaning and maintenance will ensure the longevity and hygiene of your Ezebaby high chair.

- **Tray Cleaning:** The detachable tray is dishwasher-safe. For manual cleaning, wash with warm soapy water and rinse thoroughly.
- **Cushion Cleaning:** The removable PU cushion can be wiped clean with a damp cloth and mild soap. Do not machine wash or tumble dry.

- **Frame and Legs:** Wipe down the plastic and wooden components with a damp cloth. Avoid abrasive cleaners.
- **Harness Straps:** The harness straps can be spot cleaned with mild soap and water. Ensure they are completely dry before re-use.

8. Troubleshooting

If you encounter any issues with your high chair, please refer to the following common solutions:

- **Instability:** Ensure all legs are fully inserted and locked into their respective bases. Check that the seat is securely clicked onto the table base if in high chair mode.
- **Tray Not Attaching/Detaching:** Verify that the release buttons are fully pressed when detaching and that the tray is aligned correctly when attaching until a click is heard.
- **Harness Issues:** Ensure straps are not twisted and are correctly threaded through the slots. Adjust the strap length for a snug but comfortable fit.
- **Difficulty Converting Modes:** Refer to the assembly instructions (Section 5) and ensure all release buttons for legs and seat are properly engaged or disengaged during conversion.

9. Specifications

Feature	Detail
Brand	Ezebaby
Model Number	B0F2MQ8MM8
Color	Green
Age Range Description	6-36 months
Maximum Weight Recommendation	33 Pounds (15 kg)
Item Weight	6.92 Kilograms
Item Dimensions (D x W x H)	15"D x 17"W x 12.2"H (dimensions for seat only, full high chair dimensions vary)
Material Type	Beech Wood, PU Cushion
Assembly Required	Yes (Tool-free)
Is Portable	Yes

Product Dimension



Image 9.1: Diagram illustrating the various dimensions of the high chair and its components in different configurations.

10. Warranty and Support

For any questions, concerns, or support needs regarding your Ezebaby Convertible Baby High Chair, please contact Ezebaby customer service. While specific warranty details are not provided in this manual, Ezebaby is committed to customer satisfaction.

Please retain your proof of purchase for any warranty claims or support inquiries.

You can visit the official Ezebaby store for more information and contact options: [Ezebaby Official Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F2MQ8MM8>

More documents and user manuals: <https://manuals.plus/>