

80x30x103cm

## Generic 4-Tier Microwave Oven Rack with Wheels

Model: 80x30x103cm

### PRODUCT OVERVIEW

This manual provides instructions for the assembly, operation, and maintenance of your Generic 4-Tier Microwave Oven Rack. This versatile storage solution is designed to organize kitchen appliances and essentials, optimizing your kitchen space.

Key features include:

- Versatile design suitable for kitchen and office use.
- Constructed with industrial-grade materials for stability and durability.
- Ample storage space with convenient wire baskets for utensils, recipes, and spices.
- Removable and lockable wheels for easy mobility and secure placement.
- Multifunctional use as a microwave stand, baker's rack, spice organizer, or workstation.

### SETUP INSTRUCTIONS


Please follow these steps carefully to assemble your microwave oven rack. It is recommended to assemble the unit on a soft, clean surface to prevent scratches.

#### Package Contents:

- Frame components (vertical supports, horizontal bars)
- Shelf panels (wood or metal)
- Wire baskets
- Wheels (4, with 2 lockable)
- Assembly hardware (screws, bolts, Allen wrench)

#### Assembly Steps:

1. **Attach Wheels:** Carefully insert and screw the four wheels into the designated holes at the bottom of the main frame's vertical supports. Ensure two of the wheels are the lockable type and are positioned at the front for easy access.



*Image: Detail of a wheel, showing its 360-degree rotation capability. Ensure wheels are securely attached.*

2. **Assemble Frame:** Connect the vertical support bars using the horizontal crossbars. Use the provided screws and Allen wrench to secure all connections. Do not overtighten initially.
3. **Install Shelves:** Place the shelf panels onto the designated support brackets on the frame. Ensure they are level and securely seated. The rack features multiple tiers for various items.



Image: Fully assembled rack with dimensions (80x30x103cm). Note the placement of shelves and baskets.

4. **Attach Wire Baskets:** Hook or slide the wire baskets into their designated positions on the side of the rack. These are typically designed for easy removal and reattachment.
5. **Final Tightening:** Once all components are in place and the rack is stable, fully tighten all screws and bolts.
6. **Positioning:** Move the assembled rack to your desired location. Lock the front wheels to secure it in place.

## OPERATING INSTRUCTIONS

This microwave oven rack is designed for straightforward use and organization.

- **Placement of Appliances:** Place heavier appliances such as microwave ovens or blenders on the lower, more stable shelves. Ensure the appliance fits within the shelf dimensions and weight capacity.
- **Utilizing Storage:** Use the various shelves and wire baskets to store kitchen items such as spices, dishes, cookware, and fresh produce. The wire baskets are ideal for items requiring ventilation.



*Image: Detail of wire baskets with guardrails, highlighting breathability for stored items.*

- **Mobility:** To move the rack, unlock the front wheels by flipping their levers. Guide the rack to its new position and then lock the wheels again to ensure stability.
- **Adjusting Shelf Height:** The rack features a 10cm height adjustment capability for certain shelves. Refer to the assembly diagram for specific instructions on how to reposition shelves if this feature is present.



Image: Illustration of a 10cm height adjustment capability for shelves.

## MAINTENANCE

Proper maintenance will ensure the longevity and appearance of your microwave oven rack.

- **Cleaning:** Wipe down the metal frame and wooden shelves with a soft, damp cloth. For stubborn stains, a mild soap solution can be used. Avoid abrasive cleaners or harsh chemicals, as these can damage the finish.
- **Drying:** After cleaning, dry all surfaces thoroughly with a clean, dry cloth to prevent water spots and rust.
- **Inspection:** Periodically check all screws and bolts to ensure they remain tight. Retighten if necessary to maintain stability.
- **Weight Distribution:** Avoid placing excessively heavy items on a single shelf or concentrating weight unevenly, which can stress the frame.

## TROUBLESHOOTING

If you encounter any issues with your rack, refer to the following common solutions:

- **Rack is Unstable/Wobbly:**
  - Ensure all screws and bolts are fully tightened.
  - Check that the rack is on a level surface.

- Verify that the wheels are locked if you intend for the rack to be stationary.

- **Wheels Not Rolling Smoothly:**

- Check for any debris (hair, dust) caught in the wheel mechanisms.
- Ensure the wheels are unlocked if you intend to move the rack.

- **Difficulty Assembling:**

- Review the assembly steps and diagrams carefully.
- Ensure you are using the correct hardware for each step.
- Do not overtighten screws until the entire frame is loosely assembled.

## SPECIFICATIONS

<b>Brand</b>	Generic
<b>Model Number</b>	80x30x103cm
<b>Color</b>	A
<b>Dimensions (L x W x H)</b>	80 cm x 30 cm x 103 cm
<b>Shelf Type</b>	Tiered Shelf
<b>Shape</b>	Trapezoid
<b>Material</b>	Durable metal and wood
<b>Wheels</b>	Removable and lockable



*Image: Shelf height details, indicating 32cm for the top shelf and 24cm for the middle and bottom shelves.*

## **WARRANTY AND SUPPORT**

This product is covered by a **30-day return policy** for refund or replacement, as per the seller's terms. For any questions, missing parts, or support needs beyond this period, please contact the seller directly through your purchase platform.

Please retain your proof of purchase for any warranty or support claims.