

WLIVE ADSG074WH

WLIVE LED TV Stand with Large Storage Cabinet (Model
ADSG074WH) Instruction Manual

Your guide to assembly, operation, and maintenance.

1. INTRODUCTION

Thank you for choosing the WLIVE LED TV Stand with Large Storage Cabinet. This manual provides detailed instructions for the safe assembly, operation, and maintenance of your new entertainment center. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

This modern TV stand (Model ADSG074WH) is designed to accommodate TVs from 43" to 75" and features customizable LED lighting and versatile storage options.

2. IMPORTANT SAFETY INFORMATION

- Always ensure that the TV stand is not overloaded beyond its weight limit of **10 pounds**.
- Use the provided cable routing holes to manage cables safely and prevent tripping hazards.
- Do not place heavy objects on the top of the TV stand to avoid tipping.
- Keep small parts away from children during assembly to prevent choking hazards.
- Assemble the unit on a soft, clean surface to prevent scratches.
- Periodically check all connections and tighten as necessary.

3. SETUP AND ASSEMBLY

Assembly of the WLIVE LED TV Stand requires two people for optimal safety and efficiency. All necessary parts and tools are included and labeled. Follow the steps below carefully.

3.1. Assembly Video Guide



Video Description: This video provides a detailed, step-by-step visual guide for assembling the WLIVE TV Stand (Model 044, similar to ADSG074WH). It covers all stages from identifying parts to final construction, demonstrating the correct placement and fastening of each component. The video is 14 minutes and 35 seconds long and includes English closed captions.

3.2. Step-by-Step Assembly Instructions

1. **Prepare Components:** Unpack all parts and lay them out on a soft, clean surface. Identify each part using the provided labels (A, B, C, etc.).
2. **Assemble Base Structure:** Begin by attaching the cam locks and dowels to the main base panels as indicated in the manual. Ensure all connections are secure.
3. **Install LED Strips:** Carefully attach the LED light strips to the designated areas on the main shelf. Ensure the wiring is routed correctly through the pre-drilled holes.
4. **Construct Side Cabinets:** Assemble the side cabinet frames, securing them to the main base.
5. **Attach Back Panels:** Slide the back panels into place, ensuring they fit snugly and align with the pre-drilled holes.
6. **Install Hinges:** Attach the hinges to the cabinet doors using the provided screws. Pay attention to the orientation of the hinges (refer to the manual for correct placement).
7. **Mount Cabinet Doors:** Carefully attach the cabinet doors to the main unit, aligning the hinges with the pre-drilled holes on the cabinet frame. Adjust as needed for proper closure.
8. **Connect LED Wiring:** Connect the LED light strips to the power adapter and remote receiver. Route all cables through the cable management holes to keep them tidy.
9. **Final Checks:** Once assembled, gently lift and place the TV stand in its desired location. Ensure all screws are tightened and the unit is stable.



Suitable For TV Size Up To 75"

Image Description: An image illustrating the dimensions of the WLIVE TV Stand (67" W x 14" D x 17.7" H) and its compatibility with TV sizes ranging from 50" to 75". It highlights the central open shelf area (20" W x 8.2" H) and the side cabinet depths (13.4" D x 15.5" H).

4. OPERATING INSTRUCTIONS (LED LIGHTS)

Your WLIVE LED TV Stand features customizable LED lighting to enhance your entertainment experience. Use the included remote control to manage the lighting effects.

- **Power On/Off:** Press the power button on the remote to turn the LED lights on or off.
- **Brightness Adjustment:** Select from 5 brightness levels to suit your preference.
- **Color Selection:** Choose from 20 vibrant colors to set the mood.
- **Dynamic Modes:** Explore various dynamic modes, including options that sync with music for an immersive experience.
- **Remote Control Range:** The remote control operates effectively within a distance of up to 15 meters.



Image Description: A visual representation of the WLIVE TV Stand's LED lighting features, showing a remote control and icons for 5 brightness levels, 22 modes, and 20 main colors. The image demonstrates various color combinations and the remote's functionality.



Video Description: This video showcases the WLIVE Modern LED TV Stand's lighting features. It demonstrates changing colors and modes using a remote control, highlighting the 5 brightness levels, 22 modes, and 20 main colors. The video also briefly shows the soft-close cabinet doors and large storage space. The duration is 38 seconds.

5. MAINTENANCE

- **Cleaning:** The water-resistant and stain-resistant wood countertop can be easily wiped clean with a damp cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Dusting:** Regularly dust the surfaces with a soft, dry cloth to maintain its appearance.
- **Hardware Check:** Periodically inspect all screws and connections to ensure they remain tight. Re-tighten if necessary to maintain stability.

- **LED Care:** Avoid bending or damaging the LED light strips. If the lights malfunction, check the power connection and remote control battery before contacting support.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Unit is wobbly/unstable.	Loose screws or uneven assembly.	Check all screws and tighten them securely. Ensure the unit is on a flat, level surface.
LED lights not working.	Power connection issue, remote battery dead, or damaged LED strip.	Verify the power adapter is securely plugged in. Replace the remote control battery. Inspect the LED strip for visible damage.
Cabinet doors do not close properly.	Hinges are misaligned or loose.	Adjust the hinge screws to align the doors. Ensure the soft-close mechanism is not obstructed.

7. SPECIFICATIONS

Feature	Detail
Brand	WLIVE
Model Name	ADSG074WH
Color	White
Product Dimensions	66.93 x 14.09 x 17.72 inches
Item Weight	57.7 pounds
Material	Engineered Wood
Finish Type	High-Gloss
Weight Limit	110 Pounds
Number of Shelves	4
Assembly Required	Yes

8. WARRANTY AND SUPPORT

For any questions regarding assembly, missing parts, or product functionality, please contact WLIVE customer support. Refer to your purchase documentation for specific warranty details and contact information.

You can also visit the official WLIVE store for additional product information and support:[WLIVE Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F2MV9WDP>

More documents and user manuals: <https://manuals.plus/>