

## Crompton LED5WCHTBL-DSKJOY

# Crompton DeskJoy 5W Rechargeable LED Table Lamp User Manual

Model: LED5WCHTBL-DSKJOY

## 1. INTRODUCTION

---

Thank you for choosing the Crompton DeskJoy 5W Rechargeable LED Table Lamp. This manual provides essential information for the safe and efficient use of your new lamp. Please read it thoroughly before operation and retain it for future reference.

The Crompton DeskJoy lamp is designed for study and work, featuring a flexible gooseneck, 3-step dimming, and a rechargeable battery for portable illumination.

## 2. SAFETY INSTRUCTIONS

---

- Do not expose the lamp to water or excessive moisture.
- Avoid disassembling or modifying the lamp. This may void the warranty and pose safety risks.
- Keep the lamp away from direct heat sources or flammable materials.
- Use only the provided C-type charging cable or a certified equivalent.
- Do not operate the lamp if it is damaged or malfunctioning. Contact customer support.
- This lamp is intended for indoor use only.

## 3. PACKAGE CONTENTS

---

Verify that all items are present in the package:

- Crompton DeskJoy 5W Rechargeable LED Table Lamp
- C-Type Charging Cable
- User Manual (this document)

## 4. PRODUCT OVERVIEW

---

The Crompton DeskJoy lamp features a sleek design with practical functionalities for various lighting needs.

**Crompton**

Lighting

# DESKJOY LED TABLE LAMP



**Image 1:** Crompton DeskJoy LED Table Lamp. This image shows the lamp on a desk with books and stationery, highlighting its 360-degree flexible neck and 5W LED light output.

## Key Features:

- **Rechargeable Battery:** Equipped with an 1800mAh Lithium-Ion battery, providing up to 10 hours of continuous use in low mode.
- **Flexible Gooseneck:** A 360-degree twisting and rotating gooseneck allows for precise light positioning.
- **3-Step Dimming:** Easily adjust brightness levels with a touch-sensitive control.
- **C-Type Charging:** Convenient and universal C-type charging port.
- **Durable Construction:** Made from Acrylonitrile Butadiene Styrene (ABS) for a sturdy build.

## 5. SETUP

### 5.1 Unpacking

Carefully remove all components from the packaging. Inspect the lamp and accessories for any signs of damage. If any damage is found, do not use the product and contact customer support.

### 5.2 Initial Charging

Before first use, fully charge the lamp. Connect the provided C-type charging cable to the lamp's charging

port and plug the other end into a compatible USB power adapter (not included). The charging indicator light will typically show the charging status. A full charge usually takes 4-5 hours.

## 6. OPERATING INSTRUCTIONS

### 6.1 Power On/Off and Dimming



**Image 2:** Lamp base with touch controls. This image provides a close-up view of the lamp's base, illustrating the touch-sensitive power button and the indicators for the 3-step dimming function.

- **To Power On:** Lightly tap the touch-sensitive power button located on the lamp base. The lamp will turn on at the lowest brightness setting.
- **To Adjust Brightness (Dimming):** After turning on, tap the power button repeatedly to cycle through the 3 brightness levels (low, medium, high).
- **To Power Off:** Continue tapping the power button until the lamp turns off after cycling through all brightness levels.

### 6.2 Adjusting Lamp Position

The lamp features a 360-degree flexible gooseneck. Gently bend and twist the neck to direct the light precisely where needed. Avoid excessive force to prevent damage to the gooseneck.

## 7. MAINTENANCE

---

### 7.1 Cleaning

Ensure the lamp is turned off and unplugged before cleaning. Wipe the lamp's surface with a soft, dry cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish.

### 7.2 Battery Care

To prolong battery life, avoid fully discharging the lamp frequently. Recharge the lamp when the light output becomes noticeably dim. If storing the lamp for an extended period, charge it at least once every three months to maintain battery health.

## 8. TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Lamp does not turn on.	Battery is discharged.	Charge the lamp using the C-type cable.
Lamp light is dim or flickers.	Low battery.	Recharge the lamp.
Lamp does not charge.	Charging cable or adapter faulty; improper connection.	Ensure the C-type cable is securely connected. Try a different USB power adapter or cable.
Touch control is unresponsive.	Foreign object on sensor; internal issue.	Ensure the touch sensor area is clean and dry. If the issue persists, contact customer support.

## 9. SPECIFICATIONS

---

Feature	Detail
Model Number	LED5WCHTBL-DSKJOY
Wattage	5 Watts
Light Source Type	LED
Battery Type	1800mAh Lithium-Ion (Rechargeable)
Battery Backup	Up to 10 hours (in low mode)
Charging Time	Approx. 4-5 hours
Dimming	3-Step Dimming
Switch Type	Touch Sensor
Material	Acrylonitrile Butadiene Styrene (ABS)
Product Dimensions (D x W x H)	9D x 11.5W x 20H Centimeters
Item Weight	0.23 Kilograms

Feature	Detail
Color	White
Indoor/Outdoor Usage	Indoor

## 10. WARRANTY

---

The Crompton DeskJoy 5W Rechargeable LED Table Lamp comes with a **One Year Manufacturer's Warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, unauthorized repairs, or normal wear and tear. Please retain your purchase receipt for warranty claims.

## 11. SUPPORT

---

For any queries, technical assistance, or warranty claims, please contact Crompton customer support. Refer to the product packaging or the official Crompton website for the most up-to-date contact information.

### **Crompton Greaves Consumer Electricals Limited**

05GBD, Godrej Business District, Pirojshanagar, Vikhroli (West), Mumbai, Maharashtra- 400079