



[Manuals.plus](#) /

› [AGEYOU](#) /

› AGEYOU Portable Handheld Mini Fan Instruction Manual

## AGEYOU X008

# Portable Handheld Mini Fan Instruction Manual

Brand: AGEYOU | Model: X008

### 1. PRODUCT OVERVIEW

The AGEYOU Portable Handheld Mini Fan (Model X008) is a versatile personal cooling device designed for portability and powerful performance. Featuring a brushless motor and a 4000mAh rechargeable battery, it offers adjustable wind speeds from 1 to 100, controlled via an AI digital display. Its compact design and multiple charging methods make it ideal for various indoor and outdoor activities.



Image: The AGHEYOU Portable Handheld Mini Fan in black, held in a hand, showcasing its sleek design and digital display.

## 2. SETUP

### 2.1 Initial Charging

Before first use, fully charge the fan. The fan is equipped with a 4000mAh battery and supports 5V-2A fast charging. A full charge takes approximately 2.5-3 hours.

- Connect the provided USB connection cable (1.8 feet) to the fan's charging port.
- Connect the other end of the cable to a compatible power source such as a regular USB socket, laptop, mobile power supply, or car charger.

- The digital display will indicate charging status and remaining power.

# Multiple Charging Methods

Fully Charged in as Fast as 3 Hours



Image: Illustration showing various charging methods for the fan, including wall charger, laptop, power bank, and car charger.

## 2.2 Attaching Lanyard

The mini fan comes with two types of anti-lost lanyards for convenient carrying. Attach the desired lanyard to the designated loop on the fan's handle.

## 3. OPERATING INSTRUCTIONS

### 3.1 Power On/Off

To power on the fan, slide the power button located on the side of the handle. To power off, slide the button back to its original position.




Image: A visual guide demonstrating the single-button control for powering on the fan by sliding a switch.

### 3.2 Adjusting Wind Speed

The fan features 100 adjustable wind speed levels. Use the touch controls on the digital display to increase or decrease the wind speed. The display shows the current wind speed gear.

### 3.3 Anti-Touch Lock Function

The fan is equipped with an anti-touch locking button to prevent accidental changes to settings. Refer to the digital display for the lock icon and instructions on how to activate/deactivate this feature.

### 3.4 Usage Modes

The fan's design allows for versatile use:

- **Handheld Fan:** Use it directly in your hand for personal cooling.
- **Desk Fan:** The fan can be angled and placed on a flat surface for hands-free operation.
- **Neck Fan:** Utilize the lanyard to wear the fan around your neck, directing airflow for continuous cooling.

Your browser does not support the video tag.

Video: An official product video demonstrating the AGEYOU Portable Handheld Mini Fan's features, including its powerful airflow, compact size, and various usage modes (handheld, desk, neck fan).

## 4. MAINTENANCE

### 4.1 Cleaning

To maintain optimal performance, regularly clean the fan. Use a soft, dry cloth to wipe the exterior. For the air intake and outlet grilles, use a soft brush or compressed air to remove dust and debris. Do not use liquid cleaners or immerse the fan in water.

### 4.2 Battery Care

To prolong battery life, avoid fully discharging the battery frequently. Recharge the fan when the digital display indicates low power. Store the fan in a cool, dry place when not in use for extended periods.

## 5. TROUBLESHOOTING

### 5.1 Fan Not Turning On

- Ensure the power switch is fully in the "On" position.
- Check the battery level on the digital display. If low, charge the fan.
- Verify the charging cable is securely connected and the power source is active.

### 5.2 Weak Airflow

- Increase the wind speed using the touch controls on the digital display.
- Check for any obstructions in the air intake or outlet grilles and clean if necessary.
- Ensure the battery is sufficiently charged, as low power can affect performance.

### 5.3 Digital Display Not Working

- Try turning the fan off and on again.
- Ensure the fan is charged.
- If the issue persists, contact customer support.

## 6. SPECIFICATIONS

Feature	Detail
Brand	AGEYOU
Model Name	X008
Color	Black
Power Source	Battery Powered
Battery Capacity	4000mAh (included)
Charging Time	2.5-3 hours (with 5V-2A fast charging)
Operating Time	3-15 hours (depending on speed)
Number of Speeds	100
Maximum Wind Speed	Up to 10m/s
Maximum Fan Speed	Up to 20000 RPM
Control Method	Touch
Product Dimensions	2.4"D x 2.5"W x 6.3"H
Item Weight	9.6 ounces
Special Feature	AI Digital Display, Anti-touch Function, Brushless Motor

## 7. WARRANTY AND SUPPORT

AGEYOU is committed to providing quality products and customer satisfaction. If you encounter any problems during use, please do not hesitate to contact us. Our customer service team is ready to assist you and ensure a cool experience with your fan.

For support, please refer to the contact information provided with your product packaging or visit the official AGEYOU website.