

## Campingaz Sigma 2 Cook

# Campingaz Plancha Sigma 2 Cook (Model 2217167) Instruction Manual

*Your guide to safe and efficient operation.*

## 1. INTRODUCTION

Thank you for choosing the Campingaz Plancha Sigma 2 Cook. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your new gas griddle. Please read these instructions carefully before use and retain them for future reference.



Image: The Campingaz Plancha Sigma 2 Cook in its closed position, showcasing its compact design and control knobs.

## 2. IMPORTANT SAFETY INFORMATION

**WARNING: For outdoor use only. Do not use in an enclosed space. Read all instructions before operating this appliance.**

- Always ensure adequate ventilation when operating the plancha.
- Keep children and pets away from the appliance during use.
- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.

- Check for gas leaks regularly using a soapy water solution, never an open flame.
- Ensure the gas hose is not kinked or damaged and is kept away from hot surfaces.
- Always turn off the gas supply at the cylinder after use.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

## **3. SETUP AND ASSEMBLY**

---

### **3.1 Unpacking**

Carefully remove all components from the packaging. Verify that all parts listed in the package contents are present and undamaged.

### **3.2 Gas Connection**

1. Ensure the gas cylinder valve is closed before connecting.
2. Connect the gas hose to the appliance's gas inlet. Tighten securely by hand, then with a wrench if necessary, but do not overtighten.
3. Connect the other end of the hose to the pressure regulator, then to the gas cylinder. Ensure all connections are tight.
4. Perform a leak test: Apply a soapy water solution to all gas connections. Bubbles indicate a leak. If a leak is detected, close the gas supply, tighten connections, and re-test. Do not use the appliance if a leak persists.



Image: The Plancha Sigma 2 Cook with its lid open, revealing the cooking surface.

## 4. OPERATING INSTRUCTIONS

### 4.1 Ignition

1. Open the gas cylinder valve.
2. Push and turn one of the control knobs to the high position (usually indicated by a larger flame symbol).
3. Press the electronic ignition button (lightning bolt symbol) repeatedly until the burner ignites. You should hear a clicking sound and see a flame.
4. If the burner does not ignite within 5 seconds, turn the control knob off, wait 5 minutes, and repeat the ignition process.
5. Once ignited, adjust the flame to the desired cooking temperature using the control knob.
6. Repeat for the second burner if dual-zone cooking is desired.

### 4.2 Cooking

The enamelled cast iron cooking surface provides even heat distribution. The integrated cooking lid with thermometer allows for both direct grilling and indirect cooking/baking. Monitor the temperature using the lid thermometer.



Image: An internal view of the Plancha Sigma 2 Cook demonstrating indirect cooking with the lid closed, showing heat circulation and a thermometer.

#### 4.3 Shutting Down

1. Turn all control knobs to the 'OFF' position.
2. Close the gas cylinder valve.
3. Allow the appliance to cool completely before cleaning or moving.

### 5. MAINTENANCE AND CLEANING

#### 5.1 After Each Use

- Once the plancha has cooled, scrape off any food residue from the cooking surface using a non-abrasive scraper.
- Wipe the cooking surface with a damp cloth. For stubborn residue, use warm soapy water.
- Empty and clean the grease collection tray. This tray is located at the front of the appliance.



Image: A close-up view of the removable grease collection tray, designed for easy cleaning.

## 5.2 Periodic Maintenance

- Inspect the gas hose for cracks, cuts, or abrasions. Replace if damaged.
- Clean the burner ports if they become clogged. Refer to the diagram of the burners for location.



Image: An overhead view showing the two Blue Flame burners, illustrating their design for even heat distribution.

## 6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Burner does not ignite	No gas supply; Clogged burner port; Faulty igniter	Check gas cylinder and connections; Clean burner ports; Contact customer support
Uneven heating	Clogged burner ports; Incorrect gas pressure	Clean burner ports; Ensure correct pressure regulator is used
Gas leak smell	Loose connections; Damaged hose	Immediately turn off gas. Perform leak test. Tighten connections or replace hose.

## 7. TECHNICAL SPECIFICATIONS

- Model:** Campingaz Plancha Sigma 2 Cook (2217167)
- Burner Technology:** Blue Flame burner
- Total Power:** 6 kW
- Number of Burners:** 2
- Cooking Surface Dimensions:** 58 x 36 cm (1000 cm<sup>2</sup>)
- Gas Consumption:** 437 g/h
- Ignition Type:** Electronic
- Lid Features:** Integrated thermometer


- **Operating Pressure:** 50 mbar
- **Dimensions (Closed):** 65 x 56 x 31 cm
- **Dimensions (Open):** 65 x 58 x 56 cm
- **Weight:** 25 kg
- **Material:** Steel, Enamelled Cast Iron (cooking surface)

## 8. WARRANTY AND CUSTOMER SUPPORT

For warranty information, technical assistance, or to purchase replacement parts, please refer to the official Campingaz website or contact your local dealer. Keep your proof of purchase for warranty claims.

For further assistance, please visit: [www.campingaz.com](http://www.campingaz.com)

### Related Documents - Sigma 2 Cook

	<p><a href="#"><u>Campingaz Plancha EX Series Assembly Instructions</u></a></p> <p>Comprehensive assembly instructions for the Campingaz Plancha EX, EXB, and EX Extra gas planchas on carts. Includes step-by-step guidance with detailed diagrams and part lists.</p>
	<p><a href="#"><u>Campingaz Plancha Sigma 2, 2-2 Cook, 2 Pro Spare Parts and Overview</u></a></p> <p>An overview of the Campingaz Plancha Sigma 2, 2-2 Cook, and 2 Pro models, along with a detailed spare parts list including reference numbers and compatibility information.</p>
	<p><a href="#"><u>Mode d'emploi Campingaz Plancha L, LX, EX, EXB</u></a></p> <p>Ce manuel d'utilisation fournit des instructions complètes pour l'assemblage, l'utilisation sécuritaire et l'entretien des planchas Campingaz, couvrant les modèles Plancha L, Plancha LX, Plancha EX et Plancha EXB.</p>
	<p><a href="#"><u>Campingaz 4 Series Classic LS Gas Barbecue User Manual</u></a></p> <p>User manual for the Campingaz 4 Series Classic LS Gas Barbecue, providing safety instructions, usage guidelines, and maintenance information for outdoor use.</p>

