

Manuals.plus /

› SKMEI /

› SKMEI 9350 Quartz Watch User Manual

SKMEI 9350


SKMEI 9350 Quartz Watch User Manual

Model: 9350BKBK

INTRODUCTION

Thank you for choosing the SKMEI 9350 Quartz Watch. This manual provides detailed instructions for the proper setup, operation, and maintenance of your new timepiece. Please read this manual thoroughly to ensure optimal performance and longevity of your watch.

KEY FEATURES



This image highlights the primary features of the SKMEI 9350 watch, including its analog display, round dial shape, date and week functions, stainless steel strap, and 30-meter water resistance.

- **Display Type:** Analog
- **Movement:** Quartz for precise timekeeping
- **Case Material:** Durable Zinc Alloy
- **Crystal Material:** Scratch-resistant Glass
- **Band Material:** Stainless Steel
- **Functions:** Time, Date, Week, 24-hour format, Stopwatch
- **Water Resistance:** 30 Meters (3 ATM)

SETUP

1. Setting the Time

1. Pull the crown out to the second click position.
2. Rotate the crown to set the hour and minute hands to the correct time. Ensure the 24-hour sub-dial aligns correctly if setting AM/PM.
3. Push the crown back into the normal position to start the watch.

2. Setting the Date and Week

1. Pull the crown out to the first click position.
2. Rotate the crown clockwise or counter-clockwise (depending on the specific model's mechanism) to adjust the date and week indicators.
3. Once the correct date and week are displayed, push the crown back into the normal position.


3. Adjusting the Watch Band



This diagram illustrates the physical dimensions of the watch, including the case width, case thickness, and strap width, which are important for band adjustment.

The stainless steel band is adjustable. For optimal comfort, it is recommended to have the band adjusted by a professional jeweler or watch repair service. The band width is 21.5mm.

OPERATING INSTRUCTIONS



This image provides a detailed view of the watch's multifunctional display, including the main time hands and the various sub-dials for date, week, and 24-hour format.

1. Reading the Time

The watch features a traditional analog display with hour, minute, and second hands. The main dial indicates the current time.

2. Using the Multifunctional Display

- **Date Sub-dial:** Displays the current day of the month.
- **Week Sub-dial:** Indicates the current day of the week (e.g., MON, TUE).
- **24-Hour Sub-dial:** Shows the time in a 24-hour format, useful for distinguishing between AM and PM.

3. Stopwatch Function

The SKMEI 9350 includes a stopwatch function. Specific operation details for starting, stopping, and resetting the stopwatch may vary slightly. Typically, push buttons on the side of the watch (other than the crown) are used for these functions. Refer to the quick start guide included with your watch for precise button assignments.



This image demonstrates the luminous function of the watch, where the hands and hour markers glow in low-light conditions for improved visibility.

4. Luminous Display

The watch hands and hour markers are treated with a luminous material, allowing for time readability in low-light conditions after exposure to light.

MAINTENANCE

1. Cleaning

Wipe the watch case and band regularly with a soft, dry cloth to remove dust and dirt. For stainless steel, a slightly damp cloth can be used, followed by a dry cloth. Avoid using chemical cleaners or abrasive materials.

2. Battery Replacement

The watch is powered by a quartz movement, which requires a battery. When the watch stops or the second hand begins to skip, it indicates a low battery. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and water resistance.

3. Storage

When not in use, store your watch in a cool, dry place away from direct sunlight, extreme temperatures, and strong magnetic fields. Keeping it in its original box or a watch case can help protect it from scratches and impacts.



This image shows the back of the watch, detailing the case back which often includes information about the model and water resistance.

WATER RESISTANCE GUIDELINES

The SKMEI 9350 watch is rated for 30 meters (3 ATM) of water resistance. This means it is suitable for daily use and can withstand splashes, rain, and brief immersion in water. However, it is **not recommended** for swimming, diving, or showering, as prolonged exposure to water pressure or hot water can compromise the seals.

- Do not operate the crown or push buttons when the watch is wet or submerged.
- Avoid exposing the watch to steam or hot water, as this can damage the water-resistant seals.
- If the watch is exposed to saltwater, rinse it gently with fresh water and dry it thoroughly.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch stops or runs intermittently	Low battery	Replace battery (professional service recommended).
Time is incorrect	Crown pulled out; time not set correctly	Push crown in fully; reset time as per instructions.
Date/Week not changing	Date/Week not set correctly; operating crown during restricted hours	Reset Date/Week; avoid setting between 9 PM and 3 AM.
Condensation inside watch	Temperature change; water resistance compromised	Seek professional inspection immediately to prevent damage.

SPECIFICATIONS

Feature	Detail
Model Number	9350BKBK
Movement	Quartz
Display Type	Analog
Case Material	Zinc Alloy
Case Diameter	42 Millimeters
Case Thickness	12.2 Millimeters
Crystal Material	Glass
Band Material	Stainless Steel
Band Width	21.5 Millimeters
Clasp Type	Buckle
Water Resistance Depth	30 Meters (3 ATM)
Item Weight	133.2 Grams
Functions	Time, Date, Week, 24-hour display, Stopwatch

WARRANTY AND SUPPORT

Warranty Information

Your SKMEI 9350 watch comes with a **9-month Manufacturer Warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage resulting from improper use, accidents, unauthorized repairs, or normal wear and tear.

Customer Support

For any service-related inquiries, feedback, or warranty claims, please contact the Skmei India Helpline:

Helpline Number: 1800-889-6251

Operating Hours: Monday to Saturday, 9:00 AM to 6:00 PM (IST)

Please have your purchase receipt and watch model number (9350BKBK) available when contacting support.