

[Manuals.plus](#) /

› [Legami](#) /

› Legami Meow Power Bank User Manual

Legami Meow

Legami Meow Power Bank User Manual

Model: Meow (B0F2N4JMYR)

INTRODUCTION

This manual provides essential information for the safe and efficient use of your Legami Meow Power Bank. Please read this manual thoroughly before using the device to ensure proper function and longevity.

PRODUCT OVERVIEW

The Legami Meow Power Bank is a portable, rechargeable battery designed to provide power to your smartphone and other compatible devices on the go. Its compact size and high-quality lithium battery make it an ideal companion for daily use, ensuring your devices stay charged when you need them most.



Figure 1: Front view of the Legami Meow Power Bank, showcasing its cat-inspired design.



Figure 2: The Legami Meow Power Bank shown with its included USB-A to Micro USB charging cable.

PACKAGE CONTENTS

- Legami Meow Power Bank
- USB-A to Micro USB Charging Cable (for charging the power bank)
- User Manual (this document)





Figure 3: The Legami Meow Power Bank as it appears in its retail packaging.

SETUP

Initial Charging

1. Connect the included USB-A to Micro USB cable to the power bank's input port.

2. Plug the USB-A end of the cable into a compatible USB power adapter (not included) or a computer's USB port.
3. Allow the power bank to fully charge before first use. Charging indicators (if present) will show charging status.

Note: A full charge may take several hours depending on the power source.

OPERATING INSTRUCTIONS

Charging Your Device

1. Use your device's original charging cable (USB-C, Lightning, Micro USB, etc.) to connect your smartphone or other compatible device to the power bank's output port.
2. The power bank should automatically begin charging your device. Some power banks may require a button press to initiate charging.
3. Disconnect your device once it is fully charged or when you no longer need to charge it.

Recharging the Power Bank

When the power bank's charge is low, recharge it using the steps outlined in the "Initial Charging" section.

MAINTENANCE

- Keep the power bank dry and away from moisture.
- Avoid extreme temperatures (hot or cold).
- Do not drop, disassemble, or attempt to repair the power bank yourself.
- Clean the surface with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- Store in a cool, dry place when not in use for extended periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Power bank not charging	Cable not connected properly; faulty cable; power source issue.	Ensure cable is securely connected. Try a different cable or power adapter.
Device not charging from power bank	Power bank is depleted; incorrect cable; device incompatibility.	Recharge the power bank. Use your device's original charging cable. Ensure device is compatible.
Slow charging	Low output current from power bank; high power consumption by device.	Ensure the power bank is fully charged. Close unnecessary apps on your device.

SPECIFICATIONS

- Brand:** Legami
- Model:** Meow
- Battery Capacity:** 5000 mAh
- Battery Type:** High-quality Lithium Battery
- Connector Type:** Multi-cable (USB-A to Micro USB included)
- Number of Ports:** 1
- Compatible Devices:** Smartphones
- Material:** ABS, PC

Dimensions: Approximately 4 cm (diameter) x 9.5 cm (height)

© 2025 Legami. All rights reserved.
For further assistance, please visit the official Legami website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question