Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Seizeen B0F2N5D9YL

ENYOPRO 24V Electric Go Kart Instruction Manual

Brand: Seizeen | Model: B0F2N5D9YL

1. Introduction and Overview

Thank you for choosing the ENYOPRO 24V 7Ah Electric Go Kart. This officially licensed McLaren Go Cart is designed to provide an authentic and thrilling racing experience for children aged 6 to 12 years. With its sleek design, adjustable features, and robust safety mechanisms, it ensures both fun and peace of mind. This manual will guide you through the assembly, operation, and maintenance of your new electric go-kart.



Figure 1: Front view of the ENYOPRO 24V Electric Go Kart.

2. Safety Information

Your child's safety is paramount. Please read and adhere to all safety warnings and instructions before operating the go-kart.

- **Age and Weight Limits:** Recommended for ages 6 years and up. Maximum weight capacity is 132 lbs (60 kg). Do not exceed this limit.
- **Adult Supervision:** Constant adult supervision is required during operation.
- **Protective Gear:** Always ensure the rider wears a helmet, knee pads, and elbow pads.
- **Operating Environment:** Use on flat, dry, and paved surfaces only. Avoid slopes, uneven terrain, sand, gravel, or wet conditions. Do not operate near streets, cars, or bodies of water.
- **Battery Safety:** Only use the provided charger. Do not modify the electrical system. Keep the battery away from heat sources and flammable materials.
- **Seat Belt:** Always ensure the 2-point safety belt is securely fastened before riding.

- **Braking:** Familiarize the rider with the electronic braking system. Ensure they understand how to stop the go-kart safely.

California Proposition 65 Warning: No Warning Applicable.

3. Product Features

The ENYOPRO Electric Go Kart is packed with features designed for performance and fun:

- **Official McLaren Licensed Design:** Authentic F1 styling with iconic black and orange color scheme.
- **Adjustable Steel Frame:** Features 3 length settings to accommodate growing children (ages 6+ up to 4.9ft tall).
- **Safe & Controlled Drifting Performance:** Specialized PA rear wheels and electronic brake system for exciting yet safe drifts. Anti-slip TPR front tires ensure solid grip.
- **Powerful 24V System:** Dual 200W motors deliver speeds up to 7.5 MPH (12 km/h). Powered by a 24V 7Ah rechargeable battery, offering 60-90 minutes of continuous playtime.
- **Real Driving Experience:** Intuitive gas foot pedal for smooth acceleration, forward/reverse functionality, and a battery level display.
- **Exciting LED Lights:** Cool orange ambient lighting and functional red tail lights for enhanced visibility and fun during evening rides.
- **Portable & Space-Saving Design:** Folds down to 38.6 inches (98 cm) for easy transport and storage.



Figure 2: The go-kart's powerful dual 200W motors and 24V 7Ah battery provide excellent performance, reaching speeds up to 7.5 MPH for 60-90 minutes of playtime.



Figure 3: The go-kart features cool orange ambient lighting and red tail lights for exciting night driving and enhanced visibility.

4. What's Included (Package Contents)

Upon unboxing, please verify that all components are present:

- 24V McLaren F1 Drift Go-Kart Body
- Safety Flag
- 24V 600mA Charger
- Instruction Manual
- Assembly Tools & Accessories (Wheels, Steering Wheel, Rear Fender, etc.)

5. Setup and Assembly

The ENYOPRO Go Kart requires minimal assembly. Follow these steps to get your go-kart ready for action:

1. **Unboxing:** Carefully remove all components from the packaging. Lay them out to ensure all parts are accounted for.
2. **Wheel Installation:** Attach the wheels to the axles. Ensure they are securely fastened using the provided hardware. The hubcap covers can then be snapped into place.
3. **Steering Wheel Assembly:** Connect the steering column to the main frame and then attach the steering wheel. Ensure it is firmly secured for safe operation.
4. **Rear Fender Attachment:** Install the orange rear fender to the back of the go-kart.
5. **Safety Flag:** Insert the safety flag into its designated slot at the rear of the go-kart.
6. **Initial Charge:** Before first use, fully charge the 24V battery for 8-12 hours using the provided charger. The charging port is typically located near the battery compartment.

The go-kart's frame is pre-built, simplifying the assembly process. The adjustable length feature allows you to extend or shorten the frame to fit your child's height as they grow. This adjustment is typically done by releasing locking buttons and sliding the front section of the frame.



Figure 4: The go-kart features a 3-level length adjustment to accommodate different rider heights, ensuring comfortable and safe use as

your child grows.

6. Operating Instructions

Familiarize yourself and your child with the controls before riding.

1. **Power On/Off:** Locate the power switch (usually a red button) and press it to turn the go-kart on.
2. **Forward/Reverse:** Use the forward/reverse switch to select the desired direction of travel.
3. **Acceleration:** Press the gas foot pedal to accelerate. Release the pedal to slow down.
4. **Braking:** The electronic braking system activates when the gas pedal is released or when the brake pedal is pressed. Ensure your child understands how to use the brake pedal for immediate stops.
5. **Steering:** Use the steering wheel to control the direction of the go-kart.
6. **Drifting:** The specialized PA rear wheels allow for controlled drifting. Practice in an open, safe area.
7. **LED Lights:** Use the light switch to turn on the orange ambient lights and red tail lights for enhanced visibility and fun, especially in low-light conditions.
8. **Battery Display:** Monitor the battery level display to know when recharging is needed.



Figure 5: Key controls of the go-kart, including the gas and brake pedals, forward/reverse switch, light switch, and battery display.

Video 1: Official product video demonstrating the 24V McLaren Electric Go Kart in action, highlighting its features and operation for kids aged 6-12.

7. Maintenance

Regular maintenance ensures the longevity and safe operation of your go-kart.

- **Charging:** Recharge the battery after each use. Do not overcharge. Store the go-kart with a fully charged battery if not in use for extended periods.
- **Cleaning:** Wipe down the go-kart with a damp cloth. Avoid using harsh chemicals or abrasive cleaners. Do not spray water directly onto electrical components.
- **Storage:** Store the go-kart in a dry, cool place away from direct sunlight and moisture. If folding for storage, ensure all locking mechanisms are engaged.
- **Inspection:** Periodically check all nuts, bolts, and fasteners to ensure they are tight. Inspect tires for wear and tear.

8. Troubleshooting

If you encounter issues with your go-kart, refer to the following common troubleshooting tips:

- **Go-Kart Not Moving:** Check if the power switch is ON. Ensure the battery is fully charged. Verify all electrical connections are secure.
- **Slow Speed/Short Run Time:** The battery may not be fully charged or is nearing the end of its lifespan. Ensure the charging time is sufficient (8-12 hours). Check for excessive weight on the go-kart.
- **Lights Not Working:** Check the light switch position. Ensure the battery has sufficient charge.
- **Unusual Noises:** Inspect wheels and axles for any obstructions or loose parts.

For persistent issues or complex problems, please contact customer support.

9. Specifications

Feature	Detail
Main Material	Steel Frame + PP Seat + PA/TPR Wheels
Product Dimensions	49.6 x 28.8 x 21.3 inches (Maximum Size)
Foldable Size	38.6"x28.8"x21.3"
Item Weight	70.5 pounds (Net Weight: 32kg)
Weight Capacity (Max)	132 lbs
Speed	7.5 mph (12 km/h)
Battery Type	24V 7Ah
Charge Time	8-12 hours
Running Time	60-90 minutes
Recommended Ages	6+ years
Manufacturer	ENYOPRO
Country of Origin	China

10. Warranty and Support

Your ENYOPRO Electric Go Kart comes with options for extended protection and dedicated customer support.

- **Protection Plans:** Consider purchasing a 2-Year Protection Plan or the Complete Protect plan for comprehensive coverage.
- **Returns:** The product is eligible for 30-day easy returns.
- **Customer Support:** For any questions, concerns, or assistance with troubleshooting, please contact Seizeen customer support. You can find contact information on the official Seizeen store page or through your purchase platform.

For more information, visit the Seizeen Store.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F2N5D9YL

More documents and user manuals: **https://manuals.plus/**