

[Manuals.plus](#) /

› [GAOMON](#) /

› GAOMON Outdoor Recliner Chair User Manual

GAOMON TD-P-34W8JKNL-NEW-OR22B

GAOMON Outdoor Recliner Chair User Manual

Model: TD-P-34W8JKNL-NEW-OR22B

Brand: GAOMON

1. INTRODUCTION

Thank you for choosing the GAOMON Outdoor Recliner Chair. This chair is designed to provide comfort and relaxation for your outdoor spaces. It features an ergonomically designed wider and deeper seat, a linked adjustable backrest and footrest, a convenient flip-up side table, and durable, weather-resistant materials. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure you get the most out of your new recliner chair.



Image 1.1: GAOMON Outdoor Recliner Chair in upright and reclined positions.

2. SAFETY INFORMATION

Please read and understand all safety warnings and instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- **Load Capacity:** Do not exceed the maximum load capacity of **400 pounds (181 kg)**. Overloading can cause structural failure and injury.
- **Assembly:** Exercise caution during assembly. Some parts may have sharp edges. Keep small parts and hardware away from children and pets to prevent choking hazards.
- **Stability:** Ensure the chair is placed on a flat, stable surface before use. Do not rock or stand on the chair.
- **Moving Parts:** Be aware of the linked reclining mechanism. Keep hands and fingers clear of moving parts when adjusting the backrest and footrest to prevent pinching.
- **Children:** Children should be supervised when near or using the recliner chair.

- **Weather Conditions:** While designed for outdoor use, prolonged exposure to extreme weather conditions (heavy rain, snow, strong winds) may reduce the product's lifespan. Consider covering or storing the chair during harsh weather.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

Item	Description	Quantity
A	Main Chair Frame (Left & Right Sides)	1 Set
B	Backrest Assembly	1
C	Seat Base	1
D	Footrest Assembly	1
E	Seat Cushion	1
F	Backrest Cushion	1
G	Headrest Cushion	1
H	Lumbar Pillow	1
I	Hardware Pack (Bolts, Washers, Nuts, Allen Wrench)	1 Set
J	Instruction Manual	1

4. ASSEMBLY INSTRUCTIONS

Assembly typically takes approximately 30 minutes with two people. While the process is designed to be straightforward, careful attention to detail is recommended. Lay out all components on a soft, clean surface to prevent scratches.

Tools Required:

- Included Allen Wrench (I)
- Phillips Head Screwdriver (not included, may be needed for some fasteners)

Assembly Steps:

1. **Identify Parts:** Refer to the 'Package Contents' section and the product dimension image to identify each component. It is crucial to distinguish between left and right frame pieces.

PRODUCT DIMENSION



Image 4.1: Product Dimensions for part identification.

- Assemble Main Frame:** Connect the left and right main chair frame sides (A) using the appropriate crossbars and hardware from the Hardware Pack (I). Do not fully tighten bolts until all connections are made.
- Attach Seat Base:** Secure the Seat Base (C) to the assembled main frame. Ensure proper alignment before tightening bolts.
- Install Backrest and Footrest:** Attach the Backrest Assembly (B) and Footrest Assembly (D) to the main frame. Note that the backrest and footrest are designed to move in sync. Ensure the reclining mechanism connects properly.



LINKED RECLINING MECHANISM

BACKREST & FOOTREST MOVE IN UNISON

Image 4.2: Linked Reclining Mechanism.

5. **Integrate Flip-Up Table:** The flip-up table is built into one of the armrests. Ensure it is correctly aligned and functions smoothly. It operates with a pneumatic piston for easy movement.



INTEGRATED FLIP-UP TABLE

THE PERFECT PLACE FOR YOUR FAVORITE BEVERAGE

Image 4.3: Integrated Flip-Up Table.

- Final Tightening:** Once all components are loosely assembled and aligned, systematically tighten all bolts using the provided Allen Wrench. Do not overtighten.
- Place Cushions:** Position the Seat Cushion (E), Backrest Cushion (F), Headrest Cushion (G), and Lumbar Pillow (H) onto the chair. The cushions are removable for easy cleaning.



DESIGNED FOR CONVENIENCE

REMOVABLE CUSHION FOR EASY CLEANING

Image 4.4: Removable Cushion for easy cleaning.

5. OPERATING INSTRUCTIONS

Adjusting the Recline Position:

The GAOMON Outdoor Recliner Chair features an independently adjustable design where the backrest and footrest move in sync. To recline:

1. Locate the recline lever or button on the side of the chair (typically on the right armrest).
2. While seated, push the lever/button and lean back to recline. The footrest will simultaneously rise.
3. Release the lever/button at your desired position to lock the recline. The chair can recline up to a maximum angle of 150 degrees, providing a near-flat position.
4. To return to an upright position, push the lever/button and lean forward.



Image 5.1: Chair in reclined position with flip-up table extended.

Using the Flip-Up Table Tray:

The integrated flip-up table tray is located on the outer arm of the chair, perfect for holding drinks, snacks, or small items.

1. To deploy the table, gently lift the table surface upwards. A pneumatic piston will assist in its smooth movement.
2. Ensure the table is fully extended and stable before placing items on it.
3. To retract the table, gently push it downwards until it locks back into its stored position.

The table dimensions are approximately 9.5 x 10.3 inches.

6. MAINTENANCE AND CARE

Proper maintenance will extend the life and appearance of your GAOMON Outdoor Recliner Chair.

- **Rattan Frame:** The PE rattan is designed to withstand outdoor elements. Clean regularly with a soft cloth dampened

with mild soap and water. Rinse thoroughly with clean water and allow to air dry. Avoid harsh chemicals or abrasive cleaners.




Image 6.1: Detail of the durable PE rattan weave.

- **Cushions:** The removable cushions are made of olefin fabric, which is waterproof, fade-resistant, and wear-resistant. For minor spills, wipe with a damp cloth. For deeper cleaning, remove covers (if applicable) and hand wash with mild soap, then air dry. Do not machine wash or tumble dry. Ensure cushions are completely dry before reattaching to prevent mildew.
- **Steel Frame:** The internal steel frame is powder-coated for rust resistance. Inspect periodically for any signs of rust or damage. If scratches occur, touch up with rust-inhibiting paint.
- **Hardware:** Periodically check all bolts and connections to ensure they remain tight. Retighten as necessary to maintain stability.
- **Storage:** During off-season or prolonged periods of non-use, it is recommended to store the chair in a dry, covered area to protect it from extreme weather and extend its lifespan.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your recliner chair.

- **Issue: Difficulty during assembly, unclear instructions, or unlabeled parts.**
Solution: Carefully review the 'Package Contents' and 'Assembly Instructions' sections. Refer to the product dimension image (Image 4.1) to help identify parts by their shape and size. Ensure all hardware is sorted and matched to the correct steps. If you are unsure about a step, try to visualize the final structure or refer to product images for guidance. Assembly with a second person can significantly ease the process.
- **Issue: Missing hardware or damaged parts upon arrival.**
Solution: Before starting assembly, perform a thorough inventory check against the 'Package Contents' list. If any items are missing or damaged, do not proceed with assembly. Contact GAOMON customer support immediately for replacement parts.
- **Issue: Chair feels unstable or wobbly after assembly.**
Solution: This often indicates that bolts are not fully tightened or parts are misaligned. Go back through the assembly steps, ensuring all connections are secure and all bolts are tightened evenly. Ensure the chair is on a level surface.
- **Issue: Reclining mechanism is stiff or not moving smoothly.**
Solution: Check for any obstructions around the mechanism. Ensure all assembly bolts related to the backrest and footrest are tightened correctly but not overtightened, which could impede movement. A small amount of silicone-based lubricant can be applied to pivot points if needed, but avoid oil-based lubricants that can attract dirt.
- **Issue: Cushions feel slippery or shift during use.**
Solution: While the olefin fabric is designed for durability, some slipperiness can occur. Ensure cushions are properly seated and secured with any ties or straps provided. Anti-slip mats can be placed between the cushion and the chair frame if persistent.

8. SPECIFICATIONS

Feature	Detail
Brand	GAOMON
Model Number	TD-P-34W8JKNL-NEW-OR22B
Product Dimensions (L x W x H)	34.06 x 31.5 x 41.5 inches (86.5 x 80 x 105.4 cm)
Item Weight	51.6 pounds (23.4 kg)
Material	PE Rattan, Powder-Coated Steel Frame, Olefin Fabric Cushions
Color	Grey Rattan + Grey Cushion
Max. Recline Angle	150 degrees
Load-bearing Capacity	400 pounds (181 kg)
Flip-Up Table Size	9.5 x 10.3 inches (24.1 x 26.2 cm)

9. WARRANTY AND CUSTOMER SUPPORT

GAOMON stands behind the quality of its products. For specific warranty information regarding your recliner chair, please refer to the warranty card included in your package or visit the official GAOMON website.

If you have any questions, require assistance with assembly, need replacement parts, or encounter any issues not covered in this manual, please do not hesitate to contact our customer support team. Please have your model number (TD-P-34W8JKNL-NEW-OR22B) and purchase information ready when contacting support.

Customer Support Contact:

Website: www.gaomon.com/support (Example link, please refer to actual product documentation)

Email: support@gaomon.com (Example email, please refer to actual product documentation)

Phone: 1-800-XXX-XXXX (Example number, please refer to actual product documentation)