

[Manuals.plus](#) /

› [Otлонpe](#) /

› Otлонpe Handheld Misting Fan Instruction Manual

Otлонpe OT-P6-FAN

Otлонpe Handheld Misting Fan Instruction Manual

Model: OT-P6-FAN | Brand: Otлонpe

PRODUCT OVERVIEW

The Otлонpe Handheld Misting Fan is a versatile and portable cooling device designed for personal use in various environments, including travel, outdoors, hiking, and camping. It combines powerful airflow with a fine misting function to provide enhanced cooling.

Key features include:

- **Enhanced Cooling Misting Technology:** Dual spray-airflow system with a 35ml water tank and 10-minute mist auto-off.
- **4-High Speed Turbo Cooling Wind:** High-speed motor and 7-blade design for strong airflow across four adjustable speeds.
- **10-Hour Ultra-Long Battery Life:** 4000mAh rechargeable battery providing 3.5-10 hours of operation.
- **3-In-1 Functionality:** Can be used as a handheld, neck-worn, or desk fan with a 1200 adjustable head.
- **Ultra-Portable Foldable Design:** Lightweight (9oz) and folds flat for easy transport.



Figure 1: Otolonpe Handheld Misting Fan in its handheld and folded configurations.

PACKAGE CONTENTS

Please check the package for the following items:

- Otolonpe Handheld Misting Fan (Dark Blue)
- Water Bottle (for refilling mist tank)
- Lanyard
- USB-C Charging Cable
- Instruction Manual (this document)

SETUP AND CHARGING

Initial Charging

Before first use, fully charge the fan. The fan is equipped with a 4000mAh rechargeable battery.

1. Connect the provided USB-C charging cable to the fan's charging port.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer USB port.
3. The LED digital display will show the battery percentage, indicating charging status.
4. A full charge typically takes 3.5-4 hours.




Figure 2: The fan's digital display shows battery level and fan speed.

Filling the Water Tank for Misting Function

The fan features a 35ml water tank for misting. Use clean tap water only. Do not use other liquids.

1. Locate the water tank cap on the side of the fan head.
2. Open the cap.
3. Use the provided small water bottle to carefully fill the water tank.
4. Ensure the tank is not overfilled.
5. Securely close the water tank cap after filling.



Figure 3: Water tank capacity and misting duration.

OPERATING INSTRUCTIONS

Power On/Off and Fan Speed Adjustment

The fan has four adjustable speeds (F1-F4).

1. To turn on the fan, press the power button (usually marked with a power symbol) located on the side of the handle. The fan will start at the lowest speed (F1).
2. Press the power button repeatedly to cycle through the fan speeds: F1 (low), F2 (medium), F3 (high), F4 (turbo).
3. To turn off the fan, press the power button after F4, or press and hold the power button for a few seconds at any speed.
4. The LED display will show the current fan speed (F1-F4).




Figure 4: Fan control buttons for power and mist.

Misting Function

The misting function provides an ultra-fine mist for enhanced cooling.

1. With the fan turned on, press the mist button (usually marked with a water droplet symbol) located next to the power button.
2. The misting function will activate. It has an automatic turn-off function after 10 minutes to conserve water.
3. To turn off the misting function manually, press the mist button again.




Figure 5: The fan's misting function provides instant cooling.

Using the 3-in-1 Design

The fan offers flexible usage modes:

- **Handheld Fan:** Hold the fan by its handle for direct cooling.
- **Neck Fan:** Attach the provided lanyard to the designated loops on the fan handle and wear it around your neck.
- **Desk Fan:** Fold the fan's head 1200 to create a stable base, allowing it to stand on a flat surface for hands-free operation.



Figure 6: Versatile 3-in-1 usage modes.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your Otlonpe Misting Fan.

- **Cleaning:** Use a soft, dry cloth to wipe the exterior of the fan. Do not use abrasive cleaners or immerse the fan in water.
- **Water Tank:** Regularly empty and rinse the water tank with clean water to prevent mineral buildup or mold. Ensure the tank is dry before storing for extended periods.
- **Water Type:** Always use clean tap water for the misting function. Avoid using distilled water, essential oils, perfumes, or other chemicals, as these can clog the misting nozzle or damage internal components.
- **Storage:** When not in use, store the fan in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not turn on.	Low battery; Power button not pressed correctly.	Charge the fan fully. Press the power button firmly.
Mist function not working.	Water tank empty; Misting nozzle clogged; Incorrect liquid used.	Refill water tank. Clean the misting nozzle gently. Use only clean tap water.
Fan makes unusual noise.	Obstruction in fan blades; Internal issue.	Turn off the fan and check for any obstructions. If noise persists, contact customer support.

Problem	Possible Cause	Solution
Battery life is shorter than expected.	Constant use at high speeds/misting; Battery degradation over time.	Reduce fan speed or misting frequency. Ensure full charge before use.

SPECIFICATIONS

- Brand:** Otlonpe
- Model Name:** S-P6 (OT-P6-FAN)
- Color:** Dark blue
- Electric Fan Design:** Wearable Fan
- Power Source:** USB & Battery Powered
- Product Dimensions:** 1.73"D x 3.75"W x 8.15"H
- Special Features:** 4000mAh Rechargeable Battery, Fan with Water Spray Misting Function, 4 Gear Turbo Cooling Wind, 3-In-1 Handheld & Neck & Desk Fan, 1200 Foldable
- Recommended Uses:** Moist Skin, Cooling
- Noise Level:** 45 dB
- Wattage:** 7.5 Watt-hours
- Number of Blades:** 7
- Speed:** 12000 RPM (Max)
- Voltage:** 5 Volts
- Switch Type:** Push Button
- Item Weight:** 9 ounces (0.56 Pounds)
- Included Components:** Water Bottle, Lanyard, USB C Cord, Handheld Misting Fan
- Indoor/Outdoor Usage:** Outdoor, Indoor
- Specification Met:** FCC, CE, Rohs, UKCA
- Control Method:** Touch
- Light Type:** LED Digital Display
- Connector Type:** USB Type C
- Blade Material:** Plastic
- Reusability:** Rechargeable
- Number of Power Levels:** 4
- Batteries:** 1 9V batteries required (included)

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the product packaging or contact Otlonpe customer service directly. Keep your purchase receipt for any warranty claims.

Manufacturer: Otlonpe

Date First Available: April 19, 2025

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question