



Manuals.plus /

› Funsicle /

› Funsicle Type A/C Pool Filter Cartridge Instruction Manual

Funsicle Type A/C

Funsicle Type A/C Pool Filter Cartridge Instruction Manual

Model: Type A/C

INTRODUCTION

This manual provides essential instructions for the proper use, installation, maintenance, and troubleshooting of your Funsicle Type A/C Pool Filter Cartridges. Adhering to these guidelines will ensure optimal performance and longevity of your pool filtration system, contributing to clear and clean pool water.

PRODUCT OVERVIEW

The Funsicle Type A/C Filter Cartridges are designed for efficient filtration in compatible Funsicle pool pump systems. Each cartridge features a pleated design for optimal filtration, effectively trapping dirt, leaves, and other small particles to maintain water clarity. These cartridges are available in a convenient 4-pack, ensuring you have replacements readily available.



Image: Funsicle Type A/C Filter Cartridge 4-Pack packaging, showing four individual cartridges.



Image: A single Funsicle Type A/C Filter Cartridge, highlighting its pleated structure.

COMPATIBILITY

These Funsicle Type A/C Filter Cartridges are compatible with the following Funsicle pump models:

- Funsicle RX1000/1500 & SFX1000/1500 Filter Pumps
- Funsicle CP2000 Filter Pumps

Compatible with



CP2000
SFX1000 & SFX1500



RX1000 & RX1500

Image: Visual representation of Funsicle CP2000, SFX1000 & SFX1500, and RX1000 & RX1500 pump models, indicating compatibility with Type A/C filters.

INSTALLATION INSTRUCTIONS

1. **Turn off the pump:** Before beginning any maintenance, ensure your pool pump is completely turned off and unplugged from the power source to prevent accidental operation.
2. **Locate the filter housing:** Identify the filter housing unit connected to your pool pump system.
3. **Open the filter housing:** Carefully open the filter housing. This usually involves unscrewing a cap or releasing clamps. Refer to your specific pump's manual for detailed instructions on opening the housing.
4. **Remove the old cartridge:** Take out the used filter cartridge. It may be dirty and heavy with trapped debris.
5. **Clean the housing (optional):** Wipe down the inside of the filter housing to remove any accumulated debris or grime.
6. **Insert the new cartridge:** Place a new Funsicle Type A/C Filter Cartridge into the housing. Ensure it sits correctly and securely.

7. **Close the filter housing:** Securely close the filter housing, ensuring all seals are properly seated to prevent leaks.
8. **Restart the pump:** Plug in and turn on your pool pump. Check for any leaks around the filter housing.




Image: A person demonstrating the process of changing a filter cartridge in a Funsicle pool pump system.

MAINTENANCE AND REPLACEMENT

For optimal pool water clarity and pump efficiency, it is recommended to replace each Funsicle Type A/C Filter Cartridge every 2 weeks. Depending on pool usage and debris levels, you may rinse the cartridge between replacements to extend its effective life. However, regular replacement is crucial for maintaining peak filtration performance.

- **Regular Inspection:** Periodically check the filter cartridge for visible signs of wear, tear, or excessive clogging.
- **Rinsing:** To rinse a cartridge, remove it from the pump and spray it thoroughly with a garden hose to dislodge trapped debris from the pleats. Do not use high-pressure washers as they can damage the filter material.
- **Replacement Schedule:** Even with rinsing, the filter material will degrade over time and lose its effectiveness. Adhere to the recommended 2-week replacement schedule for best results.

TROUBLESHOOTING COMMON ISSUES

- **Reduced Water Flow:** If you notice a decrease in water flow from your pump, the filter cartridge may be clogged. Try rinsing or replacing the cartridge.
- **Cloudy Pool Water:** Cloudy water often indicates that the filter is not effectively removing particles. Ensure the cartridge is clean and properly installed. If the problem persists, replace the cartridge. Also, check pool chemical balance.
- **Leaks from Filter Housing:** If water is leaking from the filter housing, ensure the cap is securely tightened and that the O-ring or gasket is properly seated and not damaged. Replace any damaged seals.

SPECIFICATIONS

Product Name:	Funsicle Type A/C Filter Cartridge
Model Type:	Type A/C
Quantity:	4-Pack
Replacement Frequency:	Every 2 weeks (recommended)
Brand:	Funsicle
Manufacturer:	Polygroup North America, Inc.
ASIN:	B0F2RDHHPR
GTIN/UPC:	195545001312

WARRANTY AND SUPPORT

For specific warranty information and customer support regarding your Funsicle Type A/C Filter Cartridges or compatible Funsicle pool pump systems, please refer to the documentation included with your original pump purchase or visit the official Funsicle website. You may also contact Polygroup North America, Inc. directly for assistance.

Manufacturer: Polygroup North America, Inc.

Brand Store: Visit the Funsicle Store on Amazon

