

[Manuals.plus](#) /

> [VINGLI](#) /

> VINGLI 35.4 inch Natural Wood Entryway Console Table Instruction Manual

VINGLI RZER232

VINGLI 35.4 inch Natural Wood Entryway Console Table Instruction Manual

Model: RZER232

1. INTRODUCTION

Thank you for choosing the VINGLI 35.4 inch Natural Wood Entryway Console Table. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.

Safety Information

- Please ensure the table is not overloaded to maintain its stability. The maximum weight capacity is 100 lbs.
- Always follow the assembly instructions carefully to avoid any potential hazards.
- Keep all small parts and packaging materials away from children during assembly.
- Periodically check all connections to ensure they remain tight.

2. PRODUCT OVERVIEW

The VINGLI Natural Wood Entryway Console Table is designed for versatility and durability, crafted from solid pine wood with a natural finish. Its compact design makes it suitable for various spaces within your home.

Key Features

- **Premium Solid Wood Craftsmanship:** Constructed from pine wood with a clean, non-toxic finish.
- **Classic Charm and Beauty:** Elegant natural wood finish complements various decorative aesthetics.
- **Versatile Applications:** Functions as an entryway table, sofa table, plant stand, or display table.
- **Ideal Dimensions:** Sized at 35.49"W x 11.89"D x 31.59"H, suitable for both large and small spaces.



Image 2.1: The VINGLI 35.4 inch Natural Wood Entryway Console Table, fully assembled and styled in an entryway setting.

3. SETUP AND ASSEMBLY

This console table is designed for ease of assembly, requiring no specialized expertise. Each component is numbered, and clear instructions are provided to guide you through the process.

Included Components

- Tabletop (A)
- Legs (B x 2)
- Assembly Guide
- Installation Tool (Hex Key/Wrench)
- Hardware Pack (Screws, dowels, etc.)

Assembly Steps

1. Unpack all components and verify against the parts list in the included Assembly Guide.
2. Attach the legs (B) to the tabletop (A) using the provided hardware. Ensure all screws are aligned and tightened securely.
3. Once assembled, gently place the table upright on a level surface.
4. Confirm stability by gently rocking the table. If unstable, re-check all connections.



Image 3.1: A diagram illustrating the dimensions of the VINGLI console table: 35.49 inches wide, 11.89 inches deep, and 31.59 inches high.



Image 3.2: Close-up view highlighting the natural pine wood material and the reliable support structure of the table legs.

4. USAGE GUIDELINES

The VINGLI console table offers versatile functionality for various areas of your home.

Recommended Uses

- **Entryway Table:** Place in your entrance or hallway for keys, mail, or decorative items.
- **Sofa Table:** Position behind a couch for easy access to drinks, books, or remote controls.
- **Plant Stand:** Display potted plants and greenery.
- **Display Table:** Showcase decorative accents, photos, or small collections.

Ensure the table is placed on a flat, stable surface. Avoid placing excessively heavy items on the table, as the maximum weight capacity is 100 lbs.



Image 4.1: The console table positioned behind a white sofa, holding a bowl of oranges and decorative items.



Image 4.2: The console table serving as a plant stand, displaying various potted plants in an indoor setting.

5. CARE AND MAINTENANCE

Proper care will help maintain the appearance and longevity of your VINGLI console table.

- **Cleaning:** Wipe the table surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the wood finish.
- **Spills:** Clean spills immediately to prevent staining, especially with liquids.
- **Heat and Moisture:** Avoid placing hot items directly on the surface. Use coasters or protective pads under drinks and hot dishes. Protect from excessive moisture.
- **Sunlight:** Prolonged exposure to direct sunlight may cause the wood to fade or change color over time.
- **Inspections:** Periodically check all screws and connections to ensure they are tight. Re-tighten if necessary.

6. TROUBLESHOOTING

If you encounter any issues with your VINGLI console table, please refer to the following common solutions:

Common Issues and Solutions

Problem	Possible Cause	Solution
Table is wobbly or unstable.	Loose screws or uneven floor.	Ensure all assembly screws are fully tightened. Move the table to a level surface or use furniture pads to stabilize.
Parts do not align during assembly.	Incorrect orientation of parts or misaligned holes.	Review the assembly guide carefully, ensuring each part is oriented correctly before tightening screws. Do not overtighten until all parts are loosely fitted.
Surface scratches or minor damage.	Accidental impact or abrasive cleaning.	For minor scratches, wood repair markers or furniture polish may help. Avoid abrasive materials for cleaning.

7. PRODUCT SPECIFICATIONS

Detailed specifications for the VINGLI 35.4 inch Natural Wood Entryway Console Table.

Specification	Detail
Brand	VINGLI
Model Name	Console Table
Model Number	RZER232
Product Dimensions (D x W x H)	11.89" x 35.49" x 31.59"
Item Weight	12.1 Pounds
Maximum Weight Recommendation	100 Pounds
Color	Natural Wood
Material Type	Pine Wood
Furniture Finish	Matte
Indoor/Outdoor Usage	Indoor
Included Components	Assembly Guide, Installation Tool

8. WARRANTY AND CUSTOMER SUPPORT

For information regarding product warranty, returns, or to contact customer support, please refer to the purchase documentation or visit the official VINGLI website. Specific warranty details are not included in this instruction manual.

For further assistance, please contact VINGLI customer service through their official channels.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F2SWH6K1>

More documents and user manuals: <https://manuals.plus/>