Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

WOKEGI WX1

WOKEGI WX1 Handheld Mini Car Vacuum Instruction Manual

3-in-1 Cordless Portable Vacuum Cleaner & Air Duster

Introduction

Thank you for choosing the WOKEGI WX1 Handheld Mini Car Vacuum. This versatile 3-in-1 device combines powerful vacuuming, effective air dusting, and convenient inflation capabilities in a compact, cordless design. It is ideal for maintaining cleanliness in your car, home, office, or during travel. Please read this manual thoroughly before use to ensure proper operation and maintenance.



Image: WOKEGI WX1 Handheld Mini Car Vacuum, showcasing its compact design.

Safety Instructions

- Do not use the device near water or in wet conditions.
- Keep out of reach of children.
- Use only the provided Type-C charging cable.
- Do not attempt to disassemble or modify the device.
- Ensure the filter is properly installed before operation to prevent damage.
- Avoid blocking the air inlets or outlets during use.
- Do not vacuum hot ashes, burning cigarettes, or sharp objects.

Package Contents

Verify that all items are present in your package:

- WOKEGI WX1 Handheld Mini Car Vacuum
- Flat Suction Nozzle
- Brush Attachment
- Blower Nozzle
- Inflation Nozzle
- Washable HEPA Filter (1 pre-installed, 1 spare)
- Type-C Charging Cable
- User Manual



Image: The WOKEGI WX1 vacuum alongside its various nozzles and charging cable.

Product Overview

The WOKEGI WX1 features a user-friendly design with a single power button for operation. Its transparent dust collection cup allows for easy monitoring of debris levels. The device is powered by a 2000mAh battery and charges via a Type-C port.



Image: Exploded view illustrating the dust collection cup, HEPA filter, pure copper motor, one-click start button, 2000mAh batteries, and Type-C charging port.

Setup

1. Initial Charging

Before first use, fully charge the device. Connect the provided Type-C charging cable to the port at the bottom of the handle and plug the other end into a compatible USB power source (e.g., laptop, power bank, car charger, or wall adapter). The charging indicator light will show red while charging and turn green when fully charged.



Image: The WOKEGI WX1 vacuum connected to a Type-C charger, showing red and green indicator lights for charging status.

2. Attaching Nozzles

The WX1 supports both vacuuming and blowing functions. Attach the desired nozzle based on your cleaning task:

- **For Vacuuming:** Insert the flat suction nozzle or brush attachment into the front opening of the dust collection cup until it clicks securely into place.
- **For Blowing/Inflating:** Remove the dust collection cup by twisting it counter-clockwise. Insert the blower nozzle or inflation nozzle into the rear air outlet of the main unit until it clicks securely.

Operating Instructions

1. Power On/Off

Press the single power button located on the handle to turn the device on. Press it again to turn it off.

2. Vacuum Mode

With the appropriate vacuum nozzle attached to the front, turn on the device. Guide the nozzle over the surface you wish to clean. The powerful 10000PA suction will effectively pick up dust, crumbs, and small debris. Use the brush attachment for delicate surfaces or to dislodge stubborn dirt.



Image: The WOKEGI WX1 vacuum being used to clean tight spaces in a car interior.

3. Blower Mode

With the blower nozzle attached to the rear air outlet, turn on the device. The strong airflow can be used to:

- Dust keyboards, electronics, and hard-to-reach crevices.
- Inflate small inflatables using the specialized inflation nozzle.
- Clear light debris from surfaces.



Image: The WOKEGI WX1 vacuum in blower mode, effectively cleaning a computer keyboard.

Your browser does not support the video tag.

Video: Official product demonstration showcasing the WOKEGI WX1's 3-in-1 functionality, including vacuuming various surfaces and using the blower for inflation and dusting.

Maintenance

1. Emptying the Dust Cup

1. Ensure the device is turned off.
2. Twist the dust collection cup counter-clockwise to detach it from the main unit.
3. Carefully remove the HEPA filter from the dust cup.
4. Empty the collected debris into a trash receptacle.

2. Cleaning the HEPA Filter

The HEPA filter is washable and reusable, extending its lifespan and promoting eco-friendly cleaning.

1. After removing the filter from the dust cup, rinse it under running water until clean.
2. Allow the filter to air dry completely before reinserting it into the dust cup. Ensure it is fully dry to prevent mold or damage.
3. Reassemble the filter into the dust cup and attach the cup back to the main unit by twisting clockwise until secure.



Image: Visual guide demonstrating the steps to remove the dust cup, remove the filter, and rinse the filter with water.

3. Storage

Due to its compact and lightweight design, the WX1 can be easily stored in various locations:

- Car door pocket
- Car glove box
- Travel bag
- Drawer



Image: The WOKEGI WX1 vacuum shown being stored in a car door pocket, glove box, travel bag, and drawer, highlighting its portability.

Troubleshooting

Problem	Possible Cause	Solution
Low Suction Power	Dust cup full, filter clogged, nozzle blocked.	Empty dust cup, clean/replace filter, clear nozzle obstruction.
Device Not Turning On	Battery depleted, power button malfunction.	Charge the device fully. If issue persists, contact support.

Problem	Possible Cause	Solution
Not Charging	Cable faulty, power source issue, charging port damaged.	Try a different Type-C cable and power source. Ensure port is clean.

Specifications

- **Brand:** WOKEGI
- **Model Name:** WX1
- **Suction Power:** 10000PA
- **Rated Power:** 120W
- **Battery Capacity:** 2000mAh Lithium Ion
- **Charging Port:** Type-C
- **Filter Type:** Washable HEPA Filter
- **Product Dimensions:** 8.2"L x 7"W x 3.1"H
- **Item Weight:** 12.6 ounces
- **Noise Level:** <45dB
- **Runtime:** 15-25 minutes
- **Recharge Time:** 1.5-2 hours
- **Dust Collection Cup Capacity:** 120 ML



Image: The WOKEGI WX1 vacuum displayed with its main technical specifications.

Warranty and Support

Your WOKEGI WX1 Handheld Mini Car Vacuum is covered by a manufacturer's warranty. For detailed warranty information, including duration and terms, please refer to the product packaging or contact WOKEGI customer support directly. If you encounter any issues or have questions regarding your device, please reach out to the manufacturer for assistance.

Manufacturer: WOKEGI

For further support, please visit the WOKEGI Store on Amazon.

© 2026 WOKEGI. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How and where can I purchase new replaceable filters for the WOKEGI WX1 Handheld Mini Car Vacuum?

To obtain new replaceable filters for your WOKEGI WX1 Handheld Mini Car Vacuum, you should first check your original packaging, as the product comes with one pre-installed filter and one spare filter included. If...

Read full answer

Open the live page

https://manuals.plus/asin/B0F2SWTQFK

More documents and user manuals: **https://manuals.plus/**