



Manuals.plus /

› LINSY HOME /

› LINSY HOME TV Stand Instruction Manual for 65-inch TVs, Model B0F2SX26M2

LINSY HOME B0F2SX26M2

LINSY HOME TV Stand Instruction Manual

Model: B0F2SX26M2

1. INTRODUCTION

Thank you for choosing the LINSY HOME TV Stand. This entertainment center is designed to accommodate TVs up to 65 inches, featuring integrated LED lighting, ample storage with glass doors, and a modern aesthetic. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure a safe and enjoyable experience with your new furniture.

2. SAFETY INFORMATION

- **Read all instructions carefully:** Before assembly and use, read and understand all instructions and safety warnings.
- **Two-person assembly recommended:** For safety and efficiency, it is highly recommended that two people assemble this product.
- **Use appropriate tools:** Ensure you have the correct tools for assembly. An electric screwdriver can save time and effort.
- **Secure all fasteners:** Ensure all screws, bolts, and connectors are securely tightened before use. Do not overtighten.
- **Weight capacity:** Do not exceed the maximum weight capacity of 400 lbs (181 kg) for the TV stand. Distribute weight evenly.
- **LED lights safety:** Ensure LED light strips are installed correctly and connections are secure. Do not expose electrical components to water.
- **Children and pets:** Keep small parts and packaging materials away from children and pets during assembly.
- **Placement:** Place the TV stand on a flat, stable, and level surface to prevent tipping.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all parts and hardware are present and undamaged. Refer to the

detailed parts list provided in your assembly guide. Typically, the package includes:

- Engineered wood panels for the stand structure
- Glass doors and hinges
- Metal handles
- LED light strip kit with remote control and power adapter
- Assembly hardware (screws, dowels, cam locks, etc.)
- Instruction manual

4. ASSEMBLY INSTRUCTIONS

Follow the step-by-step instructions provided in the included assembly guide. We recommend having a second person assist with assembly for easier handling of larger components and improved efficiency.

4.1. Preparation

- Clear a spacious area for assembly.
- Lay out all parts and hardware, organizing them by type.
- Ensure you have a Phillips head screwdriver and possibly a rubber mallet.

4.2. Step-by-Step Assembly

Refer to the visual diagrams in your assembly manual for precise component identification and placement. The general steps involve:

1. Assemble the base and side panels.
2. Install the fixed shelves and back panels.
3. Attach the top panel.
4. Assemble and attach the glass doors using the provided hinges and handles.
5. Install the adjustable shelves in the desired positions. Note: The center shelf can be removed to accommodate a 24-inch (61 cm) fireplace insert.
6. Install the LED light strip according to the separate LED installation guide.



Figure 1: Product Dimensions and Weight Capacity. This image illustrates the overall dimensions of the TV stand, including its length (59 inches), height (32 inches), and depth (15.7 inches). It also indicates a maximum weight capacity of 400 lbs (181 kg) and suitability for TVs up to 65 inches.



- 1 32" High Storage Space
- 2 4 Open Shelves & 2 Display Cabinets
- 3 3-Level Adjustable Shelves for Versatile Storage




Figure 2: Large Storage Space. This image highlights the generous storage capacity, including 32-inch high storage space, four open shelves, and two display cabinets with three-level adjustable shelves for versatile organization.



Figure 3: Design Details. This image provides a closer look at key design features such as the six cable management holes for organized wiring, upgraded metal handles for durability, and the modern American cross-style glass doors.

5. OPERATING THE LED LIGHTS

The LINSY HOME TV Stand features integrated LED lighting to enhance your entertainment experience. The LED system offers 6 vibrant colors and 22 dynamic flashing modes, controllable via a remote or a dedicated app.

5.1. Features

- **Color Options:** Choose from 6 vibrant static colors.
- **Dynamic Modes:** Select from 22 dynamic flashing and fading modes.
- **Dual Control:** Operate the lights using the included remote control or a smartphone application.
- **Timer Function:** Set a timer for the lights to turn off automatically.
- **Music Mode:** Lights can synchronize with music for an immersive experience.
- **Adjustable Speed & Brightness:** Customize the speed of dynamic modes and the brightness of all settings.

5.2. Installation and Connection

Ensure the LED light strip is properly adhered to the designated area of the TV stand. Connect the LED strip to the controller and then to the power adapter. Plug the power adapter into a standard electrical outlet.

5.3. Using the Remote Control / App

Point the remote control towards the LED receiver to change colors, modes, brightness, and activate the timer or music functions. For app control, download the recommended application (details in the LED kit manual), pair it with the LED controller via Bluetooth, and use the app interface to customize settings.



Figure 4: RGB LED Lights Features. This image illustrates the various functionalities of the LED lighting system, including customizable colors, dual control via remote and app, timer function, music mode, and adjustable speed and brightness.



Figure 5: LED Lights in Operation. This image shows the TV stand with its LED lights illuminated in a vibrant green, demonstrating the ambient lighting effect.

6. MAINTENANCE AND CARE

Proper care will extend the life and appearance of your LINSY HOME TV Stand.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the engineered wood.
- **Dusting:** Regularly dust with a dry, soft cloth.
- **Hardware:** Periodically check and retighten all hardware to ensure stability.
- **LED Lights:** If the LED strip adhesive weakens, re-secure it with appropriate adhesive tape designed for electronics.
- **Avoid direct sunlight:** Prolonged exposure to direct sunlight can cause fading or discoloration.
- **Humidity:** Maintain a stable humidity level to prevent warping or cracking of the wood.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your TV stand.

Problem	Possible Cause	Solution
LED lights not turning on.	Power connection issue, remote battery dead, LED strip faulty.	Check if the power adapter is securely plugged in. Replace remote batteries. Ensure LED strip is properly connected to the controller. If issues persist, contact support.
LED lights not sticking to the surface.	Adhesive weakening or surface not clean during installation.	Clean the surface thoroughly. Re-secure the LED strip using additional double-sided adhesive tape suitable for electronics.
Stand feels wobbly or unstable.	Loose fasteners, uneven floor.	Check and tighten all screws and bolts. Ensure the stand is placed on a level surface. Use furniture levelers if necessary.
Parts do not align during assembly.	Incorrect orientation of parts, manufacturing defect.	Review the assembly diagrams carefully to ensure parts are oriented correctly. Do not force parts. If a part appears defective, contact customer support for a replacement.

8. PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	B0F2SX26M2
Brand	LINSY HOME
Material Type	Engineered Wood
Color	White
Product Dimensions (D x W x H)	39.8 cm x 172.7 cm x 59.9 cm (15.7 in x 68 in x 23.6 in)
Product Weight	47.63 kg (105 lbs)
Maximum Weight Capacity	181 kg (400 lbs)
TV Size Compatibility	Up to 65 inches
Assembly Required	Yes
LED Lights	6 colors, 22 dynamic modes, remote/app control, timer, music mode
Fireplace Accommodation	Designed for 61 cm (24 inch) fireplace insert (center shelf removal required)

9. WARRANTY AND SUPPORT

For any questions regarding assembly, missing parts, or product defects, please contact LINSY HOME customer support. While specific warranty details are not provided in this manual, most products come with a

manufacturer's warranty against defects in materials and workmanship. Please retain your proof of purchase for any warranty claims.

Contact information can typically be found on the product packaging or the manufacturer's official website.