Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

OTTOCAST CA505-T1

OTTOCAST Mini 2025 Wireless CarPlay & Android Auto 2-in-1 Adapter User Manual

Model: CA505-T1

1. Introduction

The OTTOCAST Mini 2025 is a compact and powerful adapter designed to convert your vehicle's existing wired Apple CarPlay or Android Auto system into a seamless wireless experience. Enjoy instant connectivity, stable performance, and full access to your smartphone's features on your car's display without the need for cables.



Image: The compact OTTOCAST Mini adapter with icons representing wired to wireless conversion, CarPlay/Android Auto functionality, direct switching, and seamless upgrades.

2. What's in the Box



Image: A visual representation of the items included in the OTTOCAST Mini packaging, showing the adapter, USB cables, and user manual.

- OTTOCAST Mini Wireless CarPlay & Android Auto Adapter x 1
- 90° USB Plug Adapter (Type A to A) x 1
- USB Plug Adapter (Type A to C) x 1
- User Manual x 1

Video: A detailed unboxing of the OTTOCAST Mini, showcasing all included components and their initial appearance.

3. Setup Instructions

Setting up your OTTOCAST Mini is a simple, one-time process. After the initial pairing, the adapter will automatically connect to your phone every time you start your car.

3.1 Initial Connection

1. Ensure your vehicle's wired CarPlay or Android Auto system is active.
2. Plug the OTTOCAST Mini adapter into the USB port normally used for wired connection in your car. Use the appropriate USB adapter (Type A to A or Type A to C) if needed.
3. On your phone, enable Bluetooth and Wi-Fi.
4. On your car's infotainment screen, a Bluetooth pairing prompt should appear. Select the OTTOCAST device (e.g.,

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F2SX2FBS

More documents and user manuals: **https://manuals.plus/**