

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Bella Depot](#) /

› [Bella Depot Retractable Ceiling Fan with Lights and Remote \(Classic Black, 36"\) User Manual](#)

Bella Depot B0F2SXC9TG

Bella Depot Retractable Ceiling Fan with Lights and Remote (Classic Black, 36") User Manual

Model: B0F2SXC9TG

IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before beginning installation and use. Failure to follow these instructions may result in electric shock, fire, or serious personal injury.

- Ensure the power is turned off at the circuit breaker before installation or maintenance.
- All wiring must be in accordance with national and local electrical codes. If you are unfamiliar with wiring, consult a qualified electrician.
- The mounting structure must be capable of supporting the weight of the fan (approximately 35 lbs).
- Do not bend the blade holders during installation, balancing, or cleaning.
- Keep hands clear of the fan blades when the fan is operating.
- This fan is designed for indoor use only.

PACKAGE CONTENTS

Verify that all components are present and undamaged before proceeding with installation. If any parts are missing or damaged, contact Bella Depot customer service.

- Ceiling Fan Motor Housing with Integrated Light
- Retractable Fan Blades (pre-attached)
- Remote Control and Receiver
- Downrods (5" and 10" options)
- Mounting Bracket
- Canopy and Canopy Ring
- Hardware Pack (screws, wire nuts, washers)
- Instruction Manual

SETUP AND INSTALLATION

1. Prepare for Installation

- Turn off power at the main circuit breaker.
- Ensure the electrical box is securely mounted and capable of supporting the fan.
- Unpack all components and lay them out on a soft surface to prevent scratches.

2. Mounting the Bracket

Attach the mounting bracket to the ceiling electrical box using the provided screws and washers. Ensure the bracket is firmly secured.

3. Assembling the Downrod

Select the desired downrod length (5" or 10"). Feed the fan wires through the downrod. Insert the downrod into the fan motor housing and secure it with the provided pin and screw.

4. Hanging the Fan

Carefully lift the fan assembly and hang it on the mounting bracket hook. This will allow for hands-free wiring.

5. Wiring Connections

Connect the fan's electrical wires to the house wiring according to the following:

- **Green/Bare Copper Wire:** To Ground Wire (Green or Bare Copper)
- **White Wire:** To Neutral Wire (White)
- **Black Wire:** To Live/Hot Wire (Black)

Insert the remote receiver into the mounting bracket. Connect the receiver wires to the fan and house wires as per the receiver's instructions (typically color-coded).

6. Securing the Fan and Canopy

Once wiring is complete, carefully lift the fan off the hook and seat the downrod ball into the mounting bracket socket. Secure the canopy to the mounting bracket with the provided screws.

Item Dimension




Figure 1: Item Dimensions. This diagram illustrates the various measurements of the ceiling fan, including the 36-inch diameter, 15.4-inch light fixture diameter, 2.4-inch blade height, and adjustable downrod options (5 or 10 inches), resulting in total heights of 12 or 17 inches. It also shows adaptability for sloped ceilings up to 15 degrees.

OPERATING INSTRUCTIONS

Your Bella Depot ceiling fan is operated by the included remote control. Ensure the remote has a 23A 12V battery installed (not included).

Remote Control Functions:

- Power Button (>):** Turns the fan and light on/off.
- Fan Speed Buttons (1-6):** Adjusts fan speed from 1 (lowest) to 6 (highest).
- Light On/Off Button (>):** Toggles the light on or off independently.
- Color Temperature Button (CCT):** Cycles through 3 light color temperatures: Warm Light (3000K), Natural White (4000K), and Cool White (6000K).
- Timing Buttons (1H, 2H, 4H, 8H):** Sets the fan to turn off automatically after 1, 2, 4, or 8 hours.

- **Reverse Function Button ():** Changes the direction of the fan blades for summer (downdraft) or winter (updraft) operation.



Figure 2: Fan and Remote Control. This image displays the Bella Depot 36-inch retractable ceiling fan in black, with its blades extended and the integrated LED light illuminated. Alongside the fan, the remote control is shown, highlighting its various buttons for fan speed, light control, color temperature adjustment, timing, and reverse function.

Dual-Season Functionality:

The fan features a reversible motor for year-round comfort:

- **Summer Mode (Downdraft):** Press the reverse button to set the blades to rotate counter-clockwise, creating a downward airflow that produces a cooling effect.
- **Winter Mode (Updraft):** Press the reverse button again to set the blades to rotate clockwise, creating an upward airflow that circulates warm air trapped near the ceiling.



Figure 3: Dual-Season Airflow. This diagram visually explains the fan's reversible function. The "Forward" setting, indicated by blue arrows pointing down, is for summer use to create a cooling downdraft. The "Reverse" setting, indicated by orange arrows pointing up, is for winter use to circulate warm air upwards.

Light Color Temperature Adjustment:

The integrated LED light offers three distinct color temperatures to suit your preference or activity:

- **3000K (Warm Light):** Provides a cozy, inviting ambiance, ideal for relaxation.
- **4000K (Natural White):** A balanced, neutral light suitable for general tasks and everyday living.
- **6000K (Cool White):** Bright, crisp light, often preferred for focused work or a more modern feel.

Press the color temperature button on the remote to cycle through these options.



Figure 4: Adjustable Color Temperature. This image demonstrates the three available light color temperatures: Warm Light (3000K), Warm White (4000K), and White Light (6000K). The fan's integrated LED light can be adjusted to these settings via the remote control to match different moods or functional needs.

MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** Use a soft, damp cloth to clean the fan blades and motor housing. Do not use abrasive cleaners or solvents. Ensure the power is off before cleaning.
- **Tightening Screws:** Periodically check all screws on the fan and mounting hardware to ensure they are tight. Loose connections can cause noise or wobble.
- **Blade Balance:** If the fan wobbles, ensure all blades are securely attached and balanced. A balancing kit (not included) can be used if necessary.

TROUBLESHOOTING

Before attempting any repairs, ensure the power is turned off at the circuit breaker.

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control battery dead or not installed.	Check circuit breaker; Verify all wire connections are secure; Replace remote battery (23A 12V).
Light does not work	Loose wire connections; LED driver failure; Remote control issue.	Check light wiring connections; Contact customer service if LED driver is suspected; Ensure remote battery is functional.
Fan wobbles	Loose mounting bracket or downrod screws; Unbalanced blades.	Tighten all mounting screws; Ensure downrod is seated correctly; Use a blade balancing kit if needed.
Remote control not responding	Dead battery; Receiver not paired or faulty.	Replace remote battery (23A 12V); Refer to remote pairing instructions (if applicable, usually automatic); Contact customer service.
Fan is noisy	Loose screws; Motor hum; Blades hitting an obstruction.	Check and tighten all screws; Ensure no obstructions are near blades; Some motor hum is normal, but excessive noise may indicate an issue.

SPECIFICATIONS


- Brand:** Bella Depot
- Model:** Retractable Ceiling Fan
- ASIN:** B0F2SXC9TG
- Size:** 36 inches
- Color:** Classic Black
- Indoor/Outdoor Usage:** Indoor
- Power Source:** DC
- Voltage:** 120 Volts (AC)
- Mounting Type:** Ceiling Mount
- Product Dimensions:** 36 x 36 x 13.4 inches (with 5" downrod)
- Light Source:** Integrated Dimmable LED (36W)
- Color Temperatures:** 3000K (Warm), 4000K (Natural White), 6000K (Cool White)
- Fan Speeds:** 6
- Noise Level:** Approximately 35dB

WARRANTY AND SUPPORT

Bella Depot products are manufactured to high-quality standards. For warranty information, please refer to the warranty card included with your purchase or visit the official Bella Depot website. For technical support, replacement parts, or any inquiries, please contact Bella Depot customer service.

Bella Depot Customer Service: Refer to your purchase documentation or the manufacturer's website for current contact information.

Related Documents - B0F2SXC9TG

 Bella Depot Retractable Ceiling Fan Installation & Troubleshooting Manual  Bella Depot Modern Ceiling Fan Installation & Troubleshooting Manual  Bella Depot DC2002 Modern Ceiling Fan Installation and Troubleshooting Manual  Bella Depot DC5206 Modern Ceiling Fan: Installation and Troubleshooting Guide  Bella Depot Modern Ceiling Fan Installation and Troubleshooting Manual	<p><u>Bella Depot Retractable Ceiling Fan: Installation & Troubleshooting Manual</u> Comprehensive installation and troubleshooting manual for the Bella Depot Retractable Ceiling Fan. Includes safety rules, required tools, detailed step-by-step instructions for mounting, downrod installation, wiring with remote receiver, light kit setup, and canopy securement. Features a troubleshooting guide for common issues like lights not working or fan not starting, ensuring safe and proper operation.</p>
	<p><u>Bella Depot Modern Ceiling Fan Installation and Troubleshooting Manual</u> A comprehensive guide for installing and troubleshooting the Bella Depot Modern Ceiling Fan, including safety rules, tools required, installation steps, and solutions for common issues.</p>
	<p><u>Bella Depot DC2002 Modern Ceiling Fan Installation and Troubleshooting Manual</u> Bella Depot DC2002 Modern Ceiling Fan: Installation and Troubleshooting Manual. Get step-by-step instructions, safety guidelines, parts list, wiring diagrams, and solutions for common fan and light issues.</p>
	<p><u>Bella Depot DC5206 Modern Ceiling Fan: Installation and Troubleshooting Guide</u> Comprehensive installation and troubleshooting manual for the Bella Depot DC5206 Modern Ceiling Fan, providing step-by-step instructions and solutions for common issues.</p>
	<p><u>Bella Depot Modern Ceiling Fan Installation and Troubleshooting Manual</u> A comprehensive guide for installing and troubleshooting the Bella Depot Modern Ceiling Fan, including safety rules, tools required, parts list, installation steps, and common problem solutions.</p>



Bella Depot Retractable Ceiling Fan
Installation & Troubleshooting Manual

CAUTION
READ INSTRUCTIONS CAREFULLY FOR
SAFE INSTALLATION AND FAN OPERATION

[Bella Depot Retractable Ceiling Fan: Installation & Troubleshooting Manual](#)

Comprehensive installation and troubleshooting manual for the Bella Depot Retractable Ceiling Fan. Includes safety rules, required tools, detailed step-by-step instructions for mounting, downrod installation, wiring with remote receiver, light kit setup, and canopy securement. Features a troubleshooting guide for common issues like lights not working or fan not starting, ensuring safe and proper operation.