

[Manuals.plus](#) /

› [Woesvcai](#) /

› Woesvcai Fish Ceramic Ashtray User Manual

Woesvcai TY20250328012

Woesvcai Fish Ceramic Ashtray User Manual

Model: TY20250328012

1. INTRODUCTION

This manual provides essential information for the proper setup, operation, and maintenance of your Woesvcai Fish Ceramic Ashtray. Please read this manual thoroughly before use to ensure optimal performance and longevity of the product.



Figure 1: Front view of the Woesvcai Fish Ceramic Ashtray with a cigarette. This image shows the ashtray's unique fish shape, open mouth design, and prominent eyes, with a cigarette resting inside the mouth, demonstrating its primary function.

2. SETUP

The Woesvcai Fish Ceramic Ashtray requires minimal setup. Follow these steps to prepare your ashtray for use:

1. **Unpacking:** Carefully remove the ashtray from its packaging. Inspect for any signs of damage during transit. If damage is found, contact customer support immediately.
2. **Placement:** Place the ashtray on a stable, flat, and heat-resistant surface. Ensure it is away from flammable materials and out of reach of children and pets.
3. **Initial Cleaning:** Before first use, it is recommended to wipe the ashtray with a damp cloth to remove any dust or residue from manufacturing and packaging.



Figure 2: Top-down view of the Woesvcai Fish Ceramic Ashtray on a wooden surface. This image provides a clear overhead perspective of the ashtray's design, showing the textured scales and the wide opening for ash collection, with a cigarette butt inside.

3. OPERATING INSTRUCTIONS

Using your Woesvcai Fish Ceramic Ashtray is straightforward:

- **Ash Collection:** Use the wide opening of the fish's mouth to deposit ash and cigarette butts. The deep bowl design is intended to contain ashes effectively and prevent spillage.
- **Cigarette Rest:** The interior edges of the ashtray's mouth can serve as a resting place for cigarettes.
- **Safety Precaution:** Always ensure that cigarettes are fully extinguished before leaving them in the ashtray. Never leave burning cigarettes unattended.

4. MAINTENANCE AND CARE

Proper maintenance will ensure the longevity and aesthetic appeal of your ceramic ashtray:

- **Regular Cleaning:** Empty the ashtray regularly. For general cleaning, wipe the smooth ceramic surface with a soft,

damp cloth.

- **Deep Cleaning:** For stubborn residue, use a mild soap solution and a soft brush or sponge. Rinse thoroughly with clean water and dry completely before reuse.
- **Avoid Abrasives:** Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can scratch or damage the ceramic finish.
- **Handling:** While durable, ceramic can break if dropped or subjected to strong impact. Handle with care.



Figure 3: Two Woesvcai Fish Ceramic Ashtrays displayed on a wooden surface. One ashtray is shown from a side profile, highlighting its fish-like body and tail, while the other is viewed from the front, emphasizing its wide, open mouth and eyes. This image illustrates the product's design from multiple angles.

5. TROUBLESHOOTING

This section addresses common concerns you might encounter with your ceramic ashtray.

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Ashtray appears dirty or stained after use.	Accumulation of ash and tar residue.	Perform a deep cleaning using mild soap and water. Ensure regular emptying and wiping.
Ashtray is unstable on surface.	Uneven placement surface.	Relocate the ashtray to a flat, stable surface.
Product is chipped or cracked.	Accidental impact or drop.	Ceramic is fragile. If damaged, the product may need replacement. This is typically not covered under normal use warranty.

6. SPECIFICATIONS

Key specifications for the Woesvcai Fish Ceramic Ashtray:

- **Model Number:** TY20250328012
- **Material:** High-quality Ceramic
- **Color:** Multicolor (primarily black with white eyes)
- **Dimensions (Fish B):** Approximately 16 cm (L) x 8 cm (W) or 6.3"L x 6.3"W x 3.15"H
- **Item Weight:** Approximately 3.5 pounds
- **Manufacturer:** Woesvcai
- **UPC:** 762239533833

7. WARRANTY INFORMATION

Woesvcai products are manufactured with attention to quality. For specific warranty terms and conditions, please refer to the product packaging or contact Woesvcai customer support. Typically, ceramic items are warranted against manufacturing defects but not against breakage due to drops or misuse.

8. CUSTOMER SUPPORT

For further assistance, questions, or to report issues, please contact Woesvcai customer support. You can often find contact information on the product packaging or by visiting the official Woesvcai store on Amazon:
[Visit the Woesvcai Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question