

[Manuals.plus](#) /

› [Moremore](#) /

› Moremore Fitness Tracker R11 User Manual

Moremore R11

Moremore Fitness Tracker R11 User Manual

Model: R11

INTRODUCTION

Welcome to the Moremore Fitness Tracker R11 user manual. This guide provides detailed instructions on how to set up, operate, and maintain your new fitness tracker. Please read this manual carefully to ensure optimal performance and a comprehensive understanding of all features.



The Moremore Fitness Tracker R11, featuring a sleek black design with a rectangular display and a comfortable silicone strap.

SETUP

1. Unboxing and Initial Charge

Upon receiving your Moremore Fitness Tracker R11, carefully unbox the device and its accessories. Before first use, ensure the device is fully charged. Connect the magnetic charging cable to the charging points on the back of the tracker and plug the USB end into a compatible power source. A full charge typically takes 1-2 hours.

Your browser does not support the video tag.

This video demonstrates the unboxing of the Moremore Fitness Tracker R11, showing the device and its charging cable.

2. App Download and Device Pairing

1. Download the **GloryFit** application from your smartphone's app store (available for Android 4.4+ and iOS 9.0+).
2. Open the GloryFit app and follow the on-screen instructions to create an account or proceed as a guest.
3. Navigate to the 'Device' section within the app and select 'Select device'.
4. The app will search for nearby devices. Select 'R11' from the list to pair your fitness tracker. Ensure your tracker is close to your phone during pairing.
5. Once connected, the app will prompt you to set up personal information such as gender, height, and weight for more accurate data tracking.

Your browser does not support the video tag.

This video demonstrates the process of connecting the Moremore Fitness Tracker R11 to a smartphone via the GloryFit application, including initial app setup and device pairing.

OPERATING INSTRUCTIONS

1. Navigating the Interface

The Moremore Fitness Tracker R11 features a 1.47-inch HD full touch screen. Swipe left, right, up, or down to access different functions and menus. Press the side button to return to the main watch face or wake the screen.

Your browser does not support the video tag.

An overview video showcasing the various features and user interface navigation of the Moremore Fitness Tracker R11, including health monitoring, activity tracking, and smart functions.

2. Health Monitoring

- **Heart Rate Tracking:** The tracker continuously monitors your heart rate throughout the day. View real-time data on the watch or detailed trends in the GloryFit app.
- **Blood Oxygen (SpO2) Monitoring:** Measure your blood oxygen levels directly from your wrist. Access historical data in the app.
- **Sleep Tracking:** The device automatically tracks your sleep patterns, including light sleep, deep sleep, and awake times. Review your sleep quality score and insights in the app to help adjust sleep habits.
- **Blood Pressure Monitoring:** The tracker provides blood pressure readings for reference. *Note: This device is not intended for medical use and readings should not be used for diagnostic purposes.*

KEEP TRACK OF HEALTH



Heart Rate




Blood Pressure



Blood Oxygen



Sleep Tracker



Heart Rate



Blood Pressure



Blood Oxygen



Visual representation of the health monitoring capabilities, including heart rate, blood pressure, blood oxygen, and sleep analysis.

3. Activity Tracking

- **Daily Activity:** The tracker records daily steps, calories burned, and distance covered.
- **Sports Modes:** Choose from over 100 professional sports modes (e.g., walking, running, cycling, yoga) in the app to track specific workout data and make your exercise routines more scientific.

ALL DAY ACTIVITY TRACKING



AVG.Heart Rate
82 Bpm



Calorie
11561 kcal



Mileage
18 Km



Step count
13217 Step



Time
01:38








Illustration of the activity tracker's display showing real-time metrics such as average heart rate, calories burned, distance covered, step count, and exercise duration.

BETTER TO KONW YOUR HEALTH



Detailed health data, including blood oxygen, heart rate, blood pressure, and sleep monitoring, is accessible through the connected smartphone application.

4. Smart Features

- **Notifications:** Receive phone calls and social media notifications (Facebook, Twitter, WhatsApp, Instagram) directly on your watch. View caller names, reject calls, and read text messages.
- **Personal Assistant Functions:** Access weather updates, music control, menstrual cycle reminders, alarms, camera controls, stopwatch, hydration reminders, and sedentary reminders.

MESSAGE NOTIFICATION

Never missing important messages and phone calls



The fitness tracker receives smart message and call notifications from platforms like Facebook, Twitter, WhatsApp, and Instagram, allowing users to view messages and manage calls directly from the watch.

MAKE LIFE EASIER



Phone
Finder



Music
Control



Alarm
Clock



Sedentary
Reminder



Drinking
Reminder



Stress
Tracker



The device offers call and message notifications, allowing users to manage communications directly from their wrist. It also includes useful reminders for hydration, sedentary periods, and menstrual cycles.

5. Customization

Personalize your device with various custom watch faces available through the GloryFit app to match your style and preferences.

CUSTOMIZE YOUR OWN COLORFUL MOODS



A selection of customizable watch faces allows users to personalize the display of their Moremore Fitness Tracker R11.

MAINTENANCE

1. Cleaning

Regularly clean your fitness tracker and strap with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials, as these can damage the device. Ensure the charging contacts are clean and dry before charging.

2. Water Resistance

The Moremore Fitness Tracker R11 is waterproof. It is suitable for daily use, including hand washing and light rain exposure. Avoid prolonged submersion in water or use during high-pressure water activities like diving.

3. Battery Care

To prolong battery life, avoid fully discharging the device frequently. Charge the device when the battery level is low. Store the device in a cool, dry place when not in use for extended periods.

TROUBLESHOOTING

- **Device Not Turning On:** Ensure the device is fully charged. Connect it to the charger for at least 10 minutes.
- **Unable to Pair with Phone:** Make sure Bluetooth is enabled on your phone and the tracker is within range. Restart both the phone and the tracker, then try pairing again through the GloryFit app.
- **Inaccurate Readings:** Ensure the tracker is worn snugly on your wrist, about one finger's width above your wrist bone. Clean the sensor on the back of the device. Environmental factors and individual physiology can affect accuracy.
- **Notifications Not Appearing:** Check your phone's app permissions for GloryFit to ensure it has access to notifications. Verify that notifications are enabled within the GloryFit app settings for your device.
- **Short Battery Life:** Reduce screen brightness, disable continuous heart rate monitoring if not needed, and limit the number of active notifications to extend battery life.

SPECIFICATIONS

Feature	Detail
Brand	Moremore
Model	R11
Screen Size	1.47 Inches
Battery Life (Typical Use)	Up to 7 days
Charging Time	1-2 hours
Water Resistance	Waterproof
Compatibility	Android 4.4+ / iOS 9.0+
Item Weight	0.12 Kilograms

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or contact Moremore customer service directly. Keep your purchase receipt as proof of purchase.

© 2025 Moremore. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question