

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [BOBLOV](#) /
- › [BOBLOV A30 Mini Body Camera User Manual - 4K Ultra HD Recording](#)

BOBLOV A30

BOBLOV A30 Mini Body Camera User Manual

Model: A30



1. INTRODUCTION

This manual provides detailed instructions for the proper use and maintenance of your BOBLOV A30 Mini Body Camera. Please read this manual thoroughly before operating the device to ensure optimal performance and longevity.



Image: The BOBLOV A30 Mini Body Camera shown with its various accessories, including the charging dock, extra battery, lanyard, bike mount, and clip.

2. What's in the Box

Upon opening your BOBLOV A30 Mini Body Camera package, you should find the following items:

- BOBLOV A30 Body Camera
- Two (2) Rechargeable Batteries
- Dual-Slot Charging Dock
- USB Cable
- Bike Mount
- Lanyard
- Clip
- User Manual

What's in the Box?



Image: A visual representation of all items included in the BOBLOV A30 Mini Body Camera package, laid out neatly.

3. SETUP

3.1. Battery Installation and Charging

1. Insert a battery into the designated battery compartment on the camera. Ensure it clicks into place securely.
2. To charge the batteries, place them into the dual-slot charging dock. Connect the charging dock to a power source using the provided USB cable. The indicator lights on the dock will show charging status.
3. A full charge provides up to 7 hours of continuous 1080P recording or 6 hours of 4K recording per battery.

One in use, one charging – always ready

7Hrs
1080P

6Hrs
4K

Two batteries in total



Image: The dual-slot charging dock with two batteries, one inserted and one ready for insertion, illustrating the charging process.

3.2. MicroSD Card Installation

The camera supports external microSD cards for storage. Insert a compatible microSD card into the card slot on the camera. Ensure the card is correctly oriented before insertion.

4. OPERATING INSTRUCTIONS

4.1. Power On/Off

Press and hold the Power button to turn the camera on or off.

4.2. Recording Video

Once powered on, press the Record button to start video recording. Press it again to stop recording. The camera supports 4K Ultra HD resolution for detailed footage.

4K UHD Advanced Camera

Experience sharp, stunning visuals in every frame



Image: A comparison showing the clarity of 4K resolution video captured by the BOBLOV A30 Mini Body Camera versus standard resolution.

4.3. 180° Rotatable Lens

The camera features a 180° rotatable lens, allowing you to adjust the shooting angle as needed. Simply rotate the lens manually to capture footage from various perspectives (forward, upward, downward).

Turn, Tilt, Capture

180° adjustable lens for ultimate versatility



Image: The BOBLOV A30 Mini Body Camera demonstrating its 180° rotatable lens, showing different angles of rotation.

4.4. Loop Recording

The camera supports loop recording, which automatically overwrites the oldest footage when the storage card is full. This ensures continuous recording without manual deletion of files.

No More Full Storage Worries

No need to delete files—loop recording handles it



Image: The BOBLOV A30 Mini Body Camera screen displaying recording information, with icons indicating loop recording and compatibility with Windows and Mac operating systems.

4.5. Mounting Options

The BOBLOV A30 offers flexible mounting options to suit various activities:

- **Clip:** Attach the camera to clothing, bags, or other surfaces.
- **Lanyard:** Wear the camera around your neck for easy access.
- **Bike Mount:** Securely attach the camera to bicycle handlebars for outdoor adventures.

Multiple Ways to Wear



01



A30+360° Clips



02



A30+ Lanyard



03



A30 + Bike Mount



Image: The BOBLOV A30 Mini Body Camera displayed with its clip, lanyard, and bike mount accessories, illustrating different ways to wear or attach the camera.

Multiple Ways to Wear



Riding



Hiking



Studying

Image: Examples of the BOBLOV A30 Mini Body Camera being used during cycling, hiking, and for educational purposes, demonstrating its versatility.

4.6. Connecting to a Computer

Connect the camera to your computer using the provided USB cable to transfer files. The camera is compatible with both Windows and Mac operating systems.

5. MAINTENANCE

5.1. Battery Care

To maximize battery life, avoid fully discharging the batteries frequently. Store batteries in a cool, dry place when not in use. Use only the provided charging dock and cable.

5.2. Storage Management

Regularly transfer important footage from the microSD card to a computer or external storage device. While loop recording prevents storage from filling up, backing up data is recommended.

5.3. Cleaning

Use a soft, dry cloth to clean the camera body. For the lens, use a specialized lens cleaning cloth and solution to avoid scratches. Do not use harsh chemicals or abrasive materials.

6. TROUBLESHOOTING

- **Camera not turning on:** Ensure the battery is fully charged and correctly inserted. Try using the second battery.
- **Recording issues:** Check if the microSD card is properly inserted and has sufficient free space. Format the card if necessary (this will erase all data).
- **Poor video quality:** Ensure the lens is clean and free from smudges. Check recording settings to confirm 4K resolution is selected.
- **Computer not recognizing camera:** Try a different USB port or cable. Ensure the camera is powered on when connected.

7. SPECIFICATIONS

| Feature | Detail |
|--------------------------|-----------------------------|
| Model Number | A30 (A23) |
| Video Capture Resolution | 4K |
| Photo Sensor Technology | CMOS |
| Rotatable Lens | 180 Degrees |
| Battery Life (1080P) | Up to 7 hours (per battery) |
| Battery Life (4K) | Up to 6 hours (per battery) |
| Flash Memory Type | Micro SD |
| Video Capture Format | MOV |
| Screen Size | 1.3 Inches |
| Connectivity Technology | USB |
| Item Weight | 9.9 ounces |
| Color | Black |

8. WARRANTY AND SUPPORT

BOBLOV provides a **24-month product coverage** for its supporters. For any technical assistance or inquiries, BOBLOV offers a quick response within 24 hours and lifetime technical support. For further support or to visit the official store, please refer to the [BOBLOV Store](#).



Image: BOBLOV brand information highlighting customer satisfaction, global reach, 24-month product coverage, and 24-hour technical support.



© 2025 BOBLOV. All rights reserved.

Related Documents - A30

| | |
|--|---|
| | <p>BOBLOV A23 Mini Body Camera User Manual</p> <p>Comprehensive user manual for the BOBLOV A23 Mini Body Camera, covering setup, operation, features, specifications, troubleshooting, and customer service. Learn how to charge, power on/off, record video and audio, take photos, and use advanced features.</p> |
| | <p>Manual de utilizare cameră mini body BOBLOV A23</p> <p>Manual de utilizare complet pentru camera mini body BOBLOV A23, acoperind configurarea, operarea, caracteristicile, specificațiile și depanarea.</p> |

