

Diydeg Diydegf4e1wvapg2-11

Diydeg Anti Vibration Pads for Washing Machine - Instruction Manual

INTRODUCTION

Thank you for choosing Diydeg Anti Vibration Pads. These pads are designed to significantly reduce vibrations and noise produced by washing machines and dryers, enhancing your home comfort and protecting your flooring. Crafted from durable silicone, they offer exceptional anti-slip performance and stability.

The strong suction cup design ensures your appliance remains securely in place, preventing unwanted movement during operation. This set includes four versatile foot pads suitable for various washing machine models, providing an easy and effective solution for a quieter laundry experience.

Before And Now



Image: Before and After using Diydeg Anti Vibration Pads. The left shows a washing machine vibrating, while the right shows a stable machine, indicating reduced vibration and easier cleaning.

SETUP AND INSTALLATION

Follow these simple steps to install your Diydeg Anti Vibration Pads:

1. **Prepare the Pads:** Remove the four anti-vibration pads from their packaging.
2. **Lift Appliance Leg:** Carefully lift one leg of your washing machine or dryer. It is recommended to have assistance for heavy appliances to prevent injury.
3. **Position the Pad:** Place one anti-vibration pad directly under the lifted leg, ensuring the suction cup side faces the floor and the appliance leg rests securely in the recessed area of the pad.
4. **Adjust Position:** Gently lower the appliance leg onto the pad, making sure it is centered and stable.
5. **Repeat for Remaining Legs:** Repeat steps 2-4 for the remaining three legs of your appliance. Ensure all four pads are evenly placed and the appliance is level.

For optimal performance, ensure the floor surface where the pads will be placed is clean and dry.

Easy To Install

1



Take out the product

2



Lift one leg of the washing machine

3



Place the foot pads and adjust the position

4



Same as other 3 steps

Image: Easy installation guide showing the four steps to place the anti-vibration pads under a washing machine.

OPERATING INSTRUCTIONS

Once the Diydeg Anti Vibration Pads are installed, your washing machine or dryer can be operated as usual. The pads will automatically engage to absorb vibrations and prevent movement. You should notice a significant reduction in noise and shaking during cycles, particularly during the spin cycle.

These pads are also suitable for other furniture and appliances that may cause vibrations or require stability, such as refrigerators, sofas, tables, and chairs.

WIDELY USED



Image: Illustration demonstrating the wide applicability of the anti-vibration pads for various household items beyond washing machines.

MAINTENANCE

To ensure the longevity and continued effectiveness of your Diydeg Anti Vibration Pads, periodic maintenance is recommended:

- **Cleaning:** If the pads accumulate dust or debris, gently wipe them with a damp cloth. Ensure they are completely dry before re-positioning them under the appliance.
- **Check Placement:** Occasionally check that the pads remain securely under each leg of the appliance and that the appliance is still level.
- **Inspect for Wear:** While highly durable, inspect the silicone material for any signs of significant wear or damage over time. Replace if necessary to maintain optimal performance.



Image: Detailed view of the suction cup design on the underside of the anti-vibration pads, highlighting their grip mechanism.

TROUBLESHOOTING

- **Appliance Still Vibrates Excessively:**

- Ensure all four pads are correctly placed and the appliance legs are centered on them.
- Verify that the appliance itself is level. Adjust the appliance's built-in leveling feet if necessary.
- Check if the floor surface under the pads is clean and dry to allow proper suction.
- Ensure the washing machine load is balanced. An unbalanced load can cause significant vibration regardless of the pads.

- **Pads Do Not Stick to the Floor:**

- Clean the floor surface thoroughly to remove any dust, dirt, or moisture.
- Ensure the pads themselves are clean and free of residue.
- Confirm that the appliance's weight is evenly distributed on the pads.

SPECIFICATIONS

Feature	Detail
Item Type	Washing Machine Foot Pad
Material	Silicone
Package Dimensions	6.3 x 4.72 x 1.57 inches
Item Weight	5.3 ounces
Manufacturer	Diydeg
Model Number	Diydegf4e1wvapg2-11
ASIN	B0F2TKPMJC



Image: A set of four Diydeg Anti Vibration Pads, showcasing their design and quantity.

WARRANTY INFORMATION

Specific warranty details for Diydeg Anti Vibration Pads are typically provided at the point of purchase or within the product packaging. For information regarding warranty coverage, duration, and claims, please refer to the documentation included with your purchase or contact the seller directly.

CUSTOMER SUPPORT

If you encounter any issues or have questions regarding your Diydeg Anti Vibration Pads, please contact the seller through the platform where you made your purchase. You may also visit the official Diydeg brand store for additional product information and support resources.

Diydeg Brand Store: [Visit Diydeg Store on Amazon](#)