

[Manuals.plus](#) /

› [FORIOUS](#) /

› FORIOUS Black Touchless Kitchen Faucet with Soap Dispenser (Model FF0024B-SGY) - Instruction Manual

## FORIOUS FF0024B-SGY

# FORIOUS Black Touchless Kitchen Faucet with Soap Dispenser

Model: FF0024B-SGY

## 1. PRODUCT OVERVIEW

The FORIOUS Black Touchless Kitchen Faucet with Soap Dispenser is designed for modern kitchens, offering convenience and efficiency. This motion sensor-activated faucet features a pull-down sprayer and a single handle for precise control. It is crafted from durable SUS 304 stainless steel with a matte black finish, ensuring longevity and a sleek appearance.



*Image: The FORIOUS Black Touchless Kitchen Faucet with Soap Dispenser, showcasing its contemporary design and matte black finish.*

## 2. SETUP AND INSTALLATION

This faucet is designed for DIY-friendly installation, suitable for 1 or 3-hole sinks with the included deck plate. All necessary installation tools are provided. The touchless function is battery-operated, requiring 4 AA batteries (not included).

### 2.1 Included Components

- Kitchen Faucet Assembly
- Soap Dispenser (11.83 oz / 350 ML capacity)
- Deck Plate (for 1 or 3-hole sinks)

- Control Box (for touchless operation)
- Weight (for pull-down sprayer hose)
- Pre-attached Water Supply Lines
- Installation Hardware

## TOUCHLESS TECHNOLOGY

**Sensor-Activated System** means fewer dirt are spread.

**Touch-free faucets** are also easy for young children and seniors to use.



*Image: All components included in the FORIOUS kitchen faucet package, neatly organized in foam packaging.*

### 2.2 Dimensions and Installation Tips

Before installation, ensure your sink and countertop meet the required dimensions. The faucet is designed for easy setup with pre-attached water supply lines.

## TIPS FOR INSTALLATION



## ADDITIONAL INFORMATION

Faucet to Countertop Distance **>20 inches**

Mounting Hose Size: **1.30-1.35"**

Maximum thickness of counter-top: **1.1"**

## DIMENSIONS



3/8" Standard pipe connection



*Image: Detailed diagram showing faucet dimensions (Overall Height: 18.9 inches, Spout Reach: 8.27 inches, Spout Height: 6.89 inches) and installation tips for 1, 2, 3, or 4-hole sinks.*

### 2.3 Battery Installation

The touchless feature requires 4 AA batteries. Install them into the control box as per the instructions provided in the packaging. The control box allows switching between touchless and normal faucet operation.



### Vari-colored, Versatile, Suitable for Every Style.

Kitchen faucets in multiple colors, catering to diverse style preferences.

Image: Diagram illustrating the battery-operated control box and its connection for hands-free operation.

### 3. OPERATING INSTRUCTIONS

#### 3.1 Touchless Operation

Wave your hand in front of the motion sensor to turn the water on or off. The faucet will automatically shut off after 3 minutes of inactivity to conserve water.



Image: Demonstration of the touchless operation, showing water turning on with a hand wave and the auto-off feature.

#### 3.2 Two-Function Sprayer

The pull-down sprayer offers two functions: a steady stream for filling and a powerful spray for rinsing. Easily switch between modes using the button on the sprayer head.



*Image: Visual representation of the two spray modes: stream for filling pots and spray for cleaning vegetables/fruits.*

### 3.3 Manual Handle Operation

Use the single handle to control water temperature and flow manually. Push the handle back for cold water and forward for hot water. Lift the handle to increase flow.

## Dual-Setting Spray

Switch between two different spray modes for everyday you need



### Stream Mode

Quickly to fill pots and pans



### Sprayer Mode

Easier to wash vegetables/fruits

*Image: The pull-down sprayer extended, demonstrating its reach to cover the entire sink area.*

### 3.4 Switching to Normal Mode

In case of power outages or battery failures, you can still use the faucet by switching to normal mode. Rotate the manual switch on the control box counter-clockwise with a Phillips screwdriver to activate this mode.

### 3.5 Official Product Video

Your browser does not support the video tag.

*Video: An official demonstration of the FORIOUS Touchless Kitchen Faucet with Soap Dispenser, highlighting its features and operation.*

## 4. MAINTENANCE

### 4.1 Cleaning

The faucet is made from commercial-grade SUS 304 stainless steel with a matte black finish that resists fingerprints and water stains. Clean with a soft cloth and mild soap. Avoid abrasive cleaners or harsh chemicals that could damage the finish.

### 4.2 Soap Dispenser Refill

The included soap dispenser has an 11.83 oz (350 ml) capacity and can be refilled from the top, eliminating the need to access under the sink.

## KITCHEN FAUCET WITH SOAP DISPENSER

**Self-priming** soap dispenser with **11.83 oz larger-capacity** bottle for liquid soap, Lotion, or liquid detergent.



*Image: The FORIOUS kitchen faucet with its integrated soap dispenser, highlighting its convenient design.*

### 4.3 Drip-Free Cartridge Technology

The faucet utilizes a ceramic disc valve with a diamond coating, designed for long-lasting, drip-free performance up to 5 million uses.

## 5. TROUBLESHOOTING

- **No Water Flow:** Check if the water supply valves are fully open. Ensure batteries in the control box are correctly installed and not depleted.
- **Low Water Pressure:** Verify that the water supply lines are not kinked or obstructed. Clean the aerator for any mineral buildup.
- **Sensor Not Responding:** Ensure the sensor area is clean and unobstructed. Check battery levels and replace if necessary.
- **Leaks:** Confirm all connections are tight. If leaks persist, contact customer support.

For persistent issues, please refer to the contact information in the Support section.

## 6. SPECIFICATIONS

| Feature                     | Detail                                                                      |
|-----------------------------|-----------------------------------------------------------------------------|
| Brand                       | FORIOUS                                                                     |
| Model Name                  | Touchless Kitchen Faucet with Sprayer                                       |
| Model Number                | FF0024B-SGY                                                                 |
| Finish Type                 | Matte Black                                                                 |
| Material                    | Stainless Steel                                                             |
| Mounting Type               | Deck Mount                                                                  |
| Number of Handles           | 1                                                                           |
| Hole Count                  | 1 (or 3 with deck plate)                                                    |
| Flow Rate                   | 1.8 Gallons Per Minute                                                      |
| Spout Height                | 6.89 Inches                                                                 |
| Spout Reach                 | 8.27 Inches                                                                 |
| Item Dimensions (D x W x H) | 8.66"D x 10.04"W x 18.89"H                                                  |
| Special Features            | 360° Swivel, Dual Function Sprayer, Lead Free, Pull Down Sprayer, Touchless |

## 7. WARRANTY INFORMATION

The FORIOUS Black Touchless Kitchen Faucet comes with a limited warranty. For specific details regarding coverage and duration, please refer to the warranty card included in your product packaging or contact FORIOUS customer support.

## 8. SUPPORT

Should you have any questions, require technical assistance, or need to claim warranty service, please contact FORIOUS customer support. Contact information can typically be found on the product packaging or the official FORIOUS website.

Manufacturer: FORIOUS