

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [InnoGear](#) /

› [InnoGear 500ml Essential Oil Diffuser with Remote Control \(Model AD-H50\)](#)

InnoGear AD-H50

InnoGear 500ml Essential Oil Diffuser with Remote Control

Model: AD-H50 | **Brand:** InnoGear

PRODUCT OVERVIEW

The InnoGear 500ml Essential Oil Diffuser is designed to enhance your environment with aromatherapy and humidification. It features advanced ultrasonic technology for efficient mist diffusion, a large water capacity for extended operation, and a remote control for convenient adjustments. The diffuser also includes multiple mist modes, timer settings, and a diverse ambient night light with 8 colors.



Image: InnoGear 500ml Essential Oil Diffuser emitting a powerful mist, highlighting its instant aroma and humidification capabilities with 300% improved mist output.

WHAT'S IN THE BOX

- 1 x 500ml Diffuser
- 1 x Remote Control
- 1 x Measuring Cup

- 1 x AC/DC Adapter
- 1 x User Manual



Image: A visual representation of all items included in the InnoGear 500ml Diffuser package.

SETUP INSTRUCTIONS

- 1. Place the Diffuser:** Position the diffuser on a flat, stable surface away from direct sunlight or heat sources.
- 2. Remove the Cover:** Gently lift the top cover of the diffuser.
- 3. Add Water:** Using the provided measuring cup, fill the water tank with clean tap water up to the 'MAX' line (500ml). Do not exceed the maximum fill line to ensure proper misting.
- 4. Add Essential Oil (Optional):** Add 5-10 drops of your preferred essential oil directly into the water tank. Adjust the amount based on personal preference.
- 5. Replace the Cover:** Securely place the top cover back onto the diffuser.
- 6. Connect Power:** Plug the AC/DC adapter into the diffuser's power port and then into a wall outlet.



Image: Demonstrates filling the diffuser water tank up to the 500ml maximum line.

OPERATING INSTRUCTIONS

Remote Control Usage

The included remote control allows for convenient operation from up to 16.5 feet away. All functions available on the diffuser's base buttons are also accessible via the remote.




Image: A user operating the diffuser with the remote control, emphasizing ease of use.

Power On/Off

- Press the 'ON/OFF' button on the remote or the diffuser base to turn the unit on or off.

Mist Modes

Select your preferred mist output and duration:

- **Continuous Mode:** Press 'CONTINUOUS' on the remote or 'MIST' button on the diffuser to activate continuous mist.
- **Intermittent Mode:** Press 'INTERMITTENT' on the remote to release mist every 10 seconds.
- **Strong/Weak Mist:** Use the 'BIG/SMALL' button on the remote or the 'HIGH/LOW' button on the diffuser to adjust mist intensity. Strong mist runs for 9-12 hours, weak mist for 16-18 hours.



Image: Illustrates the optional mist modes and timer settings for customized aromatherapy.

Light Modes

The diffuser offers 8 colors of ambient light, each with two intensity settings (50% or full brightness), providing 16 different light combinations.

- Press the 'LIGHT' button on the remote or diffuser base to cycle through colors.
- Hold the 'LIGHT' button to fix on a single color.

- Press again to turn off the light or allow it to cycle through colors.



Image: Displays the 8 LED mood light feature with adjustable brightness and color options.

Timer Settings

Set the diffuser to automatically turn off after a specific period:

- Press the 'TIMING' button on the remote or the 'ON 60 120 180' button on the diffuser to select 1 hour, 2 hours, or 3 hours.
- The diffuser will automatically shut off once the selected time has elapsed.

Official Product Video

Video: An official InnoGear video demonstrating the features and remote control functionality of the essential oil diffuser.

MAINTENANCE

- **Regular Cleaning:** Clean the diffuser once a week to prevent mineral buildup and ensure optimal performance.
- **Cleaning Steps:** Remove the water tank and wipe it with a damp cloth. Allow the diffuser to dry completely before using it again.
- **Storage:** Always unplug the diffuser when not in use for extended periods.

IMPORTANT SAFETY INFORMATION

- Always unplug the diffuser when not in use.
- Clean the diffuser once a week, allowing it to dry completely before using it again.
- When using essential oils, add no more than 5-10 drops to the water tank up to the 'MAX' line.
- Keep out of reach of children and pets.
- Use only clean water; distilled water is recommended to prolong product life.
- Do not move the diffuser while it is operating or contains water.



Image: Highlights the diffuser's safety features, including BPA-free material, cool mist, and waterless auto-off.

SPECIFICATIONS

| Feature | Detail |
|--------------------|---|
| Brand | InnoGear |
| Model Name | AD-H50 |
| Color | Basic White |
| Capacity | 500 Milliliters |
| Material | Polypropylene (PP) |
| Power Source | Corded Electric |
| Special Features | Automatic Shut-Off, Long Lasting Aroma, Multiple Light Setting, Silent Operation, Timer Setting |
| Auto Shutoff | Yes |
| Product Dimensions | 6.65" L x 6.65" W x 5" H |
| Coverage | 300 square feet |