Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > EUHOMY /
- > EUHOMY Smart Nugget Ice Maker Countertop User Manual (Model HZB-15NF)

EUHOMY HZB-15NF

EUHOMY Smart Nugget Ice Maker Countertop User Manual

Model: HZB-15NF

Brand: EUHOMY

IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using your EUHOMY Smart Nugget Ice Maker. Retain this manual for future reference.

- Electrical Safety: Ensure the power outlet matches the voltage requirements of the ice maker (115 Volts). Do not operate with a damaged cord or plug. Do not immerse the appliance, cord, or plug in water or other liquids.
- Placement: Place the ice maker on a stable, level surface away from direct sunlight and heat sources. Ensure
 adequate ventilation around the unit. Maintain a minimum of 5 inches (12.7 cm) clearance from walls or other
 objects.
- Water Quality: Use only potable water in the ice maker.
- **Children:** This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure they do not play with the appliance.
- Maintenance: Unplug the ice maker before cleaning or performing any maintenance.

PRODUCT OVERVIEW

The EUHOMY Smart Nugget Ice Maker (Model HZB-15NF) is designed to produce chewable nugget ice efficiently. It features smart control via an app and a self-cleaning function.

Components Included:

- Ice Maker Machine
- Ice Scoop
- · Ice Basket

Product Diagram:



Figure 1: Front view of the EUHOMY Smart Nugget Ice Maker, showing the ice bin, control panel, and included ice scoop. A glass of iced beverage is also shown.



Figure 2: Diagram illustrating the compact dimensions of the ice maker: 11.8"D x 9.1"W x 13.1"H, alongside the 1.6 lbs ice basket.

SETUP

1. Unpacking

Carefully remove the ice maker from its packaging. Inspect the unit for any damage. Remove all packing materials, including any tape or protective films.

2. Placement

Place the ice maker on a flat, stable, and heat-resistant surface. Ensure there is at least 5 inches (12.7 cm) of space around the unit for proper ventilation. Avoid placing it near heat sources or in direct sunlight.

3. Initial Cleaning

Before first use, it is recommended to clean the interior of the ice maker. Refer to the 'Maintenance' section for detailed cleaning instructions. After cleaning, ensure all components are dry before proceeding.

4. Power Connection

Plug the power cord into a grounded electrical outlet. The unit is now ready for operation.

OPERATING INSTRUCTIONS

1. Adding Water

Open the lid and fill the water reservoir with potable water up to the 'MAX' fill line. Do not overfill.

2. Starting Ice Production

Press the ON/OFF button to start the ice-making cycle. The unit will begin producing nugget ice within approximately 7 minutes.



Figure 3: The ice maker actively producing ice, highlighting its rapid ice-making capability and capacity of 40 lbs/24h.

3. Understanding LED Status Lights

The ice maker is equipped with an intuitive LED indicator light system:

- Blue Light: Indicates the unit is actively making ice.
- Purple Light: Indicates the ice basket is full. The ice maker will pause production until ice is removed.
- Orange Light: Indicates a low water level. Refill the water reservoir to resume ice production.



Figure 4: Visual representation of the LED status lights for 'Ice Full', 'Making Ice', and 'Low Water'.

4. Smart Wi-Fi & App Control

The ice maker can be controlled remotely via a dedicated app. Follow these steps to connect:

- 1. Download the EUHOMY app from your device's app store.
- 2. Ensure your ice maker is plugged in and your smartphone's Bluetooth is enabled.
- 3. Open the app and follow the on-screen instructions to pair your ice maker.

- 4. Once connected, you can remotely start/stop ice production, set schedules, and monitor the ice maker's status.
- 5. Voice commands via Alexa are also supported once the device is integrated with your smart home system.




Figure 5: Demonstrates the smart app and voice control features, allowing remote operation of the ice maker.



Figure 6: The app interface for scheduling ice production over a 24-hour period.

MAINTENANCE

1. Automatic Self-Cleaning Function

The ice maker features an automatic self-cleaning cycle:

- 1. Ensure the water reservoir is filled.
- 2. Press and hold the ON/OFF button for 5 seconds to initiate the 20-minute self-cleaning cycle.
- 3. The unit will automatically clean its internal components.
- 4. After the cycle, drain the water from the unit.



Figure 7: Internal diagram illustrating the self-cleaning process and the separate booster pump for efficient cleaning.



Figure 8: Simplified steps for automatic cleaning: one press for a 15-minute cycle.

2. Deep Cleaning (Recommended Quarterly)

For a thorough deep clean, especially if using the machine continuously:

- 1. Unplug the machine.
- 2. Move the machine so the front hangs over a sink. Pull out the drain plug to empty all water.
- 3. Empty the ice bucket, remove the ice basket, scoop, and the small filter at the bottom of the tank (left side). Clean these components by hand or in a dishwasher.
- 4. Reinstall the drain plug. Add half a cup of bleach to the tank, then fill the tank with hot water to the very top (above the max fill line).
- 5. Hold the power button for five seconds until the 'Add Water' light starts flashing. This initiates the self-cleaning cycle. Let it run for approximately 30 minutes.
- 6. Drain the machine completely.
- 7. Refill the tank with clean hot water to the top and run the cleaning cycle one more time for 30 minutes to rinse thoroughly.
- 8. Drain the machine again. Reinstall the cleaned filter and ice basket. Refill with fresh water to the max line.

3. Draining Water

To drain the water reservoir, locate the drain plug at the bottom of the unit. Place a container under the plug and remove it to allow water to flow out. Reinsert the plug firmly after draining.




Figure 9: Instructions for easy dismantling of the top cover for cleaning access.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No ice production	Low water level (Orange light)	Refill the water reservoir with potable water.
No ice production	Ice basket full (Purple light)	Remove ice from the basket.
Ice tastes unusual	Unit needs cleaning	Perform a self-cleaning cycle or a deep clean as described in the 'Maintenance' section.
Ice maker not turning on	No power	Check power cord connection and wall outlet. Ensure the unit is plugged into a working outlet.
App connection issues	Bluetooth/Wi-Fi not enabled or pairing failed	Ensure Bluetooth is on, restart the app, or re-attempt pairing following in-app instructions. Check Wi-Fi signal strength.

SPECIFICATIONS

Specification	Detail
Brand	EUHOMY
Model Name	HZB-15NF
Product Dimensions	11.8"D x 9.1"W x 13.1"H
Capacity (Ice Basket)	1.6 Pounds
Wattage	135 watts

Specification	Detail
Voltage	115 Volts
Refrigerant	R600a
Ice Production per Day	40 Pounds
Item Weight	19.29 pounds
Color	Black
UPC	850076222765

WARRANTY AND SUPPORT

Warranty Information

Your EUHOMY Smart Nugget Ice Maker comes with a **1-year comprehensive warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the quality and performance of your appliance.

Customer Support

For technical support, troubleshooting assistance, or warranty claims, please contact EUHOMY customer service. Our dedicated team is available to assist you with any questions or concerns regarding your pebble ice maker.

Please refer to the contact information provided on the EUHOMY official website or your purchase documentation for the most up-to-date support channels.

Related Documents - HZB-15NF

User Manual of Product 1: EUH/GMY Nugget los Maker Countency, 20ths Day, 2 Way Water Roff, Set Cleaning Pathol for Morer Machine with 30: Reservol; Los Makers Counted Island for Inno. Office, Bar.

Euhomy IM-03S Nugget Ice Maker User Manual & Instructions

Comprehensive user manual for the Euhomy IM-03S countertop nugget ice maker. Includes setup, operation, cleaning, maintenance, troubleshooting, and warranty information.



Euhomy HZB-15NF Ice Maker User Manual and Troubleshooting Guide

Comprehensive user manual for the Euhomy HZB-15NF ice maker, covering operation, safety precautions, maintenance, troubleshooting, technical specifications, and warranty information.



EUHOMY IM021-BGR-EH-HD Grey Countertop Ice Maker - 27 lbs/Day

Discover the EUHOMY IM021-BGR-EH-HD, a compact and efficient grey countertop ice maker. Produces up to 27 lbs of bullet ice daily with fast 6-minute cycles, self-cleaning, and quiet operation. Includes ice scoop.



Euhomy IM-12S Portable Nugget Ice Maker Instruction Manual

This instruction manual provides detailed guidance on operating, maintaining, and troubleshooting the Euhomy IM-12S Portable Nugget Ice Maker. Learn about safety precautions, unit components, cleaning procedures, technical specifications, and warranty information.



Euhomy IM-F Ice Maker: Instruction Manual, Operation, and Troubleshooting Guide

Comprehensive guide for the Euhomy IM-F ice maker, covering safety precautions, operation, installation, maintenance, specifications, warranty, and troubleshooting tips.



EUHOMY HZB-12M Crescent Ice Maker Quick Guide

Quick start guide for the EUHOMY HZB-12M Crescent Ice Maker, covering essential setup, first-time cleaning, ice making process, maintenance, and frequently asked questions to ensure optimal performance and longevity.