Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XINFUTE MYB-A1C

User Manual

XINFUTE MYB-A1C Air Conditioner Remote Control

Model: MYB-A1C

Product Overview

This manual provides instructions for the XINFUTE MYB-A1C remote control, designed for use with TCL LED Backlight ECO AC Air Conditioners. This remote control offers essential functions for managing your air conditioner's settings, including temperature, mode, fan speed, and more. It is an original replacement unit, ready for use without complex pairing.



Figure 1: Front view of the MYB-A1C remote control with Celsius temperature display.

Setup and Battery Installation

The XINFUTE MYB-A1C remote control requires two AAA batteries (not included) for operation. No pairing or complex setup is required; simply insert the batteries, and the remote is ready to use.



Figure 2: Back view of the MYB-A1C remote control with the battery compartment closed.

1. Locate the battery compartment on the back of the remote control.
2. Press down on the "PUSH" tab and slide the battery cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.

Important Battery Information: Do not mix new and worn batteries, or different types of batteries. If the remote control will not be used for an extended period, remove the batteries to prevent leakage and damage.



Figure 3: Back view of the MYB-A1C remote control with the battery compartment open.

Operating Instructions

Point the remote control directly at the air conditioner's receiver. Ensure there are no obstructions between the remote and the air conditioner.

Button	Function
Power Button	Turns the air conditioner ON or OFF.
MODE	Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
ECO	Activates or deactivates the energy-saving ECO mode.
TIMER	Sets the timer for automatic ON/OFF operation.
FAN	Adjusts the fan speed.
SLEEP	Activates the sleep mode for quiet operation and optimized temperature control during sleep.
DISPLAY	Controls the display on the air conditioner unit.
SWING ◄ / SWING ►	Controls the horizontal or vertical swing of the air outlet.
HEALTH	Activates health-related functions (e.g., air purification, ionizer), if available on your AC model.
TURBO	Activates maximum cooling/heating for rapid temperature change.

Button	Function
LOCK	Locks the remote control buttons to prevent accidental changes.
AUH	Specific function, refer to your air conditioner's main manual for details.

Special Functions:

- **Changing Temperature Display (°C / °F):** To switch between Celsius (°C) and Fahrenheit (°F) temperature display, press the **MODE** button and the **SWING ►** button simultaneously.
- **Locking the Remote Control:** To lock the remote control buttons and prevent unintended operation, press and hold the **LOCK** button for approximately 3 seconds. Repeat the action to unlock.
- **Silent Mode:** To enter Silent Mode, press and hold the **FAN** button for approximately 3 seconds. This mode reduces fan noise for quieter operation.



Figure 4: Front view of the MYB-A1C remote control with Fahrenheit temperature display.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your remote control.

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the surface or internal components.

- **Battery Replacement:** Replace batteries when the remote's range decreases or buttons become unresponsive. Always replace both batteries at the same time with new ones of the same type (AAA).
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, remove the batteries.

Troubleshooting

If you experience issues with your remote control, try the following steps:

- **Remote Not Responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace the batteries with fresh AAA batteries.
  - Ensure there are no obstructions between the remote control and the air conditioner's receiver.
  - Verify that you are within the effective operating range of the air conditioner.
- **Buttons Not Working:**
  - Check if the remote control is in "Lock" mode. If so, press and hold the **LOCK** button for 3 seconds to unlock it.
  - Ensure the remote's infrared emitter is clean and not obstructed.

If the issue persists after following these steps, please refer to the Warranty and Support section for further assistance.

Specifications

Feature	Detail
Model Number	MYB-A1C
Brand	XINFUTE
Compatible With	TCL LED Backlight ECO AC Air Conditioners
Material	ABS Material
Color	As Shown (White)
Power Source	2 x AAA Batteries (not included)
Product Dimensions	4 x 3 x 1 inches (approximate)
Item Weight	2.4 ounces (approximate)

Warranty and Support

Warranty: This product comes with a one-year warranty from the date of purchase.
Customer Support: All products are inspected before shipment. If you are not satisfied with your purchase or encounter any issues, please contact the seller within 24 hours of receipt. For further assistance or warranty claims, please reach out to XINFUTE customer service through the platform where the purchase was made.

© 2025 XINFUTE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F32GRKB4

More documents and user manuals: **https://manuals.plus/**