

CWX250331142

# Generic 270L Grey PP Rattan Garden Storage Box Instruction Manual

Model: CWX250331142

## INTRODUCTION

---

This manual provides detailed instructions for the assembly, operation, and maintenance of your Generic 270L Grey PP Rattan Garden Storage Box. This storage chest is designed to offer an excellent solution for decluttering your garden, patio, or terrace. Constructed from durable PP material with a rattan look, it is weather-resistant, UV-resistant, lightweight, and easy to move. Its timeless design integrates seamlessly with various outdoor and indoor decors, providing ample storage space for cushions, pillows, and other household or garden items.

## SAFETY INFORMATION

---

- Read all instructions carefully before assembly and use.
- Ensure all components are present and undamaged before beginning assembly.
- Assemble the storage box on a flat, stable surface to prevent tipping.
- Keep children and pets away from the assembly area to avoid injury from small parts.
- Do not allow children to play inside the storage box to prevent suffocation.
- Do not overload the storage box. Distribute weight evenly.
- Avoid placing heavy or sharp objects on the lid.

## PACKAGE CONTENTS

---

Please verify that all the following components are included in your package:

- Side Panels (2)
- Front Panel (1)
- Back Panel (1)
- Bottom Panel (1)
- Lid Sections (3)
- Hinge Mechanisms and Pins (Set)
- Assembly Hardware (Screws, connectors)

## SETUP AND ASSEMBLY

---

Follow these steps to assemble your garden storage box. It is recommended to have two people for easier assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, flat, and soft surface to prevent scratches.
2. **Assemble Side and Front/Back Panels:** Connect the side panels to the front and back panels using the provided connectors. Ensure they click securely into place.
3. **Attach Bottom Panel:** Slide the bottom panel into the grooves of the assembled side, front, and back panels. Press down firmly until it is fully seated and secure.
4. **Attach Lid Sections:** Position the three lid sections onto the top of the box. Align the hinge points on the lid sections with the corresponding hinge points on the back panel of the box.
5. **Install Hinge Mechanisms:** Secure the hinge mechanisms to the lid sections and the back panel using the provided pins or screws. Ensure the lid opens and closes smoothly without obstruction.



Image: Open view of the assembled storage box, illustrating the interior space and the lid's hinge mechanism. This shows how the lid sections are connected and how the box provides ample storage.



Image: A detailed close-up of the lid hinge mechanism, highlighting the connection points and the robust design that allows for smooth opening and closing of the lid sections.

## OPERATING INSTRUCTIONS

---

- **Opening the Lid:** Gently lift the lid sections from the front handles. The hinges are designed to support the lid's movement.
- **Closing the Lid:** Lower the lid sections carefully until they rest securely on the top edges of the box. Ensure all sections are properly aligned to prevent gaps.
- **Storing Items:** Place items such as cushions, garden tools, or other outdoor accessories inside the box. Avoid overfilling to ensure the lid closes properly and to prevent damage to the contents or the box.
- **Placement:** Position the storage box on a level surface in your garden, patio, or terrace. While weather-resistant, prolonged exposure to extreme weather conditions should be minimized for extended product life.



Image: Front view of the fully assembled and closed grey PP rattan garden storage box, showcasing its exterior design and handles.

## MAINTENANCE

Proper maintenance will extend the life and appearance of your storage box.

- **Cleaning:** Use a mild soap solution and a soft cloth to clean the surfaces. Avoid abrasive cleaners or harsh chemicals that could damage the PP material. Rinse with clean water and dry thoroughly.
- **Storing:** If possible, store the box in a cool, dry place indoors during extreme weather conditions (e.g., heavy snow, prolonged rain, or intense heat). If stored outdoors, protect it with a waterproof cover.
- **Moisture Management:** After rain or snowfall, wipe and dry any excess water or snow from flat surfaces, especially the lid. Ensure sufficient air circulation to avoid moisture-related damage such as mold or mildew.
- **UV Protection:** While UV-resistant, prolonged direct sunlight can eventually affect the material. Consider placing the box in a shaded area or using a UV-protective cover for maximum longevity.

## TROUBLESHOOTING

- **Lid does not close properly:** Check for any obstructions inside the box or along the edges. Ensure the box is on a level surface and that the hinge mechanisms are correctly installed and not bent.
- **Box feels unstable:** Verify that all panels are securely connected and that the bottom panel is fully seated. Ensure the box is placed on a firm, level surface.
- **Water accumulation inside:** Check that the lid is fully closed and properly aligned. Ensure the box is not placed in an area where water can pool around its base. Consider using a waterproof cover during heavy precipitation.

## SPECIFICATIONS

Feature	Detail
Model Number	CWX250331142

Feature	Detail
Material	PP (Polypropylene) with Rattan Look
Color	Grey
Capacity	270 Liters
Dimensions (L x W x H)	118.5 cm x 44.5 cm x 51 cm (approximately 46.7 in x 17.5 in x 20.1 in)
Unit Count	1.0 Count



Image: Dimensional diagram of the storage box, clearly indicating its length (118.5 cm), width (44.5 cm), and height (51 cm) for reference.

## WARRANTY AND SUPPORT

This product is manufactured to high-quality standards. For any questions regarding assembly, operation, or maintenance, please refer to the retailer or manufacturer's customer support channels. Please retain your proof of purchase for any warranty claims.