

## Hicozy HAMBZD5DG

# HiCOZY Clear View Countertop Ice Maker

Model: HAMBZD5DG - User Manual

## 1. IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before operating the appliance.
- Do not immerse the power cord, plug, or any part of the appliance in water or other liquids.
- Supervise children when the appliance is in use.
- Do not operate the appliance with a damaged cord or plug. Contact customer service for repair.
- Ensure the appliance is placed on a stable, level surface with adequate ventilation.
- Use only potable water in the ice maker.
- Unplug the appliance before cleaning or when not in use.

## 2. PRODUCT OVERVIEW

The HiCOZY Clear View Countertop Ice Maker is designed for convenient ice production in your home or office. It features a transparent lid, ambient lighting, and an automatic cleaning function.



Image 2.1: The HiCOZY Clear View Countertop Ice Maker, showing its compact design, transparent lid, control panel, and included ice scoop.

### Package Contents:

- HiCOZY Ice Maker Unit
- Ice Basket
- Ice Scoop
- User Manual

## 3. SETUP AND FIRST USE

---

### 3.1 Unpacking

1. Carefully remove the ice maker from its packaging.
2. Remove all packaging materials, including any tape or protective films.
3. Inspect the appliance for any damage. If damaged, do not operate and contact customer support.

### 3.2 Placement

1. Place the ice maker on a flat, stable, and level surface.
2. Ensure there is at least 6 inches (15 cm) of space around the unit for proper ventilation. Avoid placing near heat sources or in direct sunlight.
3. Ensure the power outlet is easily accessible.

## Compact Size



Image 3.1: The compact size of the HiCOZY ice maker on a kitchen countertop, illustrating its dimensions (12.4"D x 11.3"W x 9.5"H).

### 3.3 Initial Cleaning

Before first use, it is recommended to clean the unit. Refer to the 'Automatic Cleaning' section for detailed instructions.

### 3.4 First Ice Production

1. Open the lid and remove the ice basket.

2. Fill the water reservoir with potable water up to the MAX fill line. Do not overfill.
3. Replace the ice basket and close the lid.
4. Plug the power cord into a grounded electrical outlet.
5. Press the **Power Button** to turn on the unit.
6. Select your desired ice size (Small or Large) using the **Mode Button**.
7. The unit will begin the ice-making cycle. The first few batches of ice may be smaller or irregular. Discard the first 3-4 batches of ice.

## 4. OPERATING INSTRUCTIONS

---

### 4.1 Control Panel

The intuitive control panel provides clear indicators and simple buttons for operation.

# Smart Light Indicators

Check the Status with a Glance



Image 4.1: The control panel of the HiCOZY ice maker, showing the illuminated indicators for water level, ice full, ice making, and cleaning status.

- **Power Button:** Turns the unit on or off.
- **Mode Button:** Press to switch between Small and Large ice sizes. Press and hold for 3 seconds to activate the automatic cleaning mode.
- **Light Button:** Toggles the ambient lighting on or off.

## 4.2 Ice Making Process



1. Ensure the water reservoir is filled.
2. Press the **Power Button**.
3. Select desired ice size (Small or Large). The unit will begin making ice.
4. The first batch of 9 ice cubes will be ready in approximately 6-8 minutes.
5. The ice maker can produce up to 26 lbs of ice per day.




Image 4.2: A refreshing drink with ice, demonstrating the rapid ice-making capability of the unit.

## 2 Ice Cube Sizes to Choose



Image 4.3: Visual representation of the two available ice cube sizes: small for quick chilling and large for longer-lasting chill.

### 4.3 Indicator Lights

- **Blue Light (Flashing):** Indicates insufficient water. Refill the water reservoir.
- **Blue Light (Solid):** Indicates ice is being made.
- **White Light (Solid):** Indicates the ice basket is full. Remove ice to continue production.
- **White Light (Flashing):** Indicates the unit is in cleaning mode.



## 4.4 Ambient Lighting

The built-in ambient lighting can be controlled using the **Light Button** on the control panel. This feature allows for visibility in low-light conditions.



Image 4.4: The ice maker with its ambient lighting feature, providing illumination in a dimly lit room.

## 4.5 Clear View Cover

The transparent cover allows you to monitor the ice-making process without opening the lid, maintaining optimal temperature and hygiene.

# Clear View Cover

## A New Perspective on Ice Making



Image 4.5: A close-up view of the ice maker's transparent cover, allowing observation of ice formation.

### 4.6 Portable Handle

The ice maker is equipped with a detachable handle for easy transportation.

# Detachable Handle Design

Bring Portable Icy Fun to Your Home



Image 4.6: A user carrying the HiCOZY ice maker by its integrated handle, highlighting its portability.

## 5. MAINTENANCE

### 5.1 Automatic Cleaning Function

The ice maker features an automatic cleaning cycle to maintain hygiene and performance.

1. Ensure the water reservoir is filled with clean water.



2. Press and hold the **Mode Button** for 3 seconds to activate the cleaning mode. The white light will flash.
3. The unit will perform an internal rinse cycle.
4. Once the cleaning cycle is complete, drain the water from the unit by unplugging it and removing the drain plug (usually located at the bottom or side).
5. Replace the drain plug securely.

## Automatic Tube Cleaning

Easy to Clean, Safe to Use



Image 5.1: A visual representation of the internal water circulation during the automatic cleaning process.

### 5.2 Regular Cleaning

- Unplug the ice maker before cleaning.
- Remove the ice basket and clean it with mild detergent and warm water. Rinse thoroughly.
- Wipe the interior and exterior surfaces of the unit with a soft cloth dampened with mild detergent.
- Ensure all parts are dry before reassembling and operating.
- For optimal performance, clean the unit regularly, especially if used frequently.

### 5.3 Storage

If the ice maker will not be used for an extended period:

1. Perform an automatic cleaning cycle and drain all water.
2. Ensure the interior is completely dry to prevent mold or mildew growth.
3. Store the unit in a cool, dry place, away from direct sunlight.

## 6. TROUBLESHOOTING

Review the following common issues and solutions before contacting customer support.

Problem	Possible Cause	Solution
"Insufficient Water" indicator flashing	Water reservoir is empty or below minimum level.	Add potable water to the reservoir up to the MAX fill line.
"Full Ice" indicator solid	Ice basket is full.	Remove ice from the basket. The unit will resume ice production.
No ice production	<ul style="list-style-type: none"><li>• Unit not powered on.</li><li>• No water in reservoir.</li><li>• Ambient temperature too high.</li><li>• Ventilation blocked.</li></ul>	<ul style="list-style-type: none"><li>• Press Power button.</li><li>• Fill water reservoir.</li><li>• Ensure unit is in a cool, well-ventilated area.</li><li>• Clear any obstructions around vents.</li></ul>
Ice cubes are small or irregular	<ul style="list-style-type: none"><li>• First few cycles.</li><li>• Water temperature too high.</li><li>• Air bubbles in water.</li></ul>	<ul style="list-style-type: none"><li>• Discard first few batches.</li><li>• Use colder water.</li><li>• Ensure water is fresh.</li></ul>

## 7. SPECIFICATIONS

Feature	Detail
Model Number	HAMBZD5DG
Brand	HiCOZY



Feature	Detail
Product Dimensions	14.45 x 10.08 x 12.4 inches
Item Weight	13.01 Pounds
Water Tank Capacity	1.4 Liters
Ice Production	Up to 26 lbs per day
Ice Cycle Time	6-8 minutes per batch (9 cubes)
Ice Cube Sizes	Small, Large (Bullet Ice)
Material	Plastic, Stainless Steel
Special Feature	Portable, Self-Cleaning, Ambient Lights, Clear View Cover

## 8. WARRANTY AND SUPPORT







### 8.1 Warranty Information

This product comes with a manufacturer's warranty. Please refer to the warranty card included in your packaging or visit the official HiCOZY website for detailed warranty terms and conditions.

### 8.2 Customer Support

For any questions, technical assistance, or service inquiries, please contact HiCOZY customer support. Contact information can typically be found on the product packaging, the official HiCOZY website, or through your retailer.

You may also refer to the official Installation Manual (PDF) for additional guidance[Download Installation Manual](#)

	<p><a href="#">HiCOZY HIM-D5 Ice Maker User Manual</a></p> <p>User manual for the HiCOZY HIM-D5 portable ice maker, providing instructions on operation, maintenance, troubleshooting, and warranty.</p>
	<p><a href="#">HiCOZY HIM-D4 Ice Maker User Manual - Operation and Maintenance Guide</a></p> <p>Official user manual for the HiCOZY HIM-D4 countertop ice maker. Learn how to install, operate, clean, and troubleshoot your ice maker. Includes specifications and warranty information.</p>
	<p><a href="#">HiCOZY MBBS1 Ice Maker User Manual</a></p> <p>Comprehensive user manual for the HiCOZY MBBS1 Ice Maker, detailing installation, operation, maintenance, troubleshooting, specifications, and warranty information to ensure optimal performance and longevity.</p>
	<p><a href="#">HiCOZY CB23H Ice Maker User Manual</a></p> <p>Comprehensive user manual for the HICOZY CB23H Ice Maker, covering introduction, warnings, package contents, diagram, specifications, installation, button functions, operation instructions, cleaning, troubleshooting, and warranty information.</p>
	<p><a href="#">HiCOZY F3 Slushie Machine &amp; Ice Cream Maker User Manual</a></p> <p>User manual for the HiCOZY F3 Slushie Machine &amp; Ice Cream Maker, a 5-in-1 frozen drink and dessert maker for home use. Includes safety precautions, operating instructions, cleaning guide, and troubleshooting tips.</p>
	<p><a href="#">HiCOZY Ice Maker User Manual - Model MBBS1</a></p> <p>Comprehensive user manual for the HICOZY Ice Maker, Model MBBS1, covering operation, installation, maintenance, troubleshooting, and warranty information.</p>