Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ollny NYA1000A

Ollny 1000LED 328FT Warm White Christmas String Lights Instruction Manual

Model: NYA1000A

1. Introduction

Thank you for choosing Ollny 1000LED 328FT Warm White Christmas String Lights. This product is designed to provide versatile and durable lighting for various indoor and outdoor decoration needs. Please read this manual carefully before installation and use to ensure safe and optimal performance.

2. Important Safety Information

- Always ensure the power supply is disconnected before installation or maintenance.
- This product operates on a 29V low voltage plug and has passed UL standards for safety.
- Do not attempt to modify or repair the lights or power adapter. Contact customer support if issues arise.
- Ensure all connections are secure and protected from moisture, especially for outdoor use.
- Keep out of reach of children and pets.
- The remote control requires 1 CR2032 battery. Ensure proper battery insertion and dispose of used batteries according to local regulations.

3. Package Contents

- 1 x Ollny 1000LED 328FT Warm White String Lights
- 1 x Power Adapter (29V Low Voltage)
- 1 x Remote Control (1 CR2032 battery required, not included)
- 1 x User Manual

4. Setup Instructions

1. **Unpack the Lights:** Carefully uncoil the string lights from their packaging. The lights are designed with thin, flexible wiring to minimize tangling.
2. **Connect Power:** Connect the string lights to the provided 29V low voltage power adapter. Ensure the connection is firm.

3. **Placement:** Position the lights in your desired location. The 328-foot length is suitable for large areas, such as a 9-foot Christmas tree or extensive outdoor decorations. The flexible wire allows for easy manipulation around branches, fences, or other structures.
4. **Plug In:** Plug the power adapter into a standard electrical outlet.
5. **Initial Check:** Before final placement, press the ON button on the remote control or the button on the adapter to confirm the lights illuminate correctly.



Image: The Ollny 1000LED Warm White Christmas String Lights, coiled and ready for setup, showing the power adapter and remote control.



Image: Ollny 1000LED Warm White Christmas String Lights illuminating an outdoor patio area, including a Christmas tree and table setting.

5. Operating Instructions

5.1 Remote Control Functions

The included remote control allows for convenient operation of your Ollny string lights. Ensure the CR2032 battery is correctly installed in the remote.



Image: A visual representation of the remote control, highlighting the 8 lighting modes and 3 timer functions available for the Ollny Christmas Lights.

- **ON/OFF:** Press the 'ON' button to turn the lights on, and 'OFF' to turn them off.
- **8 Lighting Modes:** Cycle through the following modes using the corresponding buttons or the 'MODE' button on the adapter:
  - Steady On
  - In Wave
  - Sequential
  - Slo-glo
  - Chasing Flash
  - Fade
  - Twinkle Flash
  - Combination

- **Timer Function:** Set the lights to automatically turn on and off daily. Available timer modes are 4 hours, 6 hours, and 8 hours. Once set, the lights will operate for the selected duration and then turn off, repeating the cycle every 24 hours.
- **Dimming:** Adjust the brightness level using the 'DIM' buttons. There are 4 brightness levels (100%, 75%, 50%, 25%) to suit your preference.
- **Memory Function:** The lights retain the last selected mode and brightness setting when turned off and on again.



Image: A visual comparison of the Ollny Christmas Lights operating at four different brightness levels, from 100% to 25%.

5.2 Adapter Button Control

The power adapter also features a button to cycle through the 8 lighting modes if the remote control is not available.

6. Maintenance

- **Cleaning:** Disconnect from power before cleaning. Wipe the lights and wires with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.

- **Storage:** When not in use, carefully coil the lights and store them in a cool, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically inspect the lights and wiring for any damage, fraying, or loose connections. Discontinue use if any damage is found.

7. Troubleshooting

Problem	Possible Cause	Solution
Lights do not turn on.	No power, loose connection, remote battery dead.	Check power outlet, ensure adapter is securely connected, replace remote battery (CR2032).
Remote control not working.	Dead battery, obstruction, out of range.	Replace CR2032 battery, ensure clear line of sight to the receiver, operate within range.
Lights flicker or dim unexpectedly.	Unstable power, damaged wiring.	Ensure stable power supply. If flickering persists, inspect wiring for damage. Discontinue use if damaged.

8. Specifications

- **Brand:** Ollny
- **Model Number:** NYA1000A
- **Light Color:** Warm White
- **Number of LEDs:** 1000
- **Total Length:** 328 Feet (100 meters)
- **Power Source:** DC (Plug-in)
- **Voltage:** 29V
- **Wattage:** 9W
- **Waterproof Rating:** IP44 (Rainproof, Snowproof, Sunproof, Windproof)
- **Indoor/Outdoor Usage:** Outdoor/Indoor
- **Special Features:** 8 Lighting Modes, Remote Control, Timer (4H/6H/8H), 4 Brightness Levels, Memory Function
- **Material:** Copper, Plastic
- **Color Temperature:** 2700 Kelvin
- **Controller Type:** Remote Control
- **Remote Battery:** 1 x CR2032 (required)
- **Certifications:** UL Certified



Image: The Ollny Christmas Lights are shown in an outdoor setting, emphasizing their IP44 waterproof rating and resilience against various weather conditions.



Image: The lights are depicted as safe to touch, with a child and adult interacting with them, underscoring the UL Certification.

9. Product Videos

9.1 Ollny Christmas Lights Features Overview

Your browser does not support the video tag.

Video: This video provides an overview of the Ollny Christmas Lights, showcasing their super bright illumination, IP44 waterproof rating, UL certification, 8 lighting modes, 4 brightness levels, 3 timer modes, and memory function. It demonstrates how these features contribute to creating a festive atmosphere.

9.2 Warm White Lights Preview

Your browser does not support the video tag.

Video: A brief preview demonstrating the warm white illumination of the Ollny string lights, highlighting their soft and inviting glow.

10. Warranty and Support

For any product inquiries, technical support, or warranty claims, please contact Ollny customer service at BrightHopeUS@outlook.com. Please provide your order number for faster service.

© 2025 Ollny. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F32TCZKC

More documents and user manuals: **https://manuals.plus/**