

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [MassaMAX](#) /
- › [MassaMAX MD906 & Cover Bundle Instruction Manual](#)

MassaMAX MD906

MassaMAX MD906 & Cover Bundle Instruction Manual

Model: MD906

1. INTRODUCTION

This manual provides comprehensive instructions for the safe and effective use, maintenance, and troubleshooting of your MassaMAX MD906 Massage Chair and its accompanying protective cover. Please read this manual thoroughly before operating the product and retain it for future reference.

The MassaMAX MD906 massage chair features a 3D massage mechanism, 5 massage techniques, and 12 preset massage programs along an SL Track. It also includes full-body airbag squeezing massage and stretching massage to target various muscle groups. The bundle includes a protective cover designed to safeguard your chair.

2. PRODUCT COMPONENTS



Figure 2.1: MassaMAX MD906 Massage Chair and Protective Cover. This image displays the complete bundle, including the massage chair in a reclined position and the separate protective cover.



Figure 2.2: Protective Cover with Dimensions. This image illustrates the dimensions of the protective cover, measuring approximately 53.1 inches in height, 63.0 inches in length, and 37.6 inches in width, ensuring a proper fit for the MD906 chair.

3. SETUP AND ASSEMBLY

The MassaMAX MD906 massage chair typically arrives partially assembled. Follow these general steps for setup. Refer to the separate assembly guide included in your packaging for detailed, model-specific instructions.

1. **Unpacking:** Carefully remove all components from the packaging. Inspect for any damage during transit. Retain packaging materials for potential future transport or service.
2. **Placement:** Position the chair on a flat, stable surface, ensuring adequate clearance around the chair for reclining and leg rest extension. Allow at least 10 inches from a wall for full recline.
3. **Assembly (if required):** Connect any detached components such as the leg rest, armrests, or remote control holder as per the assembly guide. Ensure all connections are secure.
4. **Power Connection:** Plug the power cord securely into the chair's power inlet, then into a grounded electrical outlet. Ensure the power switch on the chair (if present) is in the OFF position before plugging

in.

5. **Initial Check:** Before first use, ensure all cables are properly routed and not pinched.

4. OPERATING INSTRUCTIONS

The MassaMAX MD906 is controlled via an integrated remote panel. Familiarize yourself with the controls before beginning a massage session.

4.1. Power On/Off

- To power on, press the power button on the remote control.
- To power off, press and hold the power button until the chair shuts down.

4.2. Massage Techniques and Programs

The MD906 offers a variety of massage techniques and preset programs:



Figure 4.1: Multiple Massage Techniques and Air Massage. This diagram illustrates the 5 massage techniques (Kneading, Rolling, Shiatsu, Tapping, Knocking, Tapping/Kneading combination), 5 speed levels, 3 levels of air massage intensity, and the lower back heating function.



Figure 4.2: 12 Auto Massage Modes. This image displays the various preset massage programs available, including Relax Massage, Sleep Massage, Relief, Lady, Baby Recovery, Back & Waist Massage, Comfort Massage, Waist & Hips Massage, Office Regimen, Stretch Massage, Shoulder & Neck Massage, and Older.

- **Preset Programs:** Select from 12 pre-programmed massage routines designed for various needs (e.g., Relax, Sleep, Stretch, Back & Waist).
- **Manual Techniques:** Choose specific massage techniques such as Kneading, Rolling, Shiatsu, Tapping, or Knocking. Adjust speed and intensity as desired.
- **Airbag Massage:** Activate full-body airbag compression massage for arms, shoulders, hips, and calves. Adjust intensity levels.
- **Lower Back Heating:** Engage the heating function for soothing warmth in the lower back area.

4.3. SL Massage Track and Mechanical Hands

The MD906 utilizes an advanced SL-shaped massage track and intelligent mechanical massage hands to provide a comprehensive massage experience.

S+L Massage Track

 SL Shape

 Point




Figure 4.3: S+L Massage Track. This illustration shows the extended S+L massage track, designed to follow the natural curvature of the spine from the neck and shoulders down through the back, waist, hips, and thighs, ensuring a comprehensive massage.

Intelligent Mechanical Massage Hands



Figure 4.4: Intelligent Mechanical Massage Hands. This image highlights the sophisticated mechanical rollers that mimic human hands, providing precise and effective massage movements along the SL track.

- The SL track extends from your neck down to your glutes, providing a consistent massage along the entire spine.
- The mechanical hands are designed to replicate the feel of a professional masseuse, adapting to your body's contours.

4.4. Stretching Function

The chair includes a stretching massage function, often referred to as "Yoga Stretch," which gently extends and decompresses the spine and limbs.

Yoga Stretch




Figure 4.5: Yoga Stretch Function. This image demonstrates the chair's ability to gently stretch the user's body, promoting spinal decompression and muscle relaxation.

5. PROTECTIVE COVER USAGE AND CARE

The included protective cover is designed to shield your MassaMAX MD906 massage chair from dust, spills, and minor abrasions, helping to maintain its appearance and longevity.

Anti-scratch



Figure 5.1: Anti-scratch Protective Cover. This image shows the protective cover in use, highlighting its ability to prevent scratches and minor damage to the chair's surface, especially from pets.

Sun proof



Figure 5.2: Sun Proof Protective Cover. This image illustrates the cover's material properties that help protect the chair from UV damage and fading when exposed to sunlight.

5.1. Applying the Cover

- Ensure the chair is powered off and in its upright position before applying the cover.
- Carefully drape the cover over the entire chair, ensuring it fits snugly and covers all exposed surfaces.

5.2. Cleaning the Cover

- Wipe the cover with a damp cloth and mild soap if necessary.
- Do not machine wash or tumble dry the cover, as this may damage the material.
- Allow the cover to air dry completely before storing or reapplying to the chair.

6. MAINTENANCE AND CARE

Regular maintenance will ensure the longevity and optimal performance of your MassaMAX MD906 massage chair.

- **Cleaning the Chair:**
 - Before cleaning, ensure the chair is unplugged from the power outlet.

- Wipe the surface of the chair with a soft, damp cloth. For stubborn stains, use a mild, non-abrasive cleaner specifically designed for upholstery.
 - Do not use harsh chemicals, solvents, or abrasive cleaning agents, as these can damage the chair's finish.
 - Allow the chair to air dry completely before plugging it back in or using it.
- **General Care:**
 - Avoid exposing the chair to direct sunlight or extreme temperatures, which can cause fading or material degradation.
 - Keep the chair away from sources of moisture or high humidity.
 - Do not place heavy objects on the chair or stand on it.
 - Regularly check the power cord for any signs of damage. If damaged, contact customer support immediately.

7. TROUBLESHOOTING

If you encounter any issues with your MassaMAX MD906 massage chair, refer to the following common troubleshooting steps. If the problem persists, contact customer support.

Problem	Possible Cause	Solution
Chair does not power on.	Power cord not securely plugged in; Power outlet not functioning; Main power switch off.	Ensure power cord is fully inserted into both the chair and the wall outlet. Test the outlet with another device. Check if the main power switch on the chair is in the ON position.
Massage intensity feels too weak/strong.	Incorrect program or manual setting selected.	Adjust the intensity settings using the remote control. Try a different preset program.
Airbags are not inflating/deflating properly.	Air hose kinked or disconnected; Air pump malfunction.	Check for any visible kinks or disconnections in air hoses (if accessible). If problem persists, contact customer support.
Unusual noises during operation.	Loose components; Internal mechanism issue.	Ensure all visible components are secure. If the noise is persistent or loud, discontinue use and contact customer support.

8. PRODUCT SPECIFICATIONS

Specification	Detail
Brand	MassaMAX
Model Number	MD906
Style	MassaMAX MD906 & COVER Bundle

Specification	Detail
Back Style	Ladder Back
Arm Style	Rounded
Leg Style	Straight Leg
Form Factor	Recliner
Included Components	Foot Rest, Protective Cover
Indoor/Outdoor Usage	Indoor
Age Range (Description)	Adult
ASIN	B0F32VRNSJ
Date First Available	March 31, 2025

9. WARRANTY AND SUPPORT

Your MassaMAX MD906 & Cover Bundle is backed by a **3-year protection plan**. MassaMAX is committed to ensuring your complete satisfaction.

- **Customer Support:** For any questions, assistance, or warranty claims, our dedicated customer support team is available 24/7.
- **Contact Information:** Please refer to the contact details provided in your product packaging or visit the official MassaMAX store on Amazon for support options.
- **Online Resources:** For additional information and resources, you can visit the [MassaMAX Store on Amazon](#).