

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Delta Q](#) /
- › [Delta Q Quick Espresso Capsule Machine - User Manual](#)

Delta Q Quick

Delta Q Quick Espresso Capsule Machine - User Manual

Model: Quick (012722) | Brand: Delta Q

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new Delta Q Quick Espresso Capsule Machine. Please read these instructions thoroughly before first use and retain them for future reference.



Image 1: The Delta Q Quick Espresso Capsule Machine in Red.

2. PRODUCT OVERVIEW

The Delta Q Quick Espresso Capsule Machine is designed for convenient preparation of espresso beverages using the Delta Q capsule system. Its compact design and user-friendly features make it suitable for various kitchen environments.

Key Features:

- **Capsule System:** Exclusively designed for Delta Q capsules.
- **Water Tank:** 0.8 L capacity (approximately 21 ounces) for multiple servings without frequent refilling.
- **Used Capsule Container:** Holds up to 10 used capsules.
- **Energy Efficiency:** Rated A++ for reduced power consumption.
- **Multi-Drink System:** Programmable sizes for customized beverage volume.
- **Pressure System:** 19-bar pressure pump for optimal extraction and rich crema.
- **Heating Element:** 1450W powerful boiler for quick heating.
- **One-Touch Operation:** Simple interface for ease of use.

Components:

Familiarize yourself with the main components of your espresso machine:

- Water Reservoir (removable)
- Capsule Insertion Slot
- Beverage Dispenser
- Drip Tray (removable)
- Used Capsule Container (integrated with drip tray)
- Control Panel (Power button, Espresso/Lungo buttons)



Image 2: Product dimensions: 15"D x 7.4"W x 12"H.

3. SETUP

1. **Unpacking:** Carefully remove all packaging materials and ensure all components are present. Place the machine on a stable, flat, and heat-resistant surface.
2. **Initial Cleaning:** Before first use, wash the water reservoir and drip tray with warm, soapy water. Rinse thoroughly and dry.
3. **Fill Water Reservoir:** Remove the water reservoir from the back of the machine. Fill it with fresh, cold drinking water up to the 'MAX' line. Reattach the reservoir securely to the machine.
4. **First Use Rinse Cycle:**

- Place an empty cup on the drip tray.
- Press the power button to turn on the machine. Wait for the indicator lights to stop blinking, indicating the machine is ready.
- Press the Lungo (larger cup) button without a capsule inserted. The machine will dispense hot water, cleaning the internal system. Repeat this process 2-3 times.
- Discard the water. Your machine is now ready for use.

Specifications




Image 3: Filling the water reservoir of the Delta Q Quick Espresso Capsule Machine.

4. OPERATING INSTRUCTIONS

Making an Espresso:

1. **Power On:** Ensure the water reservoir is filled and the machine is plugged in. Press the power button. The indicator lights will blink during heating and become steady when ready (approx. 35 seconds).
2. **Insert Capsule:** Lift the lever to open the capsule insertion slot. Insert one Delta Q capsule. Close the lever firmly.
3. **Place Cup:** Place your preferred cup (espresso or lungo size) on the drip tray.
4. **Select Beverage Size:**
 - For a standard espresso, press the small cup button.
 - For a lungo (larger coffee), press the large cup button.
5. **Brewing:** The machine will begin brewing. The brewing process will stop automatically once the selected volume is dispensed.
6. **Enjoy:** Remove your freshly brewed espresso and enjoy.
7. **Eject Capsule:** After brewing, lift the lever to eject the used capsule into the internal container. Close the lever.

Programming Beverage Volume:

You can customize the volume for both espresso and lungo settings:

1. Ensure the machine is on and ready.
2. Insert a capsule and place a cup.
3. Press and hold the desired beverage button (small or large cup).
4. Release the button when your desired volume is reached. The machine will remember this setting for future brews.

Helpful Video:

Your browser does not support the video tag.

Video 1: General instructions on how to use a mini espresso machine, including filling the water tank and brewing. (Source: cutesun)

Your browser does not support the video tag.

Video 2: Overview of a multi-pod coffee maker, demonstrating different capsule types and brewing. (Source: CAPXSNOB Official Store)

5. MAINTENANCE

Regular cleaning ensures optimal performance and longevity of your espresso machine.

Daily Cleaning:

- **Empty and Clean Drip Tray:** Remove the drip tray and empty any accumulated liquid. Wash with warm, soapy water and rinse.
- **Empty Used Capsule Container:** The used capsule container is integrated with the drip tray. Empty it and clean as above.
- **Wipe Machine:** Wipe the exterior of the machine with a soft, damp cloth.

Weekly Cleaning (Water Reservoir):

- Remove the water reservoir. Wash it with warm, soapy water. Rinse thoroughly to remove all soap residue.
- Refill with fresh water before reattaching.

Descaling:

Descaling should be performed periodically (e.g., every 3-6 months, depending on water hardness and usage) to remove mineral buildup. Refer to the full product manual or Delta Q's official website for detailed descaling instructions and recommended descaling solutions.

6. TROUBLESHOOTING

If you encounter issues with your machine, consult the following common problems and solutions:

Problem	Possible Cause	Solution
Machine does not turn on.	No power supply.	Check if the power cord is securely plugged into a working outlet.
No coffee is dispensed.	Water reservoir empty; capsule not inserted correctly; machine not heated.	Fill water reservoir; ensure capsule is correctly placed and lever is closed; wait for indicator lights to become steady.
Coffee is cold or lukewarm.	Machine not fully heated; machine needs descaling.	Wait for indicator lights to stabilize; perform descaling procedure.
Water leaks from the machine.	Water reservoir not correctly positioned; drip tray full.	Ensure water reservoir is securely in place; empty and clean drip tray.

7. SPECIFICATIONS

-
- **Brand:** Delta Q
 - **Model Name:** Quick
 - **Item Model Number:** 012722
 - **Color:** Red
 - **Product Dimensions:** 15"D x 7.4"W x 12"H
 - **Water Deposit:** 0.8 L
 - **Capsules Deposit:** 10 Capsules
 - **Energy Efficiency:** A++
 - **Power:** 1450 Watts
 - **Voltage:** 120 Volts
 - **Operation Mode:** Fully Automatic
 - **Coffee Input Type:** Capsule (Delta Q System)
 - **Item Weight:** 6.6 pounds
 - **Manufacturer:** Delta Q

8. WARRANTY AND SUPPORT

Your Delta Q Quick Espresso Capsule Machine comes with a standard manufacturer's warranty. For specific warranty details, including coverage period and terms, please refer to the documentation included with your purchase or visit the official Delta Q website.

For technical support, spare parts, or any inquiries regarding your product, please contact Delta Q customer service through their official channels. Contact information can typically be found on the product packaging or the brand's website.

Visit the official Delta Q Store for more information:[Delta Q Store](#)